
ЛОС

LCD Monitor User Manual I2367Fн/I2267Fwн/ I2367F/I2267Fw/I2067F

SEE IT. FEELIT IN NEW DIMENSIONS

ADC



©2012 AOC. All Rights Reserved.

Safety	3
National Conventions	3
Power	4
Installation	5
Cleaning	6
Other	7
Setup	8
Contents in Box	8
Setup Stand & Base	9
Adjusting Viewing Angle	11
Connecting the Monitor	
Adjusting	13
Setting Optimal Resolution	13
Windows Vista	13
Windows XP	15
Windows ME/2000	16
Hotkeys	17
OSD Setting	18
Luminance	19
Image Setup	21
Color Setup	23
Picture Boost	25
OSD Setup	27
Extra	29
Exit	
LED Indicator	
Driver	
Monitor Driver	
Windows 7	
Windows Vista	
Windows XP	
Windows 2000	
Windows ME	
i-Menu	
e-Saver	
Screen+	
Troubleshoot	
Specification	
General Specification	
Preset Display Modes	
Pin Assignments	
Plug and Play	
Regulation	
CE Declaration of Conformity	
WEEE Declaration	
Service	
Warranty Statement for Europe	
Warranty Statement for North & South America (excluding Brazil)	58

Safety

National Conventions

The following subsections describe notational conventions used in this document.

Notes, Cautions, and Warnings

Throughout this guide, blocks of text may be accompanied by an icon and printed in bold type or in italic type. These blocks are notes, cautions, and warnings, and they are used as follows:



NOTE: A NOTE indicates important information that helps you make better use of your computer system.



CAUTION: A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.



WARNING: A WARNING indicates the potential for bodily harm and tells you how to avoid the problem. Some warnings may appear in alternate formats and may be unaccompanied by an icon. In such cases, the specific presentation of the warning is mandated by regulatory authority.

Power

The monitor should be operated only from the type of power source indicated on the label. If you are not sure of the type of power supplied to your home, consult your dealer or local power company.

The monitor is equipped with a three-pronged grounded plug, a plug with a third (grounding) pin. This plug will fit only into a grounded power outlet as a safety feature. If your outlet does not accommodate the three-wire plug, have an electrician install the correct outlet, or use an adapter to ground the appliance safely. Do not defeat the safety purpose of the grounded plug.

Unplug the unit during a lightning storm or when it will not be used for long periods of time. This will protect the monitor from damage due to power surges.

A Do not overload power strips and extension cords. Overloading can result in fire or electric shock.

To ensure satisfactory operation, use the monitor only with UL listed computers which have appropriate configured receptacles marked between 100 - 240V ~, Min. 5A

A The wall socket shall be installed near the equipment and shall be easily accessible.

For use only with the attached power adapter (Output 12Vdc) which have UL,CSA listed license (Only for monitors with power adapter).

Manufacturers:

I2367FH/I2267FWH

1) TPV ELECTRONICS(FUJIAN) CO., LTD model : ADPC1245

2) HONOR ELECTRONIC CO., LTD model: ADS-65LSI-12-1 12045G

I2367F/I2267FW/I2067F

1) TPV ELECTRONICS(FUJIAN) CO., LTD model : ADPC1236

2) HONOR ELECTRONIC CO., LTD model : ADS-45NP-12-1 12036G

Installation

Do not place the monitor on an unstable cart, stand, tripod, bracket, or table. If the monitor falls, it can injure a person and cause serious damage to this product. Use only a cart, stand, tripod, bracket, or table recommended by the manufacturer or sold with this product. Follow the manufacturer's instructions when installing the product and use mounting accessories recommended by the manufacturer. A product and cart combination should be moved with care.


Never push any object into the slot on the monitor cabinet. It could damage circuit parts causing a fire or electric shock. Never spill liquids on the monitor.

Do not place the front of the product on the floor.

If you mount the monitor on a wall or shelf, use a mounting kit approved by the manufacturer and follow the kit instructions.

Leave some space around the monitor as shown below. Otherwise, air-circulation may be inadequate hence overheating may cause a fire or damage to the monitor.

See below the recommended ventilation areas around the monitor when the monitor is installed on the stand:




Installed with stand

Cleaning

Clean the cabinet regularly with cloth. You can use soft-detergent to wipe out the stain, instead of strong-detergent which will cauterize the product cabinet.

When cleaning, make sure no detergent is leaked into the product. The cleaning cloth should not be too rough as it will scratch the screen surface.

Please disconnect the power cord before cleaning the product.



Other


If the product is emitting a strange smell, sound or smoke, disconnect the power plug IMMEDIATELY and contact a Service Center.

All Make sure that the ventilating openings are not blocked by a table or curtain.

LOD not engage the LCD monitor in severe vibration or high impact conditions during operation.

LO not knock or drop the monitor during operation or transportation.

Setup




Not all signal cables (Analog, and HDMI cables) will be provided for all countries and regions. Please check with the local dealer or AOC branch office for confirmation.


Setup Stand & Base

Please setup or remove the base following the steps as below.


Setup:



Remove:



Unit standing without base is available. (Caution: must put unit in flat surface. Any uneven or sloped surface may result unit damaged or injury to user.)




Adjusting Viewing Angle

For optimal viewing it is recommended to look at the full face of the monitor, then adjust the monitor's angle to your own preference.

Hold the stand so you will not topple the monitor when you change the monitor's angle.

You are able to adjust the monitor's angle from -5° to 23 °.





Do not touch the LCD screen when you change the angle. It may cause damage or break the LCD screen.

Connecting the Monitor

Cable Connections In Back of Monitor and Computer:



- 1. Power
- 2. Earphone
- 3. Audio
- 4. D-Sub
- 5. HDMI

To protect equipment, always turn off the PC and LCD monitor before connecting.

- 1 Connect the power cable to the AC port on the back of the monitor.
- 2 Connect one end of the 15-pin D-Sub/HDMI cable to the back of the monitor and connect the other end to the computer's D-Sub/HDMI port.
- 3 Turn on your monitor and computer.

If your monitor displays an image, installation is complete. If it does not display an image, please refer Troubleshooting.

Connecting the Monitor

Cable Connections In Back of Monitor and Computer:



- 1. Power
- 2. D-Sub
- 3. DVI

To protect equipment, always turn off the PC and LCD monitor before connecting.

- 1 Connect the power cable to the AC port on the back of the monitor.
- 2 Connect one end of the 15-pin D-Sub/DVI cable to the back of the monitor and connect the other end to the computer's D-Sub/DVI port.
- 3 Turn on your monitor and computer.

If your monitor displays an image, installation is complete. If it does not display an image, please refer Troubleshooting.

Adjusting

Setting Optimal Resolution

Windows Vista

For Windows Vista:

- 1 Click START.
- 2 Click CONTROL PANEL.



3 Click Appearance and Personalization.




4 Click Personalization



5 Click **Display Settings.**



6 Set the resolution SLIDE-BAR to Optimal preset resolution.



Windows XP

For Windows XP:


1 Click START.




2 Click SETTINGS.

3 Click CONTROL PANEL.

4 Click Appearance and Themes.




5 Double click **DISPLAY.**



6 Click SETTINGS.


7 Set the resolution SLIDE-BAR to Optimal preset resolution



Windows ME/2000

- For Windows ME/2000:
- 1 Click START.
- 2 Click SETTINGS.
- 3 Click CONTROL PANEL.
- 4 Double click **DISPLAY**.
- 5 Click SETTINGS.
- 6 Set the resolution SLIDE-BAR to Optimal preset resolution .

Hotkeys



1	Menu/Enter
2	Volume/ ∧
3	Eco (DCR)/\/
4	Source/Auto/Exit
5	Power

1	Menu/Enter
2	4:3 or wide / \wedge
3	Eco(DCR)/\/
4	Source/Auto/Exit
5	Power

Power

Press the Power button to turn on/off the monitor.

Eco (DCR) #/

Press the Eco key continuously to select the Eco mode of brightness and DCR on when there is no OSD. (Eco mode hot key may not be available in all models).

Jc`iaY#∕∖

When there is no OSD, press Volume adjust volume.

4:3 or wide image ratio / \wedge

When there is no OSD, press > hotkey continuously to change 4:3 or wide image ratio. (If the product screen size is 4:3 or input signal resolution is wide format, the hot key is disable to adjust.)

Auto / Exit / Source hot key

When there is no OSD, press Auto/Source button continuously about 2 second to do auto configure. When the OSD is closed, press Source button will be Source hot key function. Press Source button continuously to select the input source showed in the message bar, press Menu/Enter button to change to the source selected.

OSD Setting



Basic and simple instruction on the control keys.

- 1) Press the MENU-button to activate the OSD window.
- 2) Press \or\to navigate through the functions. Once the desired function is highlighted, press the MENU-button to activate it . press \or\to navigate through the sub-menu functions. Once the desired function is highlighted, press MENU-button to activate it.
- Press∧or ∨ to change the settings of the selected function. Press AUTO to exit. If you want to adjust any other function, repeat steps 2-3.
- 4) OSD Lock Function: To lock the OSD, press and hold the **MENU button** while the monitor is off and then press power button to turn the monitor on. To un-lock the OSD - press and hold the **MENU button** while the monitor is off and then press power button to turn the monitor on.

Notes:

- 1) If the product has only one signal input, the item of "Input Select" is disable to adjust.
- If the product screen size is 4:3 or input signal resolution is wide format, the item of "Image Ratio" is disable to adjust.
- One of non-standard ECO, DCR, DCB, Picture Boost is activated, the other three of functions are turned off accordingly.

Luminance



1. Press **MENU** (Menu) to display menu.



2. Press \land or \lor to select \checkmark (Luminance), and press **MENU** to enter.



3. Press \land or \lor to select submenu, and press **MENU** to enter.

Tarr is		1000			-		and some	8 (j=
	- martine		No.	C.	- X test	4	1.11	∧ @==
	-						- Carlos	. @=
	4. 10000 1	-	4 -	•		-	a service of the serv	x @
								•
	_				_			0 @==

4. Press $\land or \lor$ to adjust.





5. Press AUTO to exit.

	Brightness	0-100		Backlight Adjustment		
	Contrast	0-100		Contrast from Digital-register.		
		Standard	~	Standard Mode		
		Text	T	Text Mode		
	Eco mode	Internet	E	Internet Mode		
1	Ecomode	Game	1000 m	Game Mode		
1		Movie	Ø	Movie Mode		
		Sports	30	Sports Mode		
		Gamma1		Adjust to Gamma1		
	Gamma	Gamma2		Adjust to Gamma 2		
		Gamma3		Adjust to Gamma 3		
		Off		Disable dynamic contrast ratio		
	DCR	On	DCR	Enable dynamic contrast ratio		
		Weak	·			
	Quardriva	Medium		Adjust the response time		
	Overdrive	Strong		Adjust the response time		
		Off				

Image Setup



1. Press **MENU** (Menu) to display menu.



2. Press \land or \lor to select (Image Setup), and press **MENU** to enter.




3. Press \land or \lor to select submenu, and press **MENU** to enter.

Note: 1 Note: 1 Note: 1 Note: 1	Nex 2 1 view 2 1
Report In Contraction Contraction	

4. Press $\land or \lor$ to adjust.





I (#

• @=

× @⊒_45

5. Press AUTO to exit.

Clock	0-100	Adjust picture Clock to reduce Vertical-Line noise.
Phase	0-100	Adjust Picture Phase to reduce Horizontal-Line noise
Sharpness	0-100	Adjust picture sharpness
 H.Position	0-100	Adjust the horizontal position of the picture.
V.Position	0-100	Adjust the vertical position of the picture.

Color Setup




1. Press **MENU** (Menu) to display menu.



2. Press \land or \lor to select (Color Setup), and press **MENU** to enter.

-	-	C	N.	1	4	1	and the second	× @=
			-					× @=
Stiller 4	<i>a.</i> •		1705					× (∰ ■ (∰
								0 @=

3. Press $\wedge \, or \, \lor \;\;$ to select submenu, and press MENU to enter.







5. Press **AUTO** to exit.

		Warm		Recall Warm Color Temperature from EEPROM.
		Normal		Recall Normal Color Temperature from EEPROM.
		Cool		Recall Cool Color Temperature from EEPROM.
	Color setup.	sRGB		Recall SRGB Color Temperature from EEPROM.
			Red	Red Gain from Digital-register
		User	Green	Green Gain Digital-register.
			Blue	Blue Gain from Digital-register
		Full Enhance	on or off	Disable or Enable Full Enhance Mode
	DCB Mode	Nature Skin	on or off	Disable or Enable Nature Skin Mode
		Green Field	on or off	Disable or Enable Green Field Mode
		Sky-blue	on or off	Disable or Enable Sky-blue Mode
		AutoDetect	on or off	Disable or Enable AutoDetect Mode
	DCB Demo		On or off	Disable or Enable Demo

Picture Boost



1. Press **MENU** (Menu) to display menu.



2. Press \land or \lor to select (Picture Boost), and press **MENU** to enter.



3. Press \land or \lor to select submenu, and press **MENU** to enter.



4. Press \land or \lor to adjust.





5. Press AUTO to exit.

	Frame Size	14-100	Adjust Frame Size
	Brightness	0-100	Adjust Frame Brightness
	Contrast	0-100	Adjust Frame Contrast
•	H. position	0-100	Adjust Frame horizontal Position
	V.position	0-100	Adjust Frame vertical Position
	Bright Frame	on or off	Disable or Enable Bright Frame

OSD Setup



1. Press **MENU** (Menu) to display menu.



2. Press \land or \lor to select (OSD Setup), and press **MENU** to enter.



3. Press \land or \lor to select submenu, and press **MENU** to enter.



4. Press \land or \lor to adjust.





5. Press AUTO to exit.

	H.Position	0-100	Adjust the horizontal position of OSD
6	V.Position	0-100	Adjust the vertical position of OSD
	Timeout	5-120	Adjust the OSD Timeout
	Transparence	0-100	Adjust the transparence of OSD
	Language		Select the OSD language

Extra



1. Press **MENU** (Menu) to display menu.



2. Press \land or \lor to select \checkmark (Extra), and press **MENU** to enter.



3. Press \land or \lor to select submenu, and press **MENU** to enter.

1		1			5			-		-		() 2-
An tong	i	1.1	i						ete:		v	æ
				1000	- 4.5	1	and the second second		-		8	ŧ
			-								0	e e

4. Press \land or \lor to adjust.



5. Press **AUTO** to exit.

I2367Fн /I2267Fwн

		Auto	Select to Auto Detect input signal
	Input Select	D-SUB	Select D-SUB Signal Source as Input
		HDMI1	Select HDMI1 Source as Input
		HDMI 2	Select HDMI 2 Source as Input
21	Auto Config	yes or no	Auto adjust the picture to default
	Image Ratio	wide or 4:3	Select wide or 4:3 format for display
	DDC-CI	yes or no	Turn ON/OFF DDC-CI Support
	Reset	yes or no	Reset the menu to default
	Off Timer	0~24hours	Select timing to turn off the monitor.
	Information		Show the information of the main image and sub-image source

I2367F/I2267Fw/I2067F

	Input Select	Auto	Select to Auto Detect input signal		
		D-SUB	Select D-SUB Signal Source as Input		
		DVI	Select DVI Source as Input		
21	Auto Config	yes or no	Auto adjust the picture to default		
	Image Ratio	wide or 4:3	Select wide or 4:3 format for display		
· ·	DDC-CI	yes or no	Turn ON/OFF DDC-CI Support		
	Reset	yes or no	Reset the menu to default		
	Off Timer	0~24hours	Select timing to turn off the monitor.		
	Information		Show the information of the main image and sub-image source		

Exit



1. Press **MENU** (Menu) to display menu.





3. Press AUTO to exit.

LED Indicator

Status	LED Color	
Full Power Mode	Blue	
Active-off Mode	orange	

Driver

Monitor Driver


Windows 7

1.Start Windows® 7

2.Click on the 'Start' button and then click on 'Control Panel'.



3. Click on the 'Display' icon.



4.Ckick on the "Change display settings" button.

Contractor in	ancompliane here a payle	- P
Control Facel Home Adjust Homaton Se Control and Adjust Charge Joseph Active	Moder if musice to wait solutify only your assess. No constrained to condition of two execution areas of an according to being one primes oppose to temporary unregard and prevention of the instance the instance.	•
Adjantikaliga vat Senaterrænise (25)	Charles 201 Annual Index 201 Annual Charger - 520a	
	[[Aut.]]	
Service Personalization Device and Protect		

5.Click the "Advanced Settings" button.

The second local Action local	Lower Resolution	_	Cares Conta Para
Ounge the	appearance of your display		
	. 0	Second Second	
Display	1-Note Default Fail front +		
Overdation	EDI - Idili (resentrealed) = (anticase = 4		
No. of column	for tendage or order	Adventioning .	
	tig forti cloud		
	08	dent Arry	

6.Click the "Monitor" tab and then click the "Properties" button.

100 Million	Menitor	Traublesho	et Color A	lanagere	ent 🗐 Ge	Force 9100	MG
Monito	ar Type						
	Gene	ic PaP Man	OF .				
8							_
						Properties	
Monit	er Settings						
	un solites de						
_		1080					
60 H	WR						•
		that this mo					
Ged	ing this ch	eck box allo	va yeu to a	elect day			÷.
Ced	ing this ch P draphty	eck boxalle covertly. Th	va yeu to a	elect day			es.
Ced	ing this ch	eck boxalle covertly. Th	va yeu to a	elect day			in.
Cean cean dama	ing this ch in display iged head	eck boxalle covertly. Th	va yeu to a	elect day			iner.
Ced	ing this ch in display iged head	eck boxalle covertly. Th	va yeu to a	elect day			in.
Clear centro dataria	ing this ch in display iged head	eck box allo correctly. Th ware	va yeu to a	elect day			
Clear centro dataria Calar	ing this ch A Soplay ged head	eck box allo correctly. Th ware	va yeu to a	elect day			itar
Clear centro dataria Calar	ing this ch A Soplay ged head	eck box allo correctly. Th ware	va yeu to a	elect day			
Clear centro dataria Calar	ing this ch A Society ged head	eck box allo correctly. Th ware	va yeu to a	elect day			
Clear centro dataria Calar	ing this ch A Society ged head	eck box allo correctly. Th ware	va yeu to a	elect day			
Clear centro dataria Calar	ing this ch A Society ged head	eck box allo correctly. Th ware	va yeu to a	elect day			
Clear Cerimi danne Galar	ing this ch A Society ged head	eck box allo correctly. Th ware	va yeu to a	elect day			

7.Click the "Driver" tab.




8. Open the "Update Driver Software-Generic PnP Monitor" window by clicking on "**Update Driver...** "and then click the **"Browse my computer for driver software"** button.



9. Select "Let me pick from a list of device drivers on my computer".



10. Click the **"Have Disk"** button. Click on the **"Browse"** button and navigate to the following directory: X:\Driver\module name (where X is the drive letter designator for the CD-ROM drive).



11. Select the "xxx.inf" file and click the "Open" button. Click the "OK" button.

12. Select your monitor model and click the "**Next**" button. The files will be copied from the CD to your hard disk drive.

13. Close all open windows and remove the CD.

14. Restart the system. The system will automatically select the maximum refresh rate and corresponding Color Matching Profiles.

Windows Vista

- Carlo Constitutes 110 1 8 Call Street 0 BR Bart a mar -- 10 in the <u>ی</u>، Ä --Ci 0 23 新 R.
- 1. Click "Start " and "Control Panel". Then, double-click on "Appearance and Personalization".

2. Click "Personalization" and then "Display Settings".



3. Click "Advanced Settings ... ".



4. Click "Properties" in the "Monitor" tab. If the "Properties" button is deactivated, it means the configuration for your monitor is completed. The monitor can be used as is.


If the message "Windows needs..." is displayed, as shown in the figure below, click "Continue".



5. Click "Update Driver..." in the "Driver" tab.

nere Pal' Monter Trapertar	Generic Pull Monitor Properties
Server Driver Departs	General Down Details
Servers hill Madar	Server: TriP Mankar
Device spor. Benton Newberk mei Device sons Louise an W2D3 / Entre M2D (17 (Remark Copy)	Drive Provide: Microsoft Drive Date: 6:01:0006 Drive Vesaur: 6:3 6001 16306 Data Sprie: microsoft verdina
Destroit a sutting property	Doper Database To rever database about the driver lies. Update Driver To update the three software for the on-oce. Brit Rack Driver If the driver liab. After and drive the driver, rell social to the prevoule natified driver.
·	Dealine Daubles fre selected devoe. Unintial To uninetal the diver Julyanoed.
	DK Dend

6. Check the "Browse my computer for driver software" checkbox and click "Let me pick from a list of device drivers on my computer".



7. Click on the 'Have disk...' button, then click on the 'Browse...' button and then select the appropriate drive F:\Driver (CD-ROM Drive).

8. Select your monitor model and click on the 'Next' button.


9. Click "Close" \rightarrow "Close" \rightarrow "OK" \rightarrow "OK" on the following screens displayed in sequence.

Windows XP


- 1. Start Windows® XP
- 2. Click on the 'Start' button and then click on 'Control Panel'.



3. Select and click on the category 'Appearance and Themes'



4. Click on the 'Display' Item.



5. Select the 'Settings' tab then click on the 'Advanced' button.

isplay Propertie	5	2
Themes Desktop	Screen Saver Appearance Settin	900
Display:	Apr on 3D Prophet III	
Screen resolution		
1024 by 7	60 pixelo	
	Iroubleshoot	Advanced
	OK Cance	Apply A

- 6. Select 'Monitor' tab
- If the 'Properties' button is inactive, it means your monitor is properly configured. Please stop installation.
- If the 'Properties' button is active, click on 'Properties' button.

Please follow the steps below.

g and Play Monito	r and 3D Prophet III	Properties 🛛 🛜
⊴ GeForce3	Selection	Color Correction
Seneral Adapter	Monitor Troubleshoe	ot Color Managemen
Monitor type Plug and Play	y Monitor	Properties
Monitor settings		
Screen refresh rate:		
60 Hertz		4
	ox allows you to select displ y connectly. This may lead to sware.	
	ОК	Cancel Apply


7. Click on the 'Driver' tab and then click on 'Update Driver...' button.

Plug and Play Monitor Properties 🛛 😨 🔀	
General Driver	Plug and Play Monitor Properties
Plug and Play Monitor	General Driver
Device type: Monitors	Plug and Play Monitor
Manufacturer: (Standard monitor types)	Driver Provider: Microsoft
Location: on 3D Prophet III	Driver Date: 6/6/2001
Device status	Driver Version: 5.1.2001.0
This device is working properly.	Digital Signer: Microsoft Windows XP Publisher
If you are having problems with this device, click Troubleshoot to start the troubleshooter.	Driver Details To view details about the driver files.
	Ugdate Driver To update the driver for this device.
Iroubleshoot	Boll Baok Driver If the device fails after updating the driver, roll back to the previously installed driver.
Device usage: Use this device (enable)	Uninatal To uninatal the driver (Advanced).
OK Cancel	OK Cancel


8. Select the 'Install from a list or specific location [advanced]' radio button and then click on the 'Next' button.



9. Select the 'Don't Search. I will choose the driver to install' radio button. Then click on the 'Next' button.



10. Click on the 'Have disk...' button, then click on the 'Browse...' button and then select the appropriate drive F: (CD-ROM Drive).



11. Click on the 'Open' button, then click the 'OK' button.

12. Select your monitor model and click on the 'Next' button.

- If you can see the 'has not passed Windows® Logo testing to verify its compatibility with Windows® XP' message, please click on the 'Continue Anyway' button.

13. Click on the 'Finish' button then the 'Close' button.

14. Click on the 'OK' button and then the 'OK' button again to close the Display Properties dialog box.

Windows 2000

- 1. Start Windows® 2000
- 2. Click on the 'Start' button, point to 'Settings', and then click on 'Control Panel'.
- 3. Double click on the 'Display' Icon.
- 4. Select the 'Settings' tab then click on 'Advanced...'.
- 5. Select 'Monitor'
- If the 'Properties' button is inactive, it means your monitor is properly configured. Please stop installation.
- If the 'Properties' button is active. Click on 'Properties' button. Please follow the steps given below.
- 6. Click on 'Driver' and then click on 'Update Driver...' then click on the 'Next' button.
- 7. Select 'Display a list of the known drivers for this device so that I can choose a specific driver', then click on 'Next' and then click on 'Have disk...'.
- 8. Click on the 'Browse...' button then select the appropriate drive F: (CD-ROM Drive).
- 9. Click on the 'Open' button, then click on the 'OK' button.
- 10. Select your monitor model and click on the 'Next' button.
- 11. Click on the 'Finish' button then the 'Close' button.

If you can see the 'Digital Signature Not Found' window, click on the 'Yes' button.

Windows ME

- 1. Start Windows® Me
- 2. Click on the 'Start' button, point to 'Settings', and then click on 'Control Panel'.
- 3. Double click on the 'Display' Icon.
- 4. Select the 'Settings' tab then click on 'Advanced...'.
- 5. Select the 'Monitor' button, then click on 'Change...' button.
- 6. Select 'Specify the location of the driver(Advanced)' and click on the 'Next' button.
- 7. Select 'Display a list of all the drivers in a specific location, so you can choose the driver you want', then click on 'Next' and then click on 'Have Disk...'.
- 8. Click on the 'Browse...' button, select the appropriate drive F: (CD-ROM Drive) then click on the 'OK' button.
- 9. Click on the 'OK' button, select your monitor model and click on the 'Next' button.
- 10. Click on 'Finish' button then the 'Close' button.

i-Menu



Welcome to "i-Menu" software by AOC. i-Menu makes it easy to adjust your monitor display setting by using on screen menus instead of the OSD button on the monitor. To complete installation, please follow the installation guide.

i-Me	enu		umina	ance	9	
	*					
				×		
0	Contrast		50	🔆 Brightness		50
γ	Gamma	4 Gamma 1	Þ	🔯 Eco Mode	∢ 🔽	Þ
	DCR					
						-
1			/10	6		9

e-Saver



Welcome to use AOC e-Saver monitor power management software! The AOC e-Saver features Smart Shutdown functions for your monitors, allows your monitor to timely shutdown when PC unit is at any status (On, Off, Sleep or Screen Saver); the actual shutdown time depends on your preferences (see example below). Please click on "driver/e-Saver/setup.exe" to start installing the e-Saver software, follow the install wizard to complete software installation.

Under each of the four PC status, you may choose from the pull-down menu the desired time (in minutes) for your monitor to automatically shutdown. The example above illustrated:

- 1) The monitor will never shutdown when the PC is powered on.
- 2) The monitor will automatically shutdown 5 minutes after the PC is powered off.
- 3) The monitor will automatically shutdown 10 minutes after the PC is in sleep/stand-by mode.
- 4) The monitor will automatically shutdown 20 minutes after the screen saver appears.



You can click "RESET" to set the e-Saver to its default settings like below.

NOC		States and the	warmen and the	.
	\bigcirc			
When PC	On	no	Sleep	Screen Saver
Manitor Off	Never	After 5 minutes	After 10 minutes	After 20 minutes
		G		REALT

Screen+



Welcome to "Screen+" software by AOC, Screen+ software is a desktop screen splitting tool, it splits the desktop into different panes, each pane displays a different window. You only need to drag the window to a corresponding pane, when you want to access it. It supports multiple monitor display to make your task easier. Please follow the installation software to install it.

\times

Troubleshoot

Problem & Question	Possible Solutions	
Power LED Is Not ON	Make sure the power button is ON and the Power Cord is properly connected to a grounded power outlet and to the monitor.	
 Is the power cord connected properly? Check the power cord connection and power supply. Is the cable connected correctly? (Connected using the D-sub cable) Check the DB-15 cable connection. (Connected using the DVI cable) Check the DVI cable connection. * DVI input is not available on every model. If the power is on, reboot the computer to see the initial screen (screen), which can be seen. If the initial screen (the login screen) appears, boot the computer in applicable mode (the safe mode for Windows ME/XP/2000) and the the frequency of the video card. (Refer to the Setting the Optimal Resolution) If the initial screen (the login screen) does not appear, contact the Center or your dealer. Can you see "Input Not Supported" on the screen? You can see this message when the signal from the video card exa maximum resolution and frequency that the monitor can properly. Make sure the AOC Monitor Drivers are installed. 		
Picture Is Fuzzy & Has Ghosting Shadowing ProblemAdjust the Contrast and Brightness Controls. Press to auto adjust. Make sure you are not using an extension cable or switch box. We recommend plugging the monitor directly to the video card output c on the back .		
Picture Bounces, Flickers Or Wave Pattern Appears In The Picture	I TROM THE MONITOR AS DOSSINIE	
Monitor Is Stuck In Active Off-Mode"	The Computer Power Switch should be in the ON position. The Computer Video Card should be snugly fitted in its slot. Make sure the monitor's video cable is properly connected to the computer. Inspect the monitor's video cable and make sure no pin is bent. Make sure your computer is operational by hitting the CAPS LOCK key on the keyboard while observing the CAPS LOCK LED. The LED should either turn ON or OFF after hitting the CAPS LOCK key.	
Missing one of the primary colors (RED, GREEN, or BLUE)	Inspect the monitor's video cable and make sure that no pin is damaged. Make sure the monitor's video cable is properly connected to the computer.	
Screen image is not centered or sized properly	Adjust H-Position and V-Position or press hot-key (AUTO).	
Picture has color defects (white does not look white)	Adjust RGB color or select desired color temperature.	
Horizontal or vertical disturbances on the screen	Use Windows 95/98/2000/ME/XP shut-down mode Adjust CLOCK and FOCUS. Press to auto-adjust.	

Specification General Specification

I2367Fн

	Model name	I2367Fн
	Driving system	TFT Color LCD
	Viewable Image Size	584.2mm Diagonal
Panel	Pixel pitch	0.0884*RGB(H)mm x 0.2652(V)mm
Paner	Video	R, G, B Analog Interface ,HDMI
	Separate Sync.	H/V TTL
	Display Color	16.7M Colors
	Dot Clock	148.5MHz
	Horizontal scan range	30kHz to 83kHz
	Horizontal scan Size(Maximum)	509.18mm
	Vertical scan range	50Hz to 76Hz
	Vertical scan Size(Maximum)	286.42mm
	Optimal preset resolution	1920×1080@60Hz
Resolution	Plug & Play	VESA DDC2B/C1
	Input Connector	VGA,HDMI×2
	Input Video Signal	Analog: 0.7Vp-p(standard), 75 OHM, Positive、HDMI
	Power Source	100-240V~, 50/60Hz
	Power Consumption	Active<40W(Typical)
		Standby < 0.5 W
	Off timer	0-24 hrs
	Connector Type	VGA、HDMI×2
	Signal Cable Type	Detachable
	Dimensions & Weight:	
Physical	Height (with base)	394mm
Characteristics	Width	531.4mm
	Depth	120mm
	Weight (monitor only)	3.75kg
Environmental	Temperature:	

Operating	0° to 40°
Non-Operating	-25°to 55°
Humidity:	
Operating	10% to 85% (non-condensing)
Non-Operating	5% to 93% (non-condensing)
Altitude:	
Operating	0~ 2000m (0~ 6562 ft)
Non-Operating	0~ 12192m (0~ 40000 ft)

12267FwH

	Model number	12267F _{wh}
	Driving system	TFT Color LCD
	Viewable Image Size	546.2 mm diagoanl
	Pixel pitch	0.08265*RGB (H)mm x 0.24795(V)mm
Panel	Video	R, G, B Analog Interface, HDMI
	Separate Sync.	H/V TTL
	Display Color	16.7M Colors
	Dot Clock	148.5 MHz
	Horizontal scan range	30 kHz - 83 kHz
	Horizontal scan Size(Maximum)	476.06 mm
	Vertical scan range	55 Hz - 75 Hz
	Vertical scan Size(Maximum)	267.79 mm
	Optimal preset resolution	1920 x1080 (60 Hz)
Resolution	Plug & Play	VESA DDC2B/CI
	Input Connector	VGA,HDMI x2
	Input Video Signal	Analog: 0.7Vp-p(standard), 75 OHM, Positive,HDMI
	Power Source	100~240VAC, 50/60Hz
	Power Consumption	Active < 40 W
		Standby < 0.5W
	Off timer	0-24 hrs
	Connector Type	VGA,HDMI x2
	Signal Cable Type	Detachable
	Dimensions & Weight:	
Physical Characteristics	Height (with base)	375.6mm
Characteristics	Width	498.3mm
	Depth	120.6mm
	Weight (monitor only)	3.48 kg
	Temperature:	
Environmental	Operating	0° to 40°
	Non-Operating	-25°to 55°
	Humidity:	
	Operating	10% to 85% (non-condensing)
	Non-Operating	5% to 93% (non-condensing)
	Altitude:	
	Operating	0~ 2000m (0~ 6562 ft)
	Non-Operating	0~ 12192m (0~ 40000 ft)
L	-	

	Model number	12367F
	Driving system	TFT Color LCD
	-	584.2 mm diagoanl
	Pixel pitch	0.0884*RGB (H)mm x 0.2652(V)mm
Panel	Video	R, G, B Analog Interface, DVI
	Separate Sync.	H/V TTL
	Display Color	16.7M Colors
	Dot Clock	148.5 MHz
	Horizontal scan range	30 kHz - 83 kHz
	Horizontal scan Size(Maximum)	509.18 mm
	Vertical scan range	55 Hz - 75 Hz
	Vertical scan Size(Maximum)	286.42 mm
	Optimal preset resolution	1920 x1080 (60 Hz)
Resolution	Plug & Play	VESA DDC2B/CI
	Input Connector	VGA,DVI
	Input Video Signal	Analog: 0.7Vp-p(standard), 75 OHM, Positive,DVI
	Power Source	100~240VAC, 50/60Hz
	Davies Oceaning fine	Active < 30 W
	Power Consumption	Standby < 0.5W
	Off timer	0-24 hrs
	Connector Type	VGA,DVI
	Signal Cable Type	Detachable
	Dimensions & Weight:	
Physical Characteristics	Height (with base)	375.6mm
Characteristics	Width	498.3mm
	Depth	120.6mm
	Weight (monitor only)	3.75 kg
	Temperature:	
Environmental	Operating	0° to 40°
	Non-Operating	-25°to 55°
	Humidity:	
		10% to 85% (non-condensing)
	Non-Operating	5% to 93% (non-condensing)
	Altitude:	
		0∼ 2000m (0∼ 6562 ft)
		0~ 12192m (0~ 40000 ft)
1	e	

I2267Fw

	Model number	I2267Fw
	Driving system	TFT Color LCD
	Viewable Image Size	546.2 mm diagoanl
	Pixel pitch	0.08265*RGB (H)mm x 0.24795(V)mm
Panel	Video	R, G, B Analog Interface, DVI
	Separate Sync.	H/V TTL
	Display Color	16.7M Colors
	Dot Clock	148.5 MHz
	Horizontal scan range	30 kHz - 83 kHz
	Horizontal scan Size(Maximum)	476.06 mm
	Vertical scan range	55 Hz - 75 Hz
	Vertical scan Size(Maximum)	267.79 mm
	Optimal preset resolution	1920 x1080 (60 Hz)
Resolution	Plug & Play	VESA DDC2B/CI
	Input Connector	VGA,DVI
	Input Video Signal	Analog: 0.7Vp-p(standard), 75 OHM, Positive,DVI
	Power Source	100~240VAC, 50/60Hz
	Power Consumption	Active < 30 W
		Standby < 0.5W
	Off timer	0-24 hrs
	Connector Type	VGA,DVI
	Signal Cable Type	Detachable
	Dimensions & Weight:	
Physical	Height (with base)	375.6mm
Characteristics	Width	498.3mm
	Depth	120.6mm
	Weight (monitor only)	3.48 kg
	Temperature:	
Environmental	Operating	0° to 40°
	Non-Operating	-25°to 55°
	Humidity:	
	-	10% to 85% (non-condensing)
	Non-Operating	5% to 93% (non-condensing)
	Altitude:	
		0~ 2000m (0~ 6562 ft)
		0~ 12192m (0~ 40000 ft)

	Model number	I2067F		
	Driving system	TFT Color LCD		
	Viewable Image Size	508.05 mm diagoanl		
	Pixel pitch	0.09225*RGB (H)mm x 0.27675(V)mm		
Panel	Video	R, G, B Analog Interface, DVI		
	Separate Sync.	H/V TTL		
	Display Color	16.7M Colors		
	Dot Clock	140 MHz		
	Horizontal scan range	30 kHz - 83 kHz		
	Horizontal scan Size(Maximum)	442.8 mm		
	Vertical scan range	55 Hz - 75 Hz		
	Vertical scan Size(Maximum)	249.075 mm		
	Optimal preset resolution	1600 x 900 (60 Hz)		
Resolution	Plug & Play	VESA DDC2B/CI		
	Input Connector	VGA,DVI		
	Input Video Signal	Analog: 0.7Vp-p(standard), 75 OHM, Positive _{,DVI}		
	Power Source	100~240VAC, 50/60Hz		
		Active < 20 W		
	Power Consumption	Standby < 0.5W		
	Off timer	0-24 hrs		
	Connector Type	VGA,DVI		
	Signal Cable Type	Detachable		
	Dimensions & Weight:			
Physical	Height (with base)	357.5mm		
Characteristics	Width	464.8mm		
	Depth	120.6mm		
	Weight (monitor only)	3.18 kg		
	Temperature:			
Environmental	Operating	0° to 40°		
	Non-Operating	-25°to 55°		
	Humidity:			
		10% to 85% (non-condensing)		
		5% to 93% (non-condensing)		
	Altitude:	, <u>,</u>		
		0∼ 2000m (0∼ 6562 ft)		
		0∼ 12192m (0∼ 40000 ft)		

Preset Display Modes


I2367Fн / I2267Fwн / I2367F / I2267Fw

STAND	Resolution	HORIZONTAL FREQUENCY(kHz)	VERTICAL FREQUENCY(Hz)
	640x480@60Hz	31.469	59.940
VGA	640x480@72Hz	37.861	72.809
_	640x480@75Hz	37.500	75.00
	800x600@56Hz	35.156	56.250
	800x600@60Hz	37.879	60.317
SVGA _	800x600@72Hz	48.077	72.188
	800x600@75Hz	46.875	75.000
	1024x768@60Hz	48.363	60.004
XGA	1024x768@70Hz	56.476	70.069
	1024x768@75Hz	60.023	75.029
	1280x1024@60Hz	63.981	60.020
SXGA _	1280x1024@75Hz	79.976	75.025
WXGA+	1440x900@60Hz	55.935	59.887
WSXGA	1680x1050@60Hz	65.290	59.954
HD	1920x1080@60Hz	67.500	60.000
***	1280x960@60HZ	60.000	60.000
IBM	640x350@70Hz	31.469	70.087
MODE -			
DOS	720x400@70Hz	31.469	70.087
MAC MODE	640x480@67Hz	35.000	66.667
VGA	0408480@07112	55.000	00.007
MAC MODE	832x624@75Hz	49.725	74.551
MAC MODE			
XGA	1024x768@75Hz	60.241	74.927


I2067F

STAND	Resolution	HORIZONTAL	VERTICAL
STAND	Resolution	FREQUENCY(kHZ)	FREQUENCY(Hz)
	640x480@60Hz	31.469	59.940
VGA	640x480@72Hz	37.861	72.809
	640x480@75Hz	37.500	75.00
	800x600@56Hz	35.156	56.250
SVGA	800x600@60Hz	37.879	60.317
	800x600@72Hz	48.077	72.188
	800x600@75Hz	46.875	75.000
	1024x768@60Hz	48.363	60.004
XGA	1024x768@70Hz	56.476	70.069
-	1024x768@75Hz	60.023	75.029
SXGA	1280x1024@60Hz	63.981	60.020
SXGA _	1280x1024@75Hz	79.976	75.025
WSXGA	1280x720@60Hz	45.000	60.000
HD	1600x900@60Hz	60.000	60.000
IBM	640x350@70Hz	31.469	70.087
MODE DOS	720x400@70Hz	31.469	70.087
MAC MODE VGA	640x480@67Hz	35.000	66.667
MAC MODE SVGA	832x624@75Hz	49.725	74.551
MAC MODE XGA	1024x768@75Hz	60.241	74.927

Pin Assignments



Pin Number	15-Pin Side of the Signal Cable
1	Video-Red
2	Video-Green
3	Video-Blue
4	N.C.
5	Detect Cable
6	GND-R
7	GND-G
8	GND-B
9	+5V
10	Ground
11	N.C.
12	DDC-Serial data
13	H-sync
14	V-sync
15	DDC-Serial clock



Pin No.	Signal Name	Pin No.	Signal Name	Pin No.	Signal Name
1	TMDS Data 2+	9	TMDS Data 0	17	DDC/CEC Ground
2	TMDS Data 2 Shield	10	TMDS Clock +	18	+5V Power
3	TMDS Data 2	11	TMDS Clock Shield	19	Hot Plug Detect
4	TMDS Data 1+	12	TMDS Clock		
5	TMDS Data 1Shield	13	CEC		
6	TMDS Data 1	14	Reserved (N.C. on		
			device		
7	TMDS Data 0+	15	SCL		
8	TMDS Data 0 Shield	16	SDA		

$ \begin{array}{c} 1 \\ 9 \\ 17 \\ 17 \\ 17 \\ 17 \\ 17 \\ 17 \\ 17 \\ 17$					
Pin Number	24-Pin Color Display Signal Cable	Pin Number	24-Pin Color Display Signal Cable		
1	TMDS data 2-	13	TMDS data 3+		
2	TMDS data 2+	14	+5V Power		
3	TMDS data 2/4 Shield	15	Ground (for+5V)		
4	TMDS data 4-	16	Hot Plug Detect		
5	TMDS data 4+	17	TMDS data 0-		
6	DDC Clock	18	TMDS data 0+		
7	DDC Data	19	TMDS data 0/5 Shield		
8	N.C.	20	TMDS data 5-		
9	TMDS data 1-	21	TMDS data 5+		
10	TMDS data 1+	22	TMDS Clock Shield		
11	TMDS data 1/3 Shield	23	TMDS Clock +		
12	TMDS data 3-	24	TMDS Clock —		

Plug and Play

Plug & Play DDC2B Feature

This monitor is equipped with VESA DDC2B capabilities according to the VESA DDC STANDARD. It allows the monitor to inform the host system of its identity and, depending on the level of DDC used, communicate additional information about its display capabilities.

The DDC2B is a bi-directional data channel based on the I2C protocol. The host can request EDID information over the DDC2B channel.

Regulation

FCC Notice

FCC Class B Radio Frequency Interference Statement WARNING: (FOR FCC CERTIFIED MODELS)

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

NOTICE :

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Shielded interface cables and AC power cord, if any, must be used in order to comply with the emission limits. The manufacturer is not responsible for any radio or TV interference caused by unauthorized modification to this equipment. It is the responsibilities of the user to correct such interference. It is the responsibility of the user to correct such interference.

CE Declaration of Conformity

This product is in conformity with the following standards

- EN60950-1:2006 and A11+A1 (Safety requirement of Information Technology Equipment).
- EN 55022:2006+A1: 2007 (Radio Disturbance requirement of Information Technology Equipment).
- EN55024:1998+A1:2001+A2:2003 (Immunity requirement of Information Technology Equipment).
- EN 61000-3-2:2006+A1: 2009+A2: 2009 (Harmonic current emissions).
- EN 61000-3-3:2008 (Voltage fluctuations & flicker) following provisions of directives applicable.
- 2006/95/EC (Low Voltage Directive).
- 2004/108/EC (EMC Directive).

• 2005/32/EC (EuP Directive, EC No. 1275/2008 mplementing Directive for Standby and Off mode power consumption) and is produced by a manufacturing organization on ISO9000 level.

WEEE Declaration

Disposal of Waste Equipment by Users in Private Household in the European Union.



This symbol on the product or on its packaging indicates that this product must not be disposed of with your other household waste.Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment.The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or the shop where you purchased the product .



WEEE/E-Waste declaration for India



This symbol on the product or on its packaging indicates that this product must not be disposed of with your other household waste.Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling in India, please visit the below web link.

www.aocindia.com/ewaste.php

Service

Warranty Statement for Europe

LIMITED THREE-YEAR WARRANTY*

AOC Color Monitors sold within Europe

AOC International (Europe) BV warrants this product to be free from defects in material and workmanship for a period of Three (3) years after the original date of consumer purchase. During this period, AOC International (Europe) BV will, at its option, either repair the defective product with new or rebuilt parts, or replace it with a new or rebuilt product at no charge except as *stated below. The defective products that are replaced become the property of AOC International (Europe) BV.

If the product appears to be defective, please contact your local dealer or refer to the warranty card when attached to the product.

Deliver the dated proof of purchase to the AOC Authorized Service Center. If you cannot deliver the product in person:

- Pack it in its original shipping container (or equivalent)
- Put the RMA number on the address label
- Put the RMA number on the shipping carton
- Insure it (or assume the risk of loss/damage during shipment)
- Pay all shipping charges

AOC International (Europe) BV is responsible neither for any damage or loss during inbound transport damage nor to inbound product that was not properly packaged.

AOC International (Europe) BV will pay the return shipping charges within one of the countries specified within this warranty statement. AOC International (Europe) BV is not responsible for any costs associated with the transportation of product across international borders. This includes the international border within the European Union.

- * This limited warranty does not cover any losses or damages that occur as a result of
- Shipping or improper installation or maintenance
- Misuse
- Neglect
- Any cause other than ordinary commercial or industrial application
- Adjustment by non-authorized source
- * Repair, modification, or installation of options or parts by anyone other than an AOC Authorized Service Center
- Improper environment
- * Excessive or inadequate heating or air conditioning or electrical powers failures, surges, or other irregularities

This limited warranty does not cover any of the product firmware or hardware that you or any third party have

modified or altered; you bear the sole responsibility and liability for any such modification or alteration.

ALL EXPRESS AND IMPLIED WARRANTIES FOR THIS PRODUCT (INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE) ARE LIMITED IN DURATION TO A PERIOD OF THREE (3) YEARS FOR PARTS AND LABOR FROM THE ORIGINAL DATE OF CONSUMER PURCHASE. NO WARRANTIES (EITHER EXPRESSED OR IMPLIED) APPLY AFTER THIS PERIOD.

AOC INTERNATIONAL (EUROPE) BV OBLIGATIONS AND YOUR REMEDIES HEREUNDER ARE SOLELY AND EXCLUSIVELY AS STATED HERE. AOC INTERNATIONAL (EUROPE) BV LIABILITY, WHETHER BASED ON CONTRACT, TORT, WARRANTY, STRICT LIABILITY, OR OTHER THEORY, SHALL NOT EXCEED THE PRICE OF THE INDIVIDUAL UNIT WHOSE DEFECT OR DAMAGE IS THE BASIS OF THE CLAIM. IN NO EVENT SHALL AOC INTERNATIONAL (EUROPE) BV BE LIABLE FOR ANY LOSS OF PROFITS, LOSS OF USE OR FACILITIES OR EQUIPMENT, OR OTHER INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGE. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. ALTHOUGH THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, YOU MAY HAVE OTHER RIGHTS, WHICH MAY VARY FROM COUNTRY TO COUNTRY. THIS LIMITED WARRANTY IS ONLY VALID FOR PRODUCTS PURCHASED IN THE MEMBER COUNTRIES OF THE EUROPEAN UNION.

Information in this document is subject to change without notice. For more details, please visit: http://www.aoc-europe.com/en/service/index.php

Warranty Statement for North & South America (excluding Brazil)

WARRANTY STATEMENT

for AOC Color Monitors Including those Sold within North America as Specified

Envision Peripherals, Inc. warrants this product to be free from defects in material and workmanship for a period of three (3) years for parts & labor and one (1) year for CRT Tube or LCD Panel after the original date of consumer purchase. During this period, EPI (EPI is the abbreviation of Envision Peripherals, Inc.) will, at its option, either repair the defective product with new or rebuilt parts, or replace it with a new or rebuilt product at no charge except as *stated below. The parts or product that are replaced become the property of EPI.

In the USA to obtain service under this limited warranty, call EPI for the name of the Authorized Service Center closest to your area. Deliver the dated proof of purchase to the EPI Authorized Service Center. If you cannot deliver the product in person:

- Pack it in its original shipping container (or equivalent)
- Put the RMA number on the address label
- Put the RMA number on the shipping carton
- Insure it (or assume the risk of loss/damage during shipment)
- Pay all shipping charges

EPI is not responsible for damage to inbound product that was not properly packaged.

EPI will pay the return shipment charges within one of the countries specified within this warranty statement. EPI is not responsible for any costs associated with the transportation of product across international borders. This includes the international borders of the countries within this warranty statements.

In the United States and Canada contact your Dealer or EPI Customer Service, RMA Department at the toll free number (888) 662-9888. Or you can request an RMA Number online at www.aoc.com/na-warranty.

* This limited warranty does not cover any losses or damages that occur as a result of:

- Shipping or improper installation or maintenance
- Misuse
- Neglect
- Any cause other than ordinary commercial or industrial application
- Adjustment by non-authorized source
- Repair, modification, or installation of options or parts by anyone other than an EPI Authorized Service Center
- Improper environment
- Excessive or inadequate heating or air conditioning or electrical power failures, surges, or other irregularities

This three-year limited warranty does not cover any of the product's firmware or hardware that you or any third party have modified or altered; you bear the sole responsibility and liability for any such modification or alteration.

ALL EXPRESS AND IMPLIED WARRANTIES FOR THIS PRODUCT (INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE) ARE LIMITED IN DURATION TO A PERIOD OF THREE (3) YEARS FOR PARTS AND LABOR AND ONE (1) YEAR FOR CRT TUBE OR LCD PANEL FROM THE ORIGINAL DATE OF CONSUMER PURCHASE. NO WARRANTIES (EITHER EXPRESSED OR IMPLIED) APPLY AFTER THIS PERIOD. IN THE UNITED STATES OF AMERICA, SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU.

EPI OBLIGATIONS AND YOUR REMEDIES HEREUNDER ARE SOLELY AND EXCLUSIVELY AS STATED HERE. EPI' LIABILITY, WHETHER BASED ON CONTRACT, TORT. WARRANTY, STRICT LIABILITY, OR OTHER THEORY, SHALL NOT EXCEED THE PRICE OF THE INDIVIDUAL UNIT WHOSE DEFECT OR DAMAGE IS THE BASIS OF THE CLAIM. IN NO EVENT SHALL ENVISION PERIPHERALS, INC. BE LIABLE FOR ANY LOSS OF PROFITS, LOSS OF USE OR FACILITIES OR EQUIPMENT OR OTHER INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGE. IN THE UNITED STATES OF AMERICA, SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES. SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. ALTHOUGH THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY HAVE OTHER RIGHTS WHICH MAY VARY FROM STATE TO STATE.

In the United States of America, this limited warranty is only valid for Products purchased in the Continental United States, Alaska, and Hawaii.

Outside the United States of America, this limited warranty is only valid for Products purchased in Canada.

Information in this document is subject to change without notice. For more details, please visit:

USA: http://us.aoc.com/support/warranty ARGENTINA: http://ar.aoc.com/support/warranty BOLIVIA: http://bo.aoc.com/support/warranty CHILE: http://cl.aoc.com/support/warranty COLOMBIA: http://co.aoc.com/warranty COSTA RICA: http://cr.aoc.com/support/warranty DOMINICAN REPUBLIC: http://do.aoc.com/support/warranty ECUADOR: http://ec.aoc.com/support/warranty EL SALVADOR: http://sv.aoc.com/support/warranty GUATEMALA: http://gt.aoc.com/support/warranty HONDURAS: http://hn.aoc.com/support/warranty NICARAGUA: http://ni.aoc.com/support/warranty PANAMA: http://pa.aoc.com/support/warranty PARAGUAY: http://py.aoc.com/support/warranty PERU: http://pe.aoc.com/support/warranty URUGUAY: http://pe.aoc.com/warranty VENEZUELA: http://ve.aoc.com/support/warranty IF COUNTRY NOT LISTED: http://latin.aoc.com/warranty



Only for AOC branded monitors sold within the continental United States.

All AOC branded monitors are now covered by the EASE Program. If your monitor malfunctions at any time during the first three months, AOC will provide a replacement monitor within 72 hours after you are approved for our program. If your monitor qualifies for the EASE program, AOC will pay for freight both ways.

Step 1: Phone our TECH Department at 888.662.9888
Step 2: Fill out and return EASE registration forms by mail or fax.
Step 3: We will issue a Return Authorization Number upon verification into the program.
Step 4: A monitor will be advance shipped to your location.
Step 5: We will issue a UPS Call Tag to pick up the defective unit.
Step 6: Please review the following chart to see your EASE program qualifications.

WARRANTY PERIOD	COVERAGE AT NO CHARGE	CUSTOMER CHARGES
Within the first three months of purchase: Covered by EASE	 New AOC monitor Call tag dispatched and return freight charges via UPS 	- None*
Between 4 months – 1 Year	- All Parts & Labor Including CRT Tube & LCD Panel	- UPS Return Freight to AOC
Between 1 Year - 3 Years: Covered by standard limited warranty	- Parts & Labor (excluding CRT Tube & LCD Panel)	- UPS Return Freight to AOC

*AOC will need to obtain a credit card number if you would like to get a new AOC monitor advanced shipped to your location, prior to the defective unit arriving at AOC's service center. If you do not wish to supply a credit card, AOC will only ship the new monitor, once the defective unit arrives at the AOC service center.



Congratulations!

This product is designed for both you and the planet!



TCO Development works for sustainable IT manufacture, use and recycling of IT products reflecting environmental, social and economic responsibility.

TCO Certified is a third party verified program, where every product model is tested by an accredited impartial test laboratory. TCO

Certified represents one of the toughest certifications for ICT products worldwide.

Some of the Usability features of TCO Certified Displays:

- Visual Ergonomics for image quality is tested to ensure top performance and reduce sight and strain problems. Important parameters are Resolution, Luminance, Contrast, Reflection and Colour characteristics
- Products are tested according to rigorous safety standards at impartial laboratories
- Electric and magnetic fields emissions as low as normal household background levels
- Workload ergonomics to ensure a good physical environment

Some of the Environmental features of TCO Certified Displays:

- Production facilities have an Environmental Management System (EMAS or ISO 14001)
- Low energy consumption to minimize climate impact
- Restrictions on Chlorinated and Brominated flame retardants, plasticizers, plastics and heavy metals such as cadmium, mercury and lead (RoHS compliance)
- Both product and product packaging is prepared for recycling
- The brand owner offers take-back options

Corporate Social Responsibility

• The brand owner demonstrates the product is manufactured under working practices that promote good labour relations and working conditions.

The Criteria Document can be downloaded from our web site. The criteria included in this label have been developed by TCO Development in co-operation with scientists, experts, users as well as manufacturers all over the world. Since the end of the 1980s TCO has been involved in influencing the development of IT equipment in a more user and environmentally friendly direction. Our ICT product labeling system began in 1992 and is now requested by users and ICT-manufacturers all over the world.

For more information, please visit **www.tcodevelopment.com**

TCO Certified Document for Displays version. 2.3