

LCD Monitor User Manual I2279VW / I2279VWHE / I2379V / I2379VHE (LED Backlight)



Safety	4
National Conventions	4
Power	5
Installation	6
Cleaning	7
Other	8
Setup	9
Contents in Box	9
Setup Stand &Base	10
Adjusting Viewing Angle	11
Connecting the Monitor	12
Adjusting	13
Setting Optimal Resolution	13
Windows 8	13
Windows 7	15
Windows Vista	17
Windows XP	19
Windows ME/2000	20
Hotkeys	21
OSD Setting	23
Luminance	24
Image Setup	26
Color Setup	
Picture Boost	
OSD Setup	32
Extra	34
Exit	
LED Indicator	37
Driver	
Monitor Driver	
Windows 8	
Windows 7	
Windows Vista	46
Windows XP	48
Windows 2000	51
Windows ME	51
i-Menu	52
e-Saver	53
Screen+	54
Troubleshoot	55
Specification	57
General Specification (I2279VW/I2279VWHE)	
Preset Display Modes (I2279VW/I2279VWHE)	58
General Specification (I2379V/I2379VHE)	59
Preset Display Modes (I2379V/I2379VHE)	
Pin Assignments	61
Plug and Play	63

Regulation	64
FCC Notice	64
WEEE Declaration	65
WEEE Declaration for India	65
RoHS Declaration for India	65
EPA Energy Star	66
Service	67
Warranty Statement for Europe	67
Warranty Statement for Middle East and Africa (MEA)	.69
AOC International (Europe) B.V.	71
Warranty Statement for North & South America (excluding Brazil)	72

Safety

National Conventions

The following subsections describe notational conventions used in this document.

Notes, Cautions, and Warnings

Throughout this guide, blocks of text may be accompanied by an icon and printed in bold type or in italic type. These blocks are notes, cautions, and warnings, and they are used as follows:



NOTE: A NOTE indicates important information that helps you make better use of your computer system.



CAUTION: A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.



WARNING: A WARNING indicates the potential for bodily harm and tells you how to avoid the problem. Some warnings may appear in alternate formats and may be unaccompanied by an icon. In such cases, the specific presentation of the warning is mandated by regulatory authority.

Power

The monitor should be operated only from the type of power source indicated on the label. If you are not sure of the type of power supplied to your home, consult your dealer or local power company.

Unplug the unit during a lightning storm or when it will not be used for long periods of time. This will protect the monitor from damage due to power surges.

A Do not overload power strips and extension cords. Overloading can result in fire or electric shock.

To ensure satisfactory operation, use the monitor only with UL listed computers which have appropriate configured receptacles marked between 100 - 240V ~, Min. 5A

A The wall socket shall be installed near the equipment and shall be easily accessible.

For use only with the attached power adapter which have CE,UL,CSA listed license (Only for monitors with power adapter).

Manufacturer:

SHENZHEN HONOR ELECTRONIC CO., LTD ADS-25FSG-19 19025GPCN: Output: 19VDC, 1.31A; TPV ELECTRONICS (FUJIAN) CO., LTD ADPC1925EX: Output: 19VDC, 1.31A;

Installation


Do not place the monitor on an unstable cart, stand, tripod, bracket, or table. If the monitor falls, it can injure a person and cause serious damage to this product. Use only a cart, stand, tripod, bracket, or table recommended by the manufacturer or sold with this product. Follow the manufacturer's instructions when installing the product and use mounting accessories recommended by the manufacturer. A product and cart combination should be moved with care.

Never push any object into the slot on the monitor cabinet. It could damage circuit parts causing a fire or electric shock. Never spill liquids on the monitor.

Do not place the front of the product on the floor.

Leave some space around the monitor as shown below. Otherwise, air-circulation may be inadequate hence overheating may cause a fire or damage to the monitor.

See below the recommended ventilation areas around the monitor when the monitor is installed on the stand:




Installed with stand

Cleaning

Clean the cabinet regularly with cloth. You can use soft-detergent to wipe out the stain, instead of strong-detergent which will cauterize the product cabinet.

When cleaning, make sure no detergent is leaked into the product. The cleaning cloth should not be too rough as it will scratch the screen surface.

Please disconnect the power cord before cleaning the product.



Other

If the product is emitting a strange smell, sound or smoke, disconnect the power plug IMMEDIATELY and contact a Service Center.

All Make sure that the ventilating openings are not blocked by a table or curtain.

L Do not engage the LCD monitor in severe vibration or high impact conditions during operation.

L Do not knock or drop the monitor during operation or transportation.

For display with glossy bezel the user should consider the placement of the display as the bezel may cause disturbing reflections from surrounding light and bright surfaces.

If the phone on the base of LCD monitor when the phone calls will affect the circuit characteristics, may cause the screen to mute or screen interference.


Setup **Contents in Box** \bigcirc Monitor \bigcirc \bigcirc \bigcirc or Adapter **CD** Manual Base * * * Power Cable Analog Cable HDMI Cable **DVI** Cable

*Not all signal cables (Power,Analog,DVI,HDMI) will be provided for all countries and regions. Please check with the local dealer or AOC branch office for confirmation.


Setup Stand & Base

Please setup or remove the base following the steps as below.

Setup:



Remove:




Adjusting Viewing Angle

For optimal viewing, it is recommended to look at the full face of the monitor, and then adjust the monitor's angle to your own preference.

Hold the stand so you will not topple the monitor when you change the monitor's angle.

You are able to adjust the monitor's angle as below.




Do not touch the LCD screen when you change the angle. It may cause damage or break the LCD screen.


Do not adjust the viewing angle over 23 degrees in order to avoid damage.

Do not put your hand close to the gap between the monitor and the base to avoid the injury when adjusting the viewing angle.

Connecting the Monitor

Cable Connections In Back of Monitor and Computer:





I2279VW/I2379V

12279VWHE/12379VHE

- 1. DC port
- 2. D-SUB
- 3. HDMI
- 4. DVI

To protect equipment, always turn off the PC and LCD monitor before connecting.

- 1. Connect the power cable to the DC port on the back of the monitor.
- 2. Turn on your monitor and computer.
- 3. Connect one end of the 15-pin D-Sub cable to the back of the monitor and connect the other end to the computer's D-Sub port.
- 4. (Optional—Requires a video card with HDMI port) -Connect one end of the HDMI cable to the back of the monitor and connect the other end to the computer's HDMI port.
- 5. (Optional –Requires a video card with DVI port)Connect one end of the DVI cable to the back of the monitor and connect the other end to the computer's DVI port.

If your monitor displays an image, installation is complete. If it does not display an image, please refer Troubleshooting.

Adjusting

Setting Optimal Resolution

Windows 8


For Windows 8:

1. Right click and click **All apps** at the bottom-right of the screen.




10 m	- N			<u></u>
1			·	
- 14	10 ⁻		8	
1 m		a see	5-	The second secon
1 m	10-		2222	1 m
* *		2		H
* *				2 mm
- mm			Name.	a marine
11 m 👘		-		
11				
		*		
2 ···			E	

- 2. Set the "View by" to "Category".
- 3. Click Appearance and Personalization.



4. Click **DISPLAY.**



5. Set the resolution **SLIDE-BAR** to Optimal preset resolution

	Serven Resolution			
of + lighteness and beschladion	- Digity + Spraw Resistor		v 6 Institution	
Change the ap	pearance of your display			
	0	Detect Marthy		
Distance Restrictions	1.FUCTOR + TXT = DEF Processed at	-		
Interaction	1601 - 1000 Recommended	Advantation		
		W. L. Park L. Law		
	NDE - THE			
	Ourgethe ap Durie Nandani Overstani	Durbs 1.0000000 Resolution 000000000000000000000000000000000000	Charge the appearance of your display	Charge the appearance of your display

Windows 7

For Windows 7:


- 1. Click **START**.
- 2. Click CONTROL PANEL.

D Internet Sufferer	Sife .
The state of the state	Salahan Sa
Takana Cattan	Distant
🔯 Windows Maska Player	A Long
Windows Photo Catley	6mm
Contraction Matteringer Terrorition	Such
All Markey Sperr	Assetters .
Mindaon Taylore	Computer
Addar Phatychogr CD 1444Crs	Convent To
Command Printige	Generated
	Default Programs
* Alfrigant	Help and Support

3. Click APPEARANCE.



4. Click **DISPLAY**



- Change the appearance of your display Datest Bandh 1 LFLSTRH + 162 - 101 Per Internal article 102-102 08. Genel 1979 154 - 16
- 5. Set the resolution SLIDE-BAR to Optimal preset resolution.

Windows Vista

For Windows Vista:

1 Click START.

2 Click CONTROL PANEL.

ALCONY OF THE OWNER	
Distance Contract	10 ms
Total Street	And a later
Taluare Date	Deserve
The Mindows Marine Player	Atlan
Windows Photo Galley	Seren
and Mandava Live Mesonger Deventual	Samb
A Minima Mastery Spece	Ananthese .
The Market Station	Computer-
Adata Phatpolog CQ	Falsenia I
20 Handon	Convert la
Constant Printyr	Ormitteel
	Default Programs
* AllTrigram	Help and Support
transform P	

3 Click Appearance and Personalization.




4 Click Personalization



5 Click **Display Settings.**



6 Set the resolution SLIDE-BAR to Optimal preset resolution



Windows XP

For Windows XP:


1 Click START.




2 Click SETTINGS.

3 Click CONTROL PANEL.

4 Click Appearance and Themes.




5 Double click **DISPLAY**.



6 Click SETTINGS.


7 Set the resolution SLIDE-BAR to Optimal preset resolution



Windows ME/2000

- For Windows ME/2000:
- 1 Click START.
- 2 Click SETTINGS.
- 3 Click CONTROL PANEL.
- 4 Double click **DISPLAY.**
- 5 Click SETTINGS.
- 6 Set the resolution SLIDE-BAR to Optimal preset resolution

Hotkeys



1	Source/ Auto/ Exit
2	Clear Vision /<
3	Widescreen / 4:3 switch />
4	Menu/Enter
5	Power

Power

Press the Power button to turn on/off the monitor.

4:3 or wide image ratio />

When there is no OSD, press > hotkey continuously to change 4:3 or wide image ratio. (If the product screen size is 4:3 or input signal resolution is wide format, the hot key is disable to adjust.)

Auto / Exit


When there is no OSD, press Auto / Exit button continuously about 2 second to do auto configure.

Source hot key

When the OSD is closed, press Source button will be Source hot key function. Press Source button to select the input source showed in the message bar, press Menu/Enter button to change to the source selected.

Clear Vision

- 1. When there is no OSD, Press the "<" button to activate Clear Vision.
- 2. Use the "<" or ">" buttons to select between weak, medium, strong, or off settings. Default setting is always "off".



3. Press and hold "<" button for 5 seconds to activate the Clear Vision Demo, and a message of "Clear Vision Demo: on" will be display on the screen for a duration of 5 seconds. Press Menu or Exit button, the message will disappear. Press and hold "<" button for 5 seconds again, Clear Vision Demo will be off.</p>



Clear Vision function provides the best image viewing experience by converting low resolution and blurry images into clear and vivid images.

Clear Vision	Weak		
	Medium	Adjust the Clear Vision	
	Strong		
	Off		
Clear Vision Demo	on or off	Disable or Enable Demo	

OSD Setting

Basic and simple instruction on the control keys.



- 1. Press the **MENU-button** to activate the OSD window.
- Press < or > to navigate through the functions. Once the desired function is highlighted, press the IIII
 MENU-button to activate. Press < or > to navigate through the sub-menu. Once the desired function is highlighted, press IIII MENU-button to activate.
- Press < or > to change the settings of the selected function. Press + AUTO to exit. If you want to adjust any other function, repeat steps 2-3.
- 4. OSD Lock Function: To lock the OSD, press and hold the III MENU-button while the monitor is off and then press power-button to turn the monitor on. To un-lock the OSD, press and hold the III MENU-button while the monitor is off and then press power-button to turn the monitor on.

Notes:

- 1. If the product has only one signal input, the item of "Input Select" is disabled.
- 2. If the product screen size is 4:3 or input signal resolution is wide format, the item of "Image Ratio" is disabled.
- 3. One of Clear vision, DCR, Color Boost, and Picture Boost functions is activated; the other three functions are turned off accordingly.

Luminance

<*>	T-+ Image betup	Court Better	Pacitive Societ	OSO Setup	×	- Di
-Contrast Unightness -East societ	Allendar Salar Allendar Salar Allendar Salar	Barrene (1 Contra 1 2 Off			
		A	μ. 	af)		

1 Press III (Menu) to display menu.



3 Press < or > to select submenu, and press \boxed{III} to enter.



4 Press < or > to adjust.


•

Lurel safer Centres Brightness Eco mode	Hann Setup 50 50 4 Standard >	Color Selup Pick Garwan 4 DCR 4	Corr >	Extra
5 Press				Deallisht Alfrederaut
	Brightness	0-100		Backlight Adjustment.
	Contrast	0-100	T	Contrast from Digital-register.
	Eco mode	Standard	>	Standard Mode.
		Text	T	Text Mode.
		Internet	e	Internet Mode.
-0-		Game	2 20	Game Mode.
		Movie	Ø	Movie Mode.
		Sports	3ª	Sports Mode.
		Gamma1		Adjust to Gamma 1.
	Gamma	Gamma2		Adjust to Gamma 2.
		Gamma3		Adjust to Gamma 3.
		Off		Disable dynamic contrast ratio.
	DCR	On	DCR	Enable dynamic contrast ratio.

Image Setup



1 Press III (Menu) to display menu.



2 Press < or > to select

(Image Setup), and press III to enter.

K Setter	Color Setap	Picture Boost	DSD Setup	× Entra	Lair Laminance
Clack Phase Sharpness	50 50	H.Position V.Position	50		
		A106	and .		

3 Press < or > to select submenu, and press III to enter.



4 Press < or > to adjust.

Kraye Sector	Celer Bellip	Picture Boost	050 Bellep	× Extra	II Ent	
Clock Phase Sharpness	50 50 50 50	H.Position V.Position				1.
		iene.	μas	•••		

5 Press + to exit.

Clock	0-100	Adjust picture Clock to reduce Vertical-Line noise.
Phase	0-100	Adjust Picture Phase to reduce Horizontal-Line noise.
 Sharpness	0-100	Adjust picture sharpness.
 H.Position	0-100	Adjust the horizontal position of the picture.
V.Position	0-100	Adjust the vertical position of the picture.

Color Setup



1 Press IIII (Menu) to display menu.







4 Press < or > to adjust.

Color Setue		Picture B	OSD Setup Rod	Eara	Exit	Laminance	Image Setu
				-			
	_			A106 -			
				aas)			

5 Press + to exit.

		Warm		Recall Warm Color Temperature from EEPROM.
		Normal		Recall Normal Color Temperature from EEPROM.
		Cool		Recall Cool Color Temperature from EEPROM.
	Color setup.	sRGB		Recall SRGB Color Temperature from EEPROM.
			Red	Red Gain from Digital-register.
		User	Green	Green Gain Digital-register.
			Blue	Blue Gain from Digital-register.
		Full Enhance	on or off	Disable or Enable Full Enhance Mode.
		Nature Skin	on or off	Disable or Enable Nature Skin Mode.
	DCB Mode	Green Field	on or off	Disable or Enable Green Field Mode.
		Sky-blue	on or off	Disable or Enable Sky-blue Mode.
		AutoDetect	on or off	Disable or Enable AutoDetect Mode.
	DCB Demo		on or off	Disable or Enable Demo.

Picture Boost



1 Press (Menu) to display menu.



2 Press < or > to select (Picture Boost), and press III to enter.

	OSD Searp	Estra	Eni		F4 Ineque Serias	Color Setue
Toern Life			=		namilin 📕	
			A12921	d	2 th	
				(and)		

3 Press < or > to select submenu, and press \blacksquare to enter.



4 Press < or > to adjust.

Peter Bolist	OSD Swip	Estra la	Est Luminanon	T4 Image Secus	Color Setup
			50	H position	
Frame Size	- 50		50	V. position	9 9
			anne	•	

5 Press 🛨 to exit

	Bright Frame	on or off	Disable or Enable Bright Frame.
	Frame Size	14-100	Adjust Frame Size.
	Brightness	0-100	Adjust Frame Brightness.
*	Contrast	0-100	Adjust Frame Contrast.
	H. position	0-100	Adjust Frame horizontal position.
	V. position	0-100	Adjust Frame vertical position.

OSD Setup



1 Press IIII (Menu) to display menu.



3 Press < or > to select submenu, and press \boxed{III} to enter.



4 Press < or > to adjust.

Timeout 10 V. Position 0 Break Reminder 4 off	< 🗞 > OSD Serus	K Eatta E	t tunitance	T4 Image Setup	Color Setup	Picture Boost
A108			ATTAL	x X m		




	Language		Select the OSD language.
	Timeout	5-120	Adjust the OSD Timeout.
0	H. Position	0-100	Adjust the horizontal position of OSD.
	V. Position	0-100	Adjust the vertical position of OSD.
	Transparence	0-100	Adjust the transparence of OSD.
			Disable or Enable
	Break Reminder	on or off	(1 hour of work, break ?) /
			(2 hours of work, break ?)

Extra



1 Press III (Menu) to display menu.







4 Press < or > to adjust.

		 202		
			Λ	




	Input Select	Auto / D-SUB / DVI	Select input signal source. (I2279VW/I2379V)
	Input Select	Auto/D-SUB / HDMI	Select input signal source. (I2279VWHE/I2379VHE)
21	Off timer	0-24hrs	Select DC off time.
	Image Ratio	wide or 4:3	Select wide or 4:3 format for display.
	DDC-CI	yes or no	Turn ON/OFF DDC-CI Support.
	Reset	yes or no	Reset the menu to default.
	Information		Show the information of the main image and sub-image source.


Exit

< **>	F4 Inage Series	Cour Belle	Polure Soled	OSO Setup	×	
Contast Englishees Escande	Alexandra Ale	Damme) DCR	1 Carriel 1	ł		
			1982 - · · ·	d		
			6	יןיא		

1 Press III (Menu) to display menu.



3 Press AUTO to exit.



LED Indicator

Status	LED Color
Full Power Mode	White
Active-off Mode	Orange

Driver


Monitor Driver

Windows 8

- 1. Start Windows® 8
- 2. Right click and click All apps at the bottom-right of the screen.



- 3. Click on the "Control panel" icon
- 4. Set the "View by" to "Large icons" or "Small icons".



4 I I I I I

- 44

5. Click on the "**Display**" icon.

Annual and a second secon	Annumentation Annumentation	Normine Standards St	Annu Annual Annual	
---	---	--	--	--

6. Click on the "Change display settings" button.



7. Click the "Advanced Settings" button.

😭 🕼 a 🗈 Control Rend + Al Control Rend Berry + Origing +	Inverse Amountaine		a Serie Constitue
Ounge the A	opposition of your display		
	, 0 🗖	Janety	
Draine Resistaire Oraelation	3. Tenta Delasti Ran fanoi - RDE - Islati reservenantenti - undo anti-		
		data and a strings	
	he tem lage o nate tig doubt chase		
	08	- 1000 ALT	


8. Click the "Monitor" tab and then click the "Properties" button.

Month A	ar Type	ric PaP Manit	et Color Manag	_		
Monit	er Setting				Properties	
Science	on solites A	1000				
60 H	WR.					•
Certer	ing this d	eck box allow	nitor carried displ vs year to satised to is mety level to an	Asplay mod		N°N.
Color						
11,00	Color (35	• (14)				


9. Click the "Driver" tab.



10. Open the **"Update Driver Software-Generic PnP Monitor**" window by clicking on **"Update Driver...**" and then click the **"Browse my computer for driver software"** button.



11. Select "Let me pick from a list of device drivers on my computer".



12. Click the "Have Disk" button. Click on the "Browse" button and navigate to the following directory:

X:\Driver\module name (where X is the drive letter designator for the CD-ROM drive).

	In our later of a shaded of the Archiver of the sec	and discussion Marriel
Install From	r Dela Inse di far var mår, når efte son skalle som skalle som fra men soker som fra fra operand däve in sokertand soker.	or Laut
1	Copy manufacture of ear from (-c) one women and (Evers.

- 13. Select the "xxx.inf" file and click the "Open" button. Click the "OK" button.
- 14. Select your monitor model and click the "**Next**" button. The files will be copied from the CD to your hard disk drive.
- 15. Close all open windows and remove the CD.
- 16. Restart the system. The system will automatically select the maximum refresh rate and corresponding Color Matching Profiles.

Windows 7

- 1. Start Windows® 7
- 2. Click on the 'Start' button and then click on 'Control Panel'.



3. Click on the 'Display' icon.

	the name of the local division of the local	AL-	9 tono ottoni	
31	B	(Conservation)	Calman Assess	
B Institut Instant	A tray tonat	And in case of the later.	Witness.	
Q *** *****	Af home research	- Balleton	A surger and	
A recently in the local days	de betrangementen.	All Antonia lindowe	- manual	
A CARTON AND THE REAL	P Gran	W manh and the spliper-	E-mail and a feature of the second	
CONTRACTOR OF A	· Contraction Proved	A more care	d the particular	
Contractory in the local division of the loc	· ·	and Printer and Second	Presi fatore	
C Property and Property of	B both distant from	d innet.	and the second second	
Contract of the local division of the loc	ant. W fraunt	a land trager	· berieve	
B +++++	 Annotation 	1 means and her man	(#	
a marketer	G view laws laws	Contraction (M branch more	
Printer and	C manual later			

4. Click on the "Change display settings" button.

			1 m. 1
Contractor	A service of the bare A Darks		An Desch-Control Rend
Control Read Home Adjust Homes Controls action	Maler it mades to read solutil's or the conclusion to cost fractise other temporary energy any period the source	terms or your upwenty-choising one of these spoors. To	
Charge display to the part of	() hele (87)	Pasing	
Secondary lands (27)	# Bolan 2014/Auto	_mm_	
	0 larger - 158%		
		100	
Terranalization			
Demanand Protect			

5. Click the "Advanced Settings" button.

👷 🕀 📲 Entern Ford + Al Carter Ford Barry + Charge B	Lower Resolution		Carrie Contra Paral
Change the	appearance of your display		
	. 0 🖬	Lines,	
Display	1. Norda Delash Rat Newt • 100 = 100 parameterizati		
Overdeline	Department of		
	dhe tem lage o chille dhig doctri may!	Address Saffrage	
		danse April	


6. Click the **"Monitor"** tab and then click the **"Properties"** button.

Monitar Type	
Geowic PaP	Manitor
	Properties
Monitor Settings	
Screen reliesh rate:	
60 Horte	
Hide modes that th	is monitor cannot display
Hide modes that the George his check be cerved display cover of	is manitor cannot display scalares you to reflect display modes that this monitor by This may local to an winisable simplay and/or
Hide modes that the George his check bo const display const damaged headware.	scallows you to select display modes that this monitor
Hide modes that the Desring this check too	scallows you to select display modes that this monitor
Hide modes that th Decring this check to connet display obried demaged headware. Colors:	scallows you to select display modes that this monitor
Hide modes that th Decring this check to connet display, one of decringed headware. Colors:	scallows you to select display modes that this monitor

7. Click the "Driver" tab.




8. Open the "Update Driver Software-Generic PnP Monitor" window by clicking on "Update Driver... " and then click the "Browse my computer for driver software" button.



9. Select "Let me pick from a list of device drivers on my computer".



 Click the "Have Disk" button. Click on the "Browse" button and navigate to the following directory: X:\Driver\module name (where X is the drive letter designator for the CD-ROM drive).



- 11. Select the "xxx.inf" file and click the "Open" button. Click the "OK" button.
- 12. Select your monitor model and click the "**Next**" button. The files will be copied from the CD to your hard disk drive.
- 13. Close all open windows and remove the CD.
- 14. Restart the system. The system will automatically select the maximum refresh rate and corresponding Color Matching Profiles.

Windows Vista

1. Click "Start" and "Control Panel". Then, double-click on "Appearance and Personalization".



2. Click "Personalization" and then "Display Settings".




3. Click "Advanced Settings...".



4. Click "Properties" in the "Monitor" tab. If the "Properties" button is deactivated, it means the configuration for your monitor is completed. The monitor can be used as is.


If the message "Windows needs..." is displayed, as shown in the figure below, click "Continue".



5. Click "Update Driver..." in the "Driver" tab.

mane Prif Wonder Traperties	Centrals: Pull Monitor Properties
Serve [Deer] Gene	General Direr Databa
Series had Made	Servers (In P Maxim
Device spore Wittens Signalizations: Devices Spani Location an VADDA Reference SIXD (# (Remain& Device)	Driver Provider: Microsoft Driver Date: 6:21:0006 Driver Venaur: 6:3 6001 16206
Term date	Dytai Sprer microsoft windows
Pie ferra a coldra pripeto	Oper Databa Yo new databa about the driver lies. Update Driver To update the driver lies driver.
	Bit local driver. If the device table after updating the driver, ed. tools to the pervicully notabled driver.
	Deadline Daublies Per selected device,
	United To united the diver (Advanced)
OK Crow	DK Devel

6. Check the "Browse my computer for driver software" checkbox and click "Let me pick from a list of device drivers on my computer".




- Click on the 'Have disk...' button, then click on the 'Browse...' button and then select the appropriate drive F:\Driver (CD-ROM Drive).
- 8. Select your monitor model and click on the 'Next' button.
- 9. Click "Close" \rightarrow "Close" \rightarrow "OK" \rightarrow "OK" on the following screens displayed in sequence.

Windows XP


- 1. Start Windows® XP
- 2. Click on the 'Start' button and then click on 'Control Panel'.



3. Select and click on the category 'Appearance and Themes'



4. Click on the 'Display' Item.



5. Select the 'Settings' tab then click on the 'Advanced' button.

isplay Propertie	s	2 🖸
Themes Desktop	Screen Saver Appearance Settin	nge
Display: Plug and Play Mor	itor on 3D Prophet III	
Less 1024 by 7	More Highest (32 bit)	
	roubleshoot	Adganced
	OK Cance	Aoply .

- 6. Select 'Monitor' tab
 - If the 'Properties' button is inactive, it means your monitor is properly configured. Please stop installation.
 - If the 'Properties' button is active, click on 'Properties' button.

Please follow the steps below.

	r and 3D Prophet III Properti	es 🔽 🕻
GeForce3 Seneral Adapter		lor Correction r Management
Monitor type Plug and Play	Monitor	entins
Monitor settings		
Screen refresh rate:		
60 Hertz		~
	x allows you to select display modes to correctly. This may lead to an unusal ware.	


7. Click on the 'Driver' tab and then click on 'Update Driver...' button.

Plug and Play Monitor Properties	2 🔀	
General Driver		Plug and Play Monitor Properties 🛛 😨 🔀
Plug and Play Monitor		General Driver
Device type: Monitors		Plug and Play Monitor
Manufacturer: (Standard monitor types) Location: on 3D Prophet III		Driver Provider: Microsoft Driver Date: 6/6/2001
C Device status		Driver Version: 5.1.2001.0
This device is working properly.	_	Digital Signer: Microsoft Windows XP Publisher
If you are having problems with this device, click Troubleshoot to start the troubleshooter.		Driver Details To view details about the driver files.
	~	Ugdate Driver To update the driver for this device.
Iroubleshoot		Boll Back Driver If the device fails after updating the driver, roll back to the previously installed driver.
Device usage: Use this device (enable)	-	Uninstall To uninstall the driver (Advanced).
С	Cancel	OK Cancel


8. Select the 'Install from a list or specific location [advanced]' radio button and then click on the 'Next' button.



9. Select the 'Don't Search. I will choose the driver to install' radio button. Then click on the 'Next' button.



10. Click on the 'Have disk...' button, then click on the 'Browse...' button and then select the appropriate drive F: (CD-ROM Drive).



- 11. Click on the 'Open' button, then click the 'OK' button.
- 12. Select your monitor model and click on the 'Next' button.
 - If you can see the 'has not passed Windows® Logo testing to verify its compatibility with Windows® XP' message, please click on the 'Continue Anyway' button.
- 13. Click on the 'Finish' button then the 'Close' button.
- 14. Click on the 'OK' button and then the 'OK' button again to close the Display Properties dialog box.

Windows 2000

- 1. Start Windows® 2000
- 2. Click on the 'Start' button, point to 'Settings', and then click on 'Control Panel'.
- 3. Double click on the 'Display' Icon.
- 4. Select the 'Settings' tab then click on 'Advanced...'.
- 5. Select 'Monitor'
 - If the 'Properties' button is inactive, it means your monitor is properly configured. Please stop installation.
 - If the 'Properties' button is active. Click on 'Properties' button. Please follow the steps given below.
- 6. Click on 'Driver' and then click on 'Update Driver...' then click on the 'Next' button.
- 7. Select 'Display a list of the known drivers for this device so that I can choose a specific driver', then click on 'Next' and then click on 'Have disk...'.
- 8. Click on the 'Browse...' button then select the appropriate drive F: (CD-ROM Drive).
- 9. Click on the 'Open' button, then click on the 'OK' button.
- 10. Select your monitor model and click on the 'Next' button.
- 11. Click on the 'Finish' button then the 'Close' button.

If you can see the 'Digital Signature Not Found' window, click on the 'Yes' button.

Windows ME

- 1. Start Windows® Me
- 2. Click on the 'Start' button, point to 'Settings', and then click on 'Control Panel'.
- 3. Double click on the 'Display' Icon.
- 4. Select the 'Settings' tab then click on 'Advanced...'.
- 5. Select the 'Monitor' button, then click on 'Change...' button.
- 6. Select 'Specify the location of the driver(Advanced)' and click on the 'Next' button.
- 7. Select 'Display a list of all the drivers in a specific location, so you can choose the driver you want', then click on 'Next' and then click on 'Have Disk...'.
- 8. Click on the 'Browse...' button, select the appropriate drive F: (CD-ROM Drive) then click on the 'OK' button.
- 9. Click on the 'OK' button, select your monitor model and click on the 'Next' button.
- 10. Click on 'Finish' button then the 'Close' button.

i-Menu



Welcome to "i-Menu" software by AOC. i-Menu makes it easy to adjust your monitor display setting by using on screen menus instead of the OSD button on the monitor. To complete installation, please follow the installation guide. The software Supported operating systems: Windows 7, Windows Vista, Windows XP.



e-Saver




Welcome to use AOC e-Saver monitor power management software! The AOC e-Saver features Smart Shutdown functions for your monitors, allows your monitor to timely shutdown when PC unit is at any status (On, Off, Sleep or Screen Saver); the actual shutdown time depends on your preferences (see example below).


Please click on "driver/e-Saver/setup.exe" to start installing the e-Saver software, follow the install wizard to complete software installation. The software Supported operating systems: Windows 7, Windows Vista, Windows XP.

Under each of the four PC status, you may choose from the pull-down menu the desired time (in minutes)you're your monitor to automatically shutdown. The example above illustrated:

- 1. The monitor will never shutdown when the PC is powered on.
- 2. The monitor will automatically shutdown 5 minutes after the PC is powered off.
- 3. The monitor will automatically shutdown 10 minutes after the PC is in sleep/stand-by mode.
- 4. The monitor will automatically shutdown 20 minutes after the screen saver appears.








Screen+



Welcome to "Screen+" software by AOC. Screen+ software is a desktop screen splitting tool; it splits the desktop into different panels, and each panel displays a different window. You only need to drag the window to a corresponding pane, when you want to access it. It supports multiple monitor display to make your task easier. Please follow the installation software to install it. The software Supported operating systems: Windows 8, Windows 7, Windows Vista, Windows XP.



Troubleshoot

Problem & Question	Possible Solutions		
Power LED Is Not ON	Make sure the power button is ON and the Power Cord is properly connected to a grounded power outlet and to the monitor.		
No images on the screen	 Is the power cord connected properly? Check the power cord connection and power supply. Is the cable connected correctly? (Connected using the D-sub cable) Check the DB-15 cable connection. (Connected using the DVI cable) Check the DVI cable connection. * DVI input is not available on every model. (Connected using the HDMI cable) Check the HDMI cable connection. * DVI input is not available on every model. (Connected using the HDMI cable) Check the HDMI cable connection. * HDMI input is not available on every model. If the power is on, reboot the computer to see the initial screen (the login screen), which can be seen. If the initial screen (the login screen) appears, boot the computer in the applicable mode (the safe mode for Windows ME/XP/2000) and then change the frequency of the video card. (Refer to the Setting the Optimal Resolution) If the initial screen (the login screen) does not appear, contact the Service Center or your dealer. Can you see "Input Not Supported" on the screen? You can see this message when the signal from the video card exceeds the maximum resolution and frequency that the monitor can handle properly. Adjust the maximum resolution and frequency that the monitor can handle properly. Make sure the AOC Monitor Drivers are installed. 		
Picture Is Fuzzy & Has Ghosting Shadowing Problem	Adjust the Contrast and Brightness Controls. Press for auto adjust. Make sure you are not using an extension cable or switch box. We recommend plugging the monitor directly to the video card output connector on the back.		

Picture Bounces, Flickers Or Wave Pattern Appears In The Picture	Move electrical devices that may cause electrical interference as far away from the monitor as possible. Use the maximum refresh rate your monitor is capable of at the resolution you are using.
Monitor Is Stuck In Active Off-Mode''	The Computer Power Switch should be in the ON position. The Computer Video Card should be snugly fitted in its slot. Make sure the monitor's video cable is properly connected to the computer. Inspect the monitor's video cable and make sure no pin is bent. Make sure your computer is operational by hitting the CAPS LOCK key on the keyboard while observing the CAPS LOCK LED. The LED should either turn ON or OFF after hitting the CAPS LOCK key.
Missing one of the primary colors (RED, GREEN, or BLUE)	Inspect the monitor's video cable and make sure that no pin is damaged. Make sure the monitor's video cable is properly connected to the computer.
Screen image is not centered or sized properly	Adjust H-Position and V-Position or press hot-key (AUTO).
Picture has color defects (white does not look white)	Adjust RGB color or select desired color temperature.
Horizontal or vertical disturbances on the screen	Use Windows 95/98/2000/ME/XP shut-down mode Adjust CLOCK and Phase.Press to auto-adjust.

Specification

General Specification (12279VW/12279VWHE)

	Model name		I2279VW/I2279VWHE		
	Driving system		TFT Color LCD		
	Viewable Image Size		54.61cm diagonal		
	Pixel pitch		0.08265*RGB(H)mm x 0.24795(V) mm		
Panel	Video		R, G, B Analog Interface &DVI Interface (I2279VW)		
			R, G, B Analog Interface &HDMI Interface (I2279VWHE)		
	Separate Sync.		H/V TTL		
	Display Color		16.7M Colors		
	Pixel Clock		148.5MHz		
	Horizontal scan	range	30kHz - 83kHz		
	Horizontal scan	Size(Maximum)	477 mm		
	Vertical scan rar	nge	50Hz - 76 Hz		
	Vertical scan Siz	e(Maximum)	268 mm		
	Optimal preset r	esolution	1920x1080@60Hz		
Others	Plug & Play		VESA DDC2B/CI		
	Input Connector		VGA /DVI (I2279VW); VGA /HDMI (I2279VWHE)		
	Input Video Signal		Analog: 0.7Vp-p(standard), 75 OHM, TMDS		
	Power Source		19VDC, 1.31A		
	Power Consumption		Typical (brightness = 90, contrast= 50)	19W (I2279VW) 22W (I2279VWHE)	
			(brightness = 100, contrast = 100)	22W (I2279VW) 24W (I2279VWHE)	
			Power Saving	≤ 0.5 W	
	Off timer		0-24 hrs		
Physical	Connector Type		VGA /DVI (I2279VW); VGA /HDMI (I2279VWHE)		
Characteristics	Signal Cable Ty	pe	Detachable		
	Temperature:	Operating	0° C ~ 40°C		
	n emperature.	Non-Operating	-20°C ~ 60°C		
	Operating		20% ~ 90% (non-condensing)		
Environmental	Humidity:	Non-Operating	15% ~ 90% (non-condensing)		
		Operating	0~ 5000m (0~ 16404 ft)		
	Altitude:	Non-Operating	0~ 12192m (0~ 40000 ft)		
L					

Preset Display Modes(12279VW/12279VWHE)

STANDARD	RESOLUTION	HORIZONTAL FREQUENCY(kHZ)	VERTICAL FREQUENCY(Hz)
VGA	640×480@60Hz	31.469	59.940
VGA	640×480@67Hz	35.000	66.667
VGA	640×480@72Hz	37.861	72.809
VGA	640×480@75Hz	37.500	75.000
Dos-mode	720×400@70Hz	31.469	70.087
SVGA	800×600@56Hz	35.156	56.250
SVGA	800×600@60Hz	37.879	60.317
SVGA	800×600@72Hz	48.077	72.188
SVGA	800×600@75Hz	46.875	75.000
SVGA	832×624@75Hz	49.725	74.551
XGA	1024×768@60Hz	48.363	60.004
XGA	1024×768@70Hz	56.476	70.069
XGA	1024×768@75Hz	60.023	75.029
***	1280×960@60Hz	60.000	60.000
SXGA	1280×1024@60Hz	63.981	60.020
SXGA	1280×1024@75Hz	79.976	75.025
WXGA+	1440×900@60Hz	55.935	59.887
WSXGA	1680×1050@60Hz	65.290	59.954
FHD	1920×1080@60Hz	67.500	60.000

HDMI timing (I2279VWHE)

Format	Resolution	Vertical frequency
480p	640x480	60Hz
480p	720x480	60Hz
576p	720x576	50Hz
720p	1280x720	50Hz,60Hz
1080p	1920x1080	50Hz,60Hz

	Model name		I2379V/I2379VHE		
	Driving system		TFT Color LCD		
	Viewable Image	Size	58.42cm diagonal		
Panel	Pixel pitch		0.0884*RGB(H) mm x 0.2652(V) mm		
	Video		R, G, B Analog Interface &DVI Interface (I2	,	
			R, G, B Analog Interface &HDMI Interface (I2379VHE)		
	Separate Sync.		H/V TTL		
	Display Color		16.7M Colors		
	Pixel Clock		148.5MHz		
	Horizontal scan	range	30kHz - 83kHz		
	Horizontal scan	Size(Maximum)	509 mm		
	Vertical scan ra	nge	50Hz - 76 Hz		
	Vertical scan Si	ze(Maximum)	286 mm		
	Optimal preset i	resolution	1920x1080@60Hz		
Others	Plug & Play		VESA DDC2B/CI		
	Input Connector		VGA /DVI (I2379V); VGA /HDMI (I2379VHE)		
	Input Video Signal		Analog: 0.7Vp-p(standard), 75 OHM, TMDS		
	Power Source		19VDC, 1.31A		
	Power Consumption		Typical (brightness = 90, contrast = 50)	19W(I2379V) 23W(I2379VHE)	
			(brightness = 100, contr ast = 100)	22W(I2379V) 25W(I2379VHE)	
			Power Saving	≤ 0.5 W	
	Off timer		0-24 hrs	1	
Physical	Connector Type	ļ	VGA /DVI (I2379V); VGA /HDMI (I2379VHE)		
Characteristics	Signal Cable Ty	ре	Detachable		
	Tamparatura	Operating	0° C ~ 40°C		
	Temperature:	Non-Operating	-20°C ~ 60°C		
		Operating	20% ~ 90% (non-condensing)		
Environmental	Humidity:	Non-Operating	15% ~ 90% (non-condensing)		
	Altitude: Operating Non-Operating		0~ 5000m (0~ 16404 ft)		
			0~ 12192m (0~ 40000 ft)		

General Specification(12379V/12379VHE)


Preset Display Modes(12379V/12379VHE)

STANDARD	RESOLUTION	HORIZONTAL FREQUENCY(kHZ)	VERTICAL FREQUENCY(Hz)
VGA	640×480@60Hz	31.469	59.940
VGA	640×480@67Hz	35.000	66.667
VGA	640×480@72Hz	37.861	72.809
VGA	640×480@75Hz	37.500	75.000
Dos-mode	720×400@70Hz	31.469	70.087
SVGA	800×600@56Hz	35.156	56.250
SVGA	800×600@60Hz	37.879	60.317
SVGA	800×600@72Hz	48.077	72.188
SVGA	800×600@75Hz	46.875	75.000
SVGA	832×624@75Hz	49.725	74.551
XGA	1024×768@60Hz	48.363	60.004
XGA	1024×768@70Hz	56.476	70.069
XGA	1024×768@75Hz	60.023	75.029
***	1280×960@60Hz	60.000	60.000
SXGA	1280×1024@60Hz	63.981	60.020
SXGA	1280×1024@75Hz	79.976	75.025
WXGA+	1440×900@60Hz	55.935	59.887
WSXGA	1680×1050@60Hz	65.290	59.954
FHD	1920×1080@60Hz	67.500	60.000

HDMI timing (I2379VHE)

Format	Resolution	Vertical frequency
480p	640x480	60Hz
480p	720x480	60Hz
576p	720x576	50Hz
720p	1280x720	50Hz,60Hz
1080p	1920x1080	50Hz,60Hz

Pin Assignments




15-Pin Color Display Signal Cable

Pin Number	15-Pin Side of the Signal Cable	Pin Number	15-Pin Side of the Signal Cable
1	Video-Red	9	+5V
2	Video-Green	10	Ground
3	Video-Blue	11	N.C.
4	N.C.	12	DDC-Serial data
5	Detect Cable	13	H-sync
6	GND-R	14	V-sync
7	GND-G	15	DDC-Serial clock
8	GND-B		



24-Pin Color Display Signal Cable

Pin Number	24-Pin Color Display Signal Cable	Pin Number	24-Pin Color Display Signal Cable
1	TMDS data 2-	13	TMDS data 3+/N.C.
2	TMDS data 2+	14	+5V Power
3	TMDS data 2/4 Shield	15	Ground (for+5V)
4	TMDS data 4 – / N.C.	16	Hot Plug Detect
5	TMDS data 4 +/ N.C.	17	TMDS data 0-
6	DDC Clock	18	TMDS data 0+
7	DDC Data	19	TMDS data 0/5 Shield
8	N.C.	20	TMDS data 5—/N.C.
9	TMDS data 1-	21	TMDS data 5+/N.C.
10	TMDS data 1+	22	TMDS Clock Shield
11	TMDS data 1/3 Shield	23	TMDS Clock +
12	TMDS data 3-/N.C.	24	TMDS Clock —



19 Pin Color Display Signal Cable

Pin No.	Signal Name	Pin No.	Signal Name	Pin No.	Signal Name
1	TMDS Data 2+	9	TMDS Data 0-	17	DDC/CEC Ground
2	TMDS Data 2 Shield	10	TMDS Clock +	18	+5V Power
3	TMDS Data 2-	11	TMDS Clock Shield	19	Hot Plug Detect
4	TMDS Data 1+	12	TMDS Clock-		
5	TMDS Data 1Shield	13	CEC		
6	TMDS Data 1-	14	Reserved (N.C. on device		
7	TMDS Data 0+	15	SCL		
8	TMDS Data 0 Shield	16	SDA		

Plug and Play

Plug & Play DDC2B Feature

This monitor is equipped with VESA DDC2B capabilities according to the VESA DDC STANDARD. It allows the monitor to inform the host system of its identity and, depending on the level of DDC used, communicate additional information about its display capabilities.

The DDC2B is a bi-directional data channel based on the I2C protocol. The host can request EDID information over the DDC2B channel.

Regulation

FCC Notice

FCC Class B Radio Frequency Interference Statement WARNING: (FOR FCC CERTIFIED MODELS)

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

NOTICE:

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Shielded interface cables and AC power cord, if any, must be used in order to comply with the emission limits. The manufacturer is not responsible for any radio or TV interference caused by unauthorized modification to this equipment. It is the responsibilities of the user to correct such interference. It is the responsibility of the user to correct such interference.

WEEE Declaration

Disposal of Waste Equipment by Users in Private Household in the European Union.



This symbol on the product or on its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

WEEE Declaration Zcf =bX]U



This symbol on the product or on its packaging indicates that this product must not be disposed of with your other household waste. Instead it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment.

For more information about where you can drop off your waste equipment for recycling in India please visit the below web link.

www.aocindia.com/ewaste.php.

RoHS Declaration for India

This product complies with all implemented RoHS type regulations worldwide, including but not limited to, EU, Korea, Japan, US States (e.g. California), Ukraine, Serbia, Turkey, Vietnam and India.

We continue to monitor, influence and develop our processes to comply with upcoming proposed RoHS type regulations, including but not limited to, Brazil, Argentina, Canada.

Restriction on Hazardous Substances statement (India)

This product complies with the "India E-waste Rule 2011" and prohibits use of lead, mercury, hexavalent chromium, polybrominated biphenyls or polybrominated diphenyl ethers in concentrations exceeding 0.1 weight % and 0.01 weight % for cadmium, except for the exemptions set in Schedule 2 of the Rule.

EPA Energy Star



ENERGY STAR® is a U.S. registered mark. As an ENERGY STAR® Partner, AOC International (Europe) BV and Envision Peripherals, Inc. have determined that this product meets the ENERGY STAR® guidelines for energy efficiency.

(FOR EPA CERTIFIED MODELS)

Service

Warranty Statement for Europe

LIMITED THREE-YEAR WARRANTY*

For AOC LCD Monitors sold within Europe, AOC International (Europe) B.V. warrants this product to be free from defects in material and workmanship for a period of Three (3) years after the original date of consumer purchase. During this period, AOC International (Europe) B.V. will, at its option, either repair the defective product with new or rebuilt parts, or replace it with a new or rebuilt product at no charge except as *stated below. In the absent of the proof of purchase, the warranty will start 3 months after the date of manufacturing indicated on the product.

If the product appears to be defective, please contact your local dealer or refer to the service and support section on <u>www.aoc-europe.com</u> for the warranty instructions in your country. The freight cost for the warranty is pre-paid by AOC for the delivery and return. Please ensure you provide a dated proof of purchase along with the product and deliver to the AOC Certified or Authorized Service Center under the following condition:

- Make sure the LCD Monitor is packed in a proper carton box (AOC prefers the original carton box to protects your monitor well enough during transport).
- Put the RMA number on the address label
- Put the RMA number on the shipping carton

AOC International (Europe) B.V. will pay the return shipping charges within one of the countries specified within this warranty statement. AOC International (Europe) B.V. is not responsible for any costs associated with the transportation of product across international borders. This includes the international border within the European Union. If the LCD Monitor is not available for collection when the currier attends, you will be charged a collection fee.

* This limited warranty does not cover any losses or damages that occur as a result of:

- Damages during transport due to improper packaging
- Improper installation or maintenance other then in accordance with AOC's user manual
- Misuse
- Neglect
- Any cause other than ordinary commercial or industrial application
- Adjustment by non-authorized source
- Repair, modification, or installation of options or parts by anyone other than an AOC Certified or Authorized Service Center
- Improper environments like humidity, water damage and dusts
- Damaged by violence, earthquake and terrorist attacks
- Excessive or inadequate heating or air conditioning or electrical powers failures, surges, or other irregularities

This limited warranty does not cover any of the product firmware or hardware that you or any third party have modified or altered; you bear the sole responsibility and liability for any such modifications or alteration.

All AOC LCD Monitors are produced according to the ISO 9241-307 Class 1 pixel policy standards.

If your warranty has expired, you still have access to all available service options, but you will be responsible for the cost of service, including parts, labor, shipping (if any) and applicable taxes. AOC Certified or Authorized Service Center will provide you with an estimate of service costs before receiving your authorization to perform service.

ALL EXPRESS AND IMPLIED WARRANTIES FOR THIS PRODUCT (INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE) ARE LIMITED IN DURATION TO A PERIOD OF THREE (3) YEARS FOR PARTS AND LABOR FROM THE ORIGINAL DATE OF CONSUMER PURCHASE. NO WARRANTIES (EITHER EXPRESSED OR IMPLIED) APPLY AFTER THIS PERIOD. AOC INTERNATIONAL (EUROPE) B.V. OBLIGATIONS AND YOUR REMEDIES HEREUNDER ARE SOLELY AND EXCULSIVELY AS STATED HERE. AOC INTERNATIONAL (EUROPE) B.V. LIABILITY, WHETHER BASED ON CONTRACT, TORT, WARRANTY, STRICT LIABILITY, OR OTHER THEORY, SHALL NOT EXCEED THE PRICE OF THE INDIVIDUAL UNIT WHOSE DEFECT OR DAMAGE IS THE BASIS OF THE CLAIM. IN NO EVENT SHALL AOC INTERNATIONAL (EUROPE) B.V. BE LIABLE FOR ANY LOSS OF PROFITS, LOSS OF USE OR FACILITIES OR EQUIPMENT, OR OTHER INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGE. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. ALTHOUGH THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, YOU MAY HAVE OTHER RIGHTS, WHICH MAY VARY FROM COUNTRY TO COUNTRY. THIS LIMITED WARRANTY IS ONLY VALID FOR PRODUCTS PURCHASED IN THE MEMBER COUNTRIES OF THE EUROPEAN UNION.

Information in this document is subject to change without notice. For more information, please visit: <u>http://www.aoc-europe.com</u>

Warranty Statement for Middle East and Africa (MEA)

And

The Commonwealth of Independent States (CIS)

LIMITED ONE to THREE YEARS WARRANTY*

For AOC LCD Monitors sold within the Middle East and Africa (MEA) and the Commonwealth of Independent States (CIS), AOC International (Europe) B.V. warrants this product to be free from defects in material and workmanship for a period of One (1) to Three (3) years from the manufacture date depending on sale country. During this period, AOC International (Europe) B.V. offers a Carry-In (return to Service Center) Warranty Support at an AOC's Authorized Service Center or Dealer and at its option, either repair the defective product with new or rebuilt parts, or replace it with a new or rebuilt product at no charge except as *stated below. As a Standard Policy, the warranty will be calculated from the manufacture date identified from the product ID serial number, but the total warranty will be Fifteen (15) months to Thirty Nine (39) months from MFD (manufacture date) depending on sale country. Warranty will be considered for exceptional cases that are out of warranty as per the product ID serial number and for such exceptional cases; Original Invoice/Proof Of Purchase Receipt is mandatory.

If the product appears to be defective, please contact your AOC authorized dealer or refer to the service and support section on AOC's website for the warranty instructions in your country:

- Egypt: <u>http://aocmonitorap.com/egypt_eng</u>
- CIS Central Asia: <u>http://aocmonitorap.com/ciscentral</u>
- Middle East: <u>http://aocmonitorap.com/middleeast</u>
- South Africa: <u>http://aocmonitorap.com/southafrica</u>
- Saudi Arabia: <u>http://aocmonitorap.com/saudiarabia</u>

Please ensure you provide a dated proof of purchase along with the product and deliver to the AOC Authorized Service Center or Dealer under the following condition:

- Make sure the LCD Monitor is packed in a proper carton box (AOC prefers the original carton box to protects your monitor well enough during transport).
- Put the RMA number on the address label
- Put the RMA number on the shipping carton

* This limited warranty does not cover any losses or damages that occur as a result of:

- Damages during transport due to improper packaging
- Improper installation or maintenance other then in accordance with AOC's user manual
- Misuse
- Neglect
- Any cause other than ordinary commercial or industrial application
- Adjustment by non-authorized source

- Repair, modification, or installation of options or parts by anyone other than an AOC Certified or Authorized Service Center
- Improper environments like humidity, water damage and dusts
- Damaged by violence, earthquakes and terrorist attacks
- Excessive or inadequate heating or air conditioning or electrical powers failures, surges, or other irregularities

This limited warranty does not cover any of the product firmware or hardware that you or any third party have modified or altered; you bear the sole responsibility and liability for any such modifications or alteration.

All AOC LCD Monitors are produced according to the ISO 9241-307 Class 1 pixel policy standards.

If your warranty has expired, you still have access to all available service options, but you will be responsible for the cost of service, including parts, labor, shipping (if any) and applicable taxes. AOC Certified, Authorized Service Center or dealer will provide you with an estimate of service costs before receiving your authorization to perform service.

ALL EXPRESS AND IMPLIED WARRANTIES FOR THIS PRODUCT (INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE) ARE LIMITED IN DURATION TO A PERIOD OF ONE (1) to THREE (3) YEARS FOR PARTS AND LABOR FROM THE ORIGINAL DATE OF CONSUMER PURCHASE. NO WARRANTIES (EITHER EXPRESSED OR IMPLIED) APPLY AFTER THIS PERIOD. AOC INTERNATIONAL (EUROPE) B.V. OBLIGATIONS AND YOUR REMEDIES HEREUNDER ARE SOLELY AND EXCULSIVELY AS STATED HERE. AOC INTERNATIONAL (EUROPE) B.V. LIABILITY, WHETHER BASED ON CONTRACT, TORT, WARRANTY, STRICT LIABILITY, OR OTHER THEORY, SHALL NOT EXCEED THE PRICE OF THE INDIVIDUAL UNIT WHOSE DEFECT OR DAMAGE IS THE BASIS OF THE CLAIM. IN NO EVENT SHALL AOC INTERNATIONAL (EUROPE) B.V. BE LIABLE FOR ANY LOSS OF PROFITS, LOSS OF USE OR FACILITIES OR EQUIPMENT, OR OTHER INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGE. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. ALTHOUGH THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, YOU MAY HAVE OTHER RIGHTS, WHICH MAY VARY FROM COUNTRY TO COUNTRY. THIS LIMITED WARRANTY IS ONLY VALID FOR PRODUCTS PURCHASED IN THE MEMBER COUNTRIES OF THE EUROPEAN UNION.

Information in this document is subject to change without notice. For more information, please visit: <u>http://www.aocmonitorap.com</u>



AOC International (Europe) B.V.

Prins Bernhardplein 200 / 6th floor, Amsterdam, The Netherlands Tel: +31 (0)20 504 6962 • Fax: +31 (0)20 5046933


AOC Pixel Policy ISO 9241-307 Class 1

July 25th, 2013

AOC strives to deliver the highest quality products. We use some of the industry's most advanced manufacturing processes and practice stringent quality control. However, pixel or sub pixel defects on the TFT monitor panels used in flat panel monitors are sometimes unavoidable. No manufacturer can guarantee that all panels will be free from pixel defects, but AOC guarantees that any monitor with an unacceptable number of defects will be repaired or replaced under warranty. This Pixel Policy explains the different types of pixel defects and defines acceptable defect levels for each type. In order to qualify for repair or replacement under warranty, the number of pixel defects on a TFT monitor panel must exceed these acceptable levels.

Pixels and Sub Pixel Definition

A pixel, or picture element, is composed of three sub pixels in the primary colors of red, green and blue. When all sub pixels of pixel are lit, the three colored sub pixel together appear as a single white pixel. When all are dark, the three colored sub pixels together appear as a single black pixel.



Types of Pixel Defects

- Bright Dot Defects: the monitor displays a dark pattern, sub pixels or pixels are always lit or "on"
- Black Dot Defects: the monitor displays a light pattern, sub pixels or pixels are always dark or "off".

ISO 9241-307	Defect Type 1	Defect Type 2	Defect Type 3		Defect Type 4 Black
Pixel Defect Class	Bright Pixel	Black Pixel	Bright Sub pixel		Sub pixel
			2	+	1
Class 1	1	1	1	+	3
			0	+	5

AOC International (Europe) B.V.

Warranty Statement for North & South America (excluding Brazil)

WARRANTY STATEMENT for AOC Color Monitors Including those Sold within North America as Specified

Envision Peripherals, Inc. warrants this product to be free from defects in material and workmanship for a period of three (3) years for parts & labor and one (1) year for CRT Tube or LCD Panel after the original date of consumer purchase. During this period, EPI (EPI is the abbreviation of Envision Peripherals, Inc.) will, at its option, either repair the defective product with new or rebuilt parts, or replace it with a new or rebuilt product at no charge except as *stated below. The parts or product that are replaced become the property of EPI.

In the USA to obtain service under this limited warranty, call EPI for the name of the Authorized Service Center closest to your area. Deliver the product freight pre-paid, along with the dated proof of purchase, to the EPI Authorized Service Center. If you cannot deliver the product in person:

- Pack it in its original shipping container (or equivalent)
- Put the RMA number on the address label
- Put the RMA number on the shipping carton
- Insure it (or assume the risk of loss/damage during shipment)
- Pay all shipping charges

EPI is not responsible for damage to inbound product that was not properly packaged.

EPI will pay the return shipment charges within one of the countries specified within this warranty statement. EPI is not responsible for any costs associated with the transportation of product across international borders. This includes the international borders of the countries within this warranty statement.

In the United States and Canada contact your Dealer or EPI Customer Service, RMA Department at the toll free number (888) 662-9888. Or you can request an RMA Number online at www.aoc.com/na-warranty.

* This limited warranty does not cover any losses or damages that occur as a result of:

- Shipping or improper installation or maintenance
- Misuse
- Neglect
- Any cause other than ordinary commercial or industrial application
- Adjustment by non-authorized source
- Repair, modification, or installation of options or parts by anyone other than an EPI Authorized Service Center
- Improper environment
- Excessive or inadequate heating or air conditioning or electrical power failures, surges, or other irregularities

This three-year limited warranty does not cover any of the product's firmware or hardware that you or any third party have modified or altered; you bear the sole responsibility and liability for any such modification or alteration.

ALL EXPRESS AND IMPLIED WARRANTIES FOR THIS PRODUCT (INCLUDING THE WARRANTIES OF

MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE) ARE LIMITED IN DURATION TO A PERIOD OF THREE (3) YEARS FOR PARTS AND LABOR AND ONE (1) YEAR FOR CRT TUBE OR LCD PANEL FROM THE ORIGINAL DATE OF CONSUMER PURCHASE. NO WARRANTIES (EITHER EXPRESSED OR IMPLIED) APPLY AFTER THIS PERIOD. IN THE UNITED STATES OF AMERICA, SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU.

EPI OBLIGATIONS AND YOUR REMEDIES HEREUNDER ARE SOLELY AND EXCLUSIVELY AS STATED HERE. EPI' LIABILITY, WHETHER BASED ON CONTRACT, TORT. WARRANTY, STRICT LIABILITY, OR OTHER THEORY, SHALL NOT EXCEED THE PRICE OF THE INDIVIDUAL UNIT WHOSE DEFECT OR DAMAGE IS THE BASIS OF THE CLAIM. IN NO EVENT SHALL ENVISION PERIPHERALS, INC. BE LIABLE FOR ANY LOSS OF PROFITS, LOSS OF USE OR FACILITIES OR EQUIPMENT OR OTHER INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGE. IN THE UNITED STATES OF AMERICA, SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES. SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. ALTHOUGH THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY HAVE OTHER RIGHTS WHICH MAY VARY FROM STATE TO STATE.

In the United States of America, this limited warranty is only valid for Products purchased in the Continental United States, Alaska, and Hawaii.

Outside the United States of America, this limited warranty is only valid for Products purchased in Canada.

Information in this document is subject to change without notice. For more details, please visit:

USA: http://us.aoc.com/support/warranty ARGENTINA: http://ar.aoc.com/support/warranty BOLIVIA: http://bo.aoc.com/support/warranty CHILE: http://cl.aoc.com/support/warranty COLOMBIA: http://co.aoc.com/warranty COSTA RICA: http://cr.aoc.com/support/warranty DOMINICAN REPUBLIC: http://do.aoc.com/support/warranty ECUADOR: http://ec.aoc.com/support/warranty EL SALVADOR: http://sv.aoc.com/support/warranty_ GUATEMALA: http://gt.aoc.com/support/warranty_ HONDURAS: http://hn.aoc.com/support/warranty____ NICARAGUA: http://ni.aoc.com/support/warranty_____ PANAMA: http://pa.aoc.com/support/warranty PARAGUAY: http://py.aoc.com/support/warranty PERU: http://pe.aoc.com/support/warranty URUGUAY: http://pe.aoc.com/warranty VENEZUELA: http://ve.aoc.com/support/warranty IF COUNTRY NOT LISTED: http://latin.aoc.com/warranty



Only for AOC branded monitors sold within the continental United States.

All AOC branded monitors are now covered by the EASE Program. If your monitor malfunctions at any time during the first three months, AOC will provide a replacement monitor within 72 hours after you are approved for our program. If your monitor qualifies for the EASE program, AOC will pay for freight both ways.

Step 1: Phone our TECH Department at 888.662.9888
Step 2: Fill out and return EASE registration forms by mail or fax.
Step 3: We will issue a Return Authorization Number upon verification into the program.
Step 4: A monitor will be advance shipped to your location.
Step 5: We will issue a UPS Call Tag to pick up the defective unit.
Step 6: Please review the following chart to see your EASE program qualifications.

WARRANTY PERIOD	COVERAGE AT NO CHARGE	CUSTOMER CHARGES
Within the first three months of purchase: Covered by EASE	 New AOC monitor Call tag dispatched and return freight charges via UPS 	- None*
Between 4 months – 1 Year	- All Parts & Labor Including CRT Tube & LCD Panel	- UPS Return Freight to AOC
Between 1 Year - 3 Years: Covered by standard limited warranty	- Parts & Labor (excluding CRT Tube & LCD Panel)	- UPS Return Freight to AOC

*AOC will need to obtain a credit card number if you would like to get a new AOC monitor advanced shipped to your location, prior to the defective unit arriving at AOC's service center. If you do not wish to supply a credit card, AOC will only ship the new monitor, once the defective unit arrives at the AOC service center.

