

OWNER'S MANUAL

LED LCD MONITOR

(LED Monitor*)

* LG LED Monitor applies LCD screen with LED backlights.

Please read this manual carefully before operating your set and retain it for future reference.

27BN65Q

TABLE OF CONTENTS

LICENSE	2
ASSEMBLING AND PREPARING	3
USING THE MONITOR	9
USER SETTINGS	11
TROUBLESHOOTING	22
PRODUCT SPECIFICATION	24

LICENSE

Each model has different licenses. Visit www.lg.com for more information on the license.



The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.



The SuperSpeed USB Trident logo is a registered trademark of USB Implementers Forum, Inc.

ASSEMBLING AND PREPARING

! CAUTION

- · Always use genuine LG components to ensure safety and product performance.
- The product warranty will not cover damage or injury caused by the use of unauthorized components.
- It is recommended that use the supplied components.
- If you use generic cables not certified by LG, the screen may not display or there may be image noises.
- Illustrations in this document represent typical procedures, so they may look different from the actual product.
- Do not apply foreign substances (oils, lubricants, etc.) to the screw parts when assembling the product. (Doing so may damage the product.)
- Applying excessive force when tightening screws may cause damage to the monitor. Damage caused in this
 way will not be covered by the product warranty.
- Do not carry the monitor upside down by just holding the base. This may cause the monitor to fall off the stand and could result in personal injury.
- When lifting or moving the monitor, do not touch the monitor screen. The force applied to the monitor screen
 may cause damage to it.

NOTE

- The components may look different from those illustrated here.
- Without prior notice, all product information and specifications contained in this manual are subject to change to improve the performance of the product.
- To purchase optional accessories, visit an electronics store or an online shopping site, or contact the retailer from which you purchased the product.
- The power cord provided may differ depending upon the region.

Supported Drivers and Software

You can download and install the latest version from the LGE website (www.lq.com).

Drivers and Software	Installation Priority
Monitor Driver	Recommended
OnScreen Control	Recommended
Dual Controller	Optional

Product and Button Description



How to Use the Joystick Button

You can easily control the functions of the monitor by pressing the joystick button or moving it left/right/up/down with your finger.

Basic Functions

	&	Power on	Press the joystick button once with your finger to turn on the monitor.
		Power off	Press and hold the joystick button once more than 3 seconds with your finger to turn off the monitor.
	⋖/ ►	Volume control	You can control the volume by moving the joystick button left/right.




• The joystick button is located at the bottom of the monitor.

Moving and Lifting the Monitor

When moving or lifting the monitor, follow these instructions to prevent the monitor from being scratched or damaged and to ensure safe transportation, regardless of its shape or size.

- Place the monitor in the original box or packing material before attempting to move it.
- Before moving or lifting the monitor, disconnect the power cord and all other cables.
- Hold the bottom and side of the monitor frame firmly. Do not hold the panel itself.
- When holding the monitor, the screen should face away from you to prevent it from being scratched.
- When transporting the monitor, do not expose the monitor to shock or excessive vibration.
- When moving the monitor, keep it upright and never turn the monitor on its side or tilt it sideways.






A CAUTION

- Avoid touching the monitor screen as much as possible.
- This may result in damage to the screen or some of the pixels used to create images.
- If you use the monitor panel without the stand base, its joystick button may cause the monitor to become
 unstable and fall, resulting in damage to the monitor or human injury. In addition, this may cause the joystick
 button to malfunction.

Installing on a Table

 Lift the monitor and place it on the table in an upright position. Place the monitor at least 100 mm away from the wall to ensure sufficient ventilation.




! CAUTION

- Unplug the power cord before moving or installing the monitor. There is risk of electric shock.
- Make sure to use the power cord that is provided in the product package and connect it to a grounded power outlet.
- If you need another power cord, please contact your local dealer or the nearest retail store.

Adjusting the Stand Height

- 1 Place the monitor mounted on the stand base in an upright position.
- 2 Handle the monitor with both hands for safety.




MARNING

• When adjusting the screen height, do not place your hand on the stand body to avoid injury to your fingers.

Adjusting the Angle


- 1 Place the monitor mounted on the stand base in an upright position.
- 2 Adjust the angle of the screen.

The angle of the screen can be adjusted forward or backward from -5° to 35° for a comfortable viewing experience.





WARNING



• Be careful not to touch or press the screen area when adjusting the angle of the monitor.



Rear Side





Swivel stand

- Image shown may differ from your Monitor set.
- 1 Swivel 355 degrees and adjust the angle of the Monitor set to suit your view.

WARNING

- To avoid injury to the fingers when adjusting the screen, do not hold the lower part of the monitor's frame as illustrated below.
- Be careful not to touch or press the screen area when adjusting the angle of the monitor.

Using the Kensington Lock

The connector for the Kensington security system is located at the back of the monitor.

For more information on installation and usage, refer to the Kensington lock owner's manual or visit the website at http://www.kensington.com.

Connect the monitor to a table using the Kensington security system cable.




NOTE

• The Kensington security system is optional. You can obtain optional accessories from most electronics stores.



• The left or right side of the monitor head can be slightly rotated up or down (up to 3°). Adjust the horizontal level of the monitor head.



Installing the Wall Mount Plate

This monitor meets the specifications for the wall mount plate or other compatible devices.




NOTE

- The wall mount plate is sold separately.
- For more information on installation, refer to the wall mount plate's installation guide.
- Be careful not to apply too much force while mounting the wall mount plate as it may cause damage to the screen.
- Remove the stand before installing the monitor on a wall mount by performing the stand attachment in reverse.

Installing on the Wall

Install the monitor at least 100 mm away from the wall and leave about 100 mm of space at each side of the monitor to ensure sufficient ventilation. Detailed installation instructions can be obtained from your local retail store. Alternatively, please refer to the manual for how to install and set up a tilting wall mounting bracket.



To install the monitor to a wall, attach a wall mounting bracket (optional) to the back of the monitor. Make sure that the wall mounting bracket is securely fixed to the monitor and to the wall.


Wall Mount (mm)	100 x 100
Standard screw	M4 x L10
Number of screws	4
Wall Mount Plate (Optional)	LSW 149



- A non-VESA standard screw may damage the product and cause the monitor to fall. LG Electronics is not liable
 for any accidents relating to the use of non-standard screws.
- The wall mount kit includes the installation guide and all necessary parts.
- The wall mounting bracket is optional. You can obtain optional accessories from your local dealer.
- The length of the screw may differ for each wall mounting bracket. If you use screws longer than the standard length, it may damage the inside of the product.
- For more information, please refer to the user manual for the wall mounting bracket.

! CAUTION

- Unplug the power cord before moving or installing the monitor to avoid electric shock.
- Installing the monitor on the ceiling or on a slanted wall may result in the monitor falling off, which could lead
 to injury. Use an authorized LG wall mount and contact the local dealer or qualified personnel.
- Applying excessive force when tightening screws may cause damage to the monitor. Damage caused in this
 way will not be covered by the product warranty.
- Use the wall mounting bracket and screws that conform to VESA standards. Damage caused by the use or misuse of inappropriate components will not be covered by the product warranty.
- When measured from the back of the monitor, the length of each installed screw must be 8 mm or less.



USING THE MONITOR

• Illustrations in this manual may differ from the actual product.

Press the joystick button, go to **Settings** \rightarrow **Input**, and then select the input option.

! CAUTION

- Do not press the screen for a prolonged time. This may cause image distortion.
- Do not display a still image on the screen for a prolonged time. This may cause image retention. Use a PC screensaver if possible.
- When connecting the power cord to the outlet, use a grounded (3-hole) power strip or a grounded power
- The monitor may flicker when turned on in an area where the temperature is low. This is normal.
- Sometimes red, green, or blue spots may appear on the screen. This is normal.

Connecting to a PC

- This monitor supports the *Plug and Play feature.
- * Plug and Play: A feature that allows you to add a device to your computer without having to reconfigure anything or install any manual drivers.

HDMI Connection

Transmits digital video and audio signals from your PC to the monitor.



- Using a DVI to HDMI / DP (DisplayPort) to HDMI cable may cause compatibility issues.
- Use a certified cable with the HDMI logo attached. If you do not use a certified HDMI cable, the screen may not display or a connection error may occur.
- Recommended HDMI cable types
- High-Speed HDMI°/™ cable
- High-Speed HDMI°/TM cable with Ethernet

DisplayPort Connection

Transmits digital video and audio signals from your PC to the monitor.



- There may be no video or audio output depending on the DP (DisplayPort) version of the PC.
- If you are using a Mini DisplayPort output graphics card, use a Mini DP to DP (Mini DisplayPort to DisplayPort) cable or gender that supports DisplayPort 1.4. (Sold separately)

Connecting AV Devices

HDMI Connection

HDMI transmits digital video and audio signals from your AV device to the monitor.



- Using a DVI to HDMI / DP (DisplayPort) to HDMI cable may cause compatibility issues.
- Use a certified cable with the HDMI logo attached. If you do not use a certified HDMI cable, the screen may not display or a connection error may occur.
- · Recommended HDMI cable types
 - High-Speed HDMI°/™ cable
 - High-Speed HDMI°/™ cable with Ethernet

Connecting Peripherals

USB Cable connection

The USB port on the product functions as a USB hub.

To use USB 3.0, connect the A-B type USB 3.0 cable of the product to the PC.

Peripheral devices connected to the USB IN port can be controlled from the PC.



- Make sure to install the most recent Windows OS service pack before using the product.
- Peripheral devices are sold separately.
- A keyboard, mouse, or USB device can be connected to the USB port.



Cautions When Using a USB Device

- A USB device with an automatic recognition program installed, or that uses its own driver, may not be recognized.
- Some USB devices may not be supported or may not work properly.
- It is recommended to use a USB hub or hard disk drive with power supplied. (If the power supply is not adequate, the USB device may not be recognized properly.)

Headphones Connection

Connect peripherals to the monitor via the headphones port.



NOTE

- Peripheral devices are sold separately.
- Depending on the audio settings of the PC and external device, headphones and speaker functions may be limited.
- If you use angled earphones, it may cause a problem with connecting another external device to the monitor. Therefore, it is recommended to use straight earphones.





Angled

Straight (Recommend)

USER SETTINGS



• Your monitor's OSD (On Screen Display) may differ slightly from that shown in this manual.


Activating the Main Menu



- 1 Press the joystick button on the bottom of the monitor.
- 2 Move the joystick up/down and left/right to set the options.
- Press the joystick button once more to exit the main menu.

Button	Menu Status		Description		
	Main menu disabled		Enables the main menu.		
Main menu enabled		nu enabled	Exits the main menu. (Holding down the button more than 3 seconds to turn off the monitor. You can turn off the monitor this way at any time, including when the OSD is on.)		
		Main menu disabled	Adjusts the monitor volume level.		
	Main menu enabled		Enters the Input features.		
	Main menu disabled Main menu enabled		Adjusts the monitor volume level.		
			Enters the Settings feature.		
<u> </u>	Main menu disabled Displays the information on the current input.		Displays the information on the current input.		
	Main menu enabled		Turns off the monitor.		
	Main menu disabled Main menu enabled		Displays the information on the current input.		
Y			Enters the Picture Mode feature.		

Main Menu Features



Main Menu	Description		
Input	Sets input mode.		
Power Off	Turns off the monitor.		
Settings	Configures the screen settings.		
Picture Mode	Sets the picture mode.		
Exit	Exits the main menu.		

Menu Settings

- 1 To view the OSD menu, press the joystick button at the bottom of the monitor and then enter the **Settings**.
- 2 Move the joystick up/down and left/right to set the options.
- 3 To return to the upper menu or set other menu items, move the joystick to ◀ or pressing (؈) it.
- 4 If you want to exit the OSD menu, move the joystick to ◀until you exit.











Quick Settings

Input

Picture

Sound

General

Quick Settings

Settings > Quick Settings	Description			
Brightness	Adjusts the contract and brightness of			
Contrast	Adjusts the contrast and brightness of	uie scieen.		
	Adjusts the volume.			
Volume	NOTE			
	You can adjust Mute / Unmute by moving the joystick button to ▼ in the Volume menu.			
	Custom	The user can adjust it to red, green, or blue by customization.		
	Warm	Sets the screen color to a reddish tone.		
Color Temp	Medium	Sets the screen color between a red and blue tone.		
	Cool	Sets the screen color to a bluish tone.		
Manual The user can fine-tune the color temperature.				
Manager de	On	MaxxAudio® by Waves, recipient of a Technical GRAMMY Award® is a suite of studio-quality sound tools for a superior listening experience.		
MaxxAudio	Off	Disables the MaxxAudio function.		

Input

Settings > Input	Description		
Input List	Selects the input mode.		
	Adjusts the aspect ratio of the screen.		
	Full Wide	Displays the video in widescreen, regardless of the video signal input.	
	Original	Displays video according to the aspect ratio of the video signal input.	
Aspect Ratio	Just Scan The aspect ratio is not adjusted from the original. NOTE		
	• The display may look the same for Full Wide, Original, and Just Scan options at the recommended resolution (2560 x 1440).		
	There is no Just Scan menu on FreeSync Mode. (Go to Picture → Game Adjust → FreeSync , to set from On to Off)		

Picture



• If the **Picture Mode** is changed, the screen may flicker or the resolution of your PC screen may be affected.

Settings > Picture	Description			
	Custom	Allows the user to adjust each element.		
	Vivid	Heightens contrast, brightness and sharpness to display vivid images.		
	HDR Effect	Optimizes the screen for high dynamic range.		
	Reader	Optimizes the screen for viewing documents. You can brighten the screen in the OSD menu.		
Picture Mode	Cinema	Optimizes the screen for video.		
	FPS	This mode is optimized for FPS games.		
	RTS	This mode is optimized for RTS Game.		
	Color Weakness	This mode is for users who cannot distinguish between red and green. It enables users with color weakness to easily distinguish between the two colors.		

[Picture Mode on HDR signal]

Settings > Picture	Description			
	Custom	Allows the user to adjust each element.		
	Vivid	Optimized the screen for HDR vivid colors.		
	Cinema	Optimized the screen for HDR video.		
	FPS	This mode is optimized for FPS games.It is suitable for very dark FPS games.		
Picture Mode	RTS	This mode is optimized for RTS Game.		
	 NOTE HDR content may not display correctly depending on Window10 OS settings, please check HDR On/Off settings in Windows. When the HDR function is turned on, the characters or picture quality may be poor according to Graphic card performance. While the HDR function is on, screen flickering or cracking may occur when changing the monitor input or power on/off according to Graphic card performance. 			

Settings > Picture	Description		
	Brightness	Adjusts the centre	et and heightness of the serven
	Contrast	Adjusts the contrast and brightness of the screen.	
	Sharpness	Adjusts the sharpness of the screen.	
		High	Optimizes the screen for crystal clear images. Best for high-definition video or games.
	SUPER RESOLUTION+ O	Middle	Optimizes the screen for comfortable viewing, with images at the middle level between the low and high modes. Best for UCC or SD videos.
		Low	Optimizes the screen for smooth and natural images. Best for still images or images with less movement.
Picture Adjust		Off	Displays in the most common setting. Disables SUPER RESOLUTION+ .
			function to increase the sharpness of low resolution pictures, it is not recommended to use the function for normal text cons. Doing so may result in unnecessarily high sharpness.
	Black Level	Sets the offset leve Offset: as a refer	el (for HDMl only). rence for a video signal, this is the darkest color the monitor can display.
		High	Keeps the current contrast ratio of the screen.
		Low	Lowers the black levels and raises the white levels from the current contrast ratio of the screen.
	DF4	On	Adjusts the brightness automatically according to the screen.
	DFC	Off	Disables the DFC feature.

Settings > Picture	Description		
	Sets a response time for displayed pictures based on the movement of the picture on the screen. For a normal environment, it is recommended that you use Fast . When there is a lot of motion, it is recommended the Setting to Faster may cause image sticking.		onment, it is recommended that you use Fast . When there is a lot of motion, it is recommended that you use Faster .
	Response Time	Faster	Sets the response time to Faster.
		Fast	Sets the response time to Fast.
		Normal	Sets the response time to Normal.
		Off	Does not use the response time improvement feature.
		Provides seamless and natural images by synchronizing the vertical frequency of the input signal with that of the output signal.	
Game Adjust		<u>^</u> CAUTION	
		Supported Interface: DisplayPort,HDMI.	
	FreeSync	Supported Graphic Card : A graphic card that supports AMD's FreeSync is necessary.	
	,	Supported Version : Make sure to update the graphic card to the latest driver.	
		For more information and requirement, refer to AMD website at http://www.amd.com/FreeSync	
		On	FreeSync function on.
		Off	FreeSync function off.
	You can control the black contrast to have better visibility in dark scenes. Increasing the Black Stabilizer value brightens the low gray level area on the screen. (You can easily distinguish obscreens.)		e black contrast to have better visibility in dark scenes.
			ck Stabilizer value brightens the low gray level area on the screen. (You can easily distinguish objects on dark game
		Reducing the Blac	k Stabilizer value darkens the low gray level area and increases the dynamic contrast on the screen.

Settings > Picture		Description		
	Gamma	Mode 1, Mode 2, Mode 3	The higher the gamma value, the darker the image becomes. Likewise, the lower the gamma value, the lighter the image becomes.	
		Mode 4	If you do not need to adjust the gamma settings, select Mode 4 .	
		Set your own color	temperature.	
		Custom	The user can adjust it to red, green, or blue by customization.	
	Color Temp	Warm	Sets the screen color to a reddish tone.	
		Medium	Sets the screen color to between a red and blue tone.	
Color Adjust		Cool	Sets the screen color to a bluish tone.	
		Manual	The user can fine-tune the color temperature.	
	Red/Green/Blue	You can customize the picture color using red, green, and blue colors.		
	Six Color	Meets the user requirements for colors by adjusting the hue and saturation of the six colors (red, green, blue, cyan, magenta, and yellow) and then saving the settings.		
		Hue	Adjusts the tone of the screen colors.	
		Saturation	Adjusts the saturation of the screen colors. The lower the value, the less saturated and brighter the colors become. The higher the value, the more saturated and darker the colors become.	
Distura Dasat	Do you want to reset your picture settings?	Yes	Returns to the default settings.	
Picture Reset		No	Cancel the select.	

Settings > Sound	Description		
Volume	To adjust the Volume of headphone or speaker.		
Manage And Ba	On	$MaxxAudio^{\circ}\ by\ Waves,\ recipient\ of\ a\ Technical\ GRAMMY\ Award^{\circ}\ is\ a\ suite\ of\ studio-quality\ sound\ tools\ for\ a\ superior\ listening\ experience.$	
MaxxAudio	Off	Disables the MaxxAudio function.	

General

Settings > General	Description		
Language	Sets the menu screen to the desired language.		
	Conserve energy by using luminance compensation algorithm.		
	High	Saves energy using the high-efficiency SMART ENERGY SAVING feature.	
	Low	Saves energy using the low-efficiency SMART ENERGY SAVING feature.	
SMART ENERGY SAVING	Off	Disables the feature.	
	 NOTE The value of energy saving data may differ depending on panel and panel suppliers. If you select the option of SMART ENERGY SAVING is High or Low, monitor luminance become lower or higher depend on source. 		
	On	The power LED turns on automatically.	
	Off The power LED turns off.		
Power LED	 NOTE When the Power LED function is turned on, it operates as follows: On Mode: White Sleep Mode: White Blinking Off Mode: Off 		
Automatic Standby	Feature that automatically turns off the monitor when there is no movement on the screen for a period of time. You can set a timer for the auto-off function. (Off, 4 H, 6 H, and 8 H)		
DisplayPort Version	Set DisplayPort Version to the same version as the connected external device. (1.4, 1.2, and 1.1) To use the HDR function, set to 1.4.		

Settings > General	Description		
	This feature lets you set the sound generated t	from Buzzer when your monitor powers on.	
Buzzer	On	Enables your monitor's Buzzer .	
	Off	Disables your monitor's Buzzer .	
	This feature disables the configuration and ad	justment of menus.	
	On	Enables OSD Lock .	
OSD Lock	Off	Disables OSD Lock .	
	● NOTE		
	All features are disabled except Brightness, Contrast, Volume, Input List, Aspect Ratio, OSD Lock and Information.		
Information	The following display information will be shown; Total Power On Time, Resolution.		
	Do you want to reset your settings?		
Reset to Initial Settings	Yes	Returns to the default settings.	
	No	Cancel the reset.	

TROUBLESHOOTING

Nothing is displayed on the screen.	
Is the monitor's power cord plugged in?	Check if the power cord is correctly plugged into the power outlet.
Is the power LED on?	Check the power cable connection and press the power button.
Is the power on and the power LED displaying white?	Check that the connected input is enabled (Settings > Input).
Is the No Signal message being displayed?	• This is displayed when the signal cable between the PC and the monitor is missing or disconnected. Check the cable and reconnect it.
Is the Out of Range message being displayed?	• This occurs when signals transferred from the PC (graphics card) are out of the horizontal or vertical frequency range of the monitor. Please see the Product Specification section of this manual to set the appropriate frequency.
Screen display is unstable and shaky. / Images displayed on the	e monitor leave shadow trails.
Did you select the appropriate resolution?	 If the selected resolution is HDMI 1080i 60/50 Hz (interlaced), the screen may be flickering. Change the resolution to 1080p or the recommended resolution. Not setting the graphics card to the recommended (optimal) resolution may result in blurred text, a dimmed screen, a truncated display area or misalignment of the display. The setting methods may be different depending on the computer or operating system, and some resolutions may not be available depending on the performance of the graphics card. If this is the case, contact the manufacturer of the computer or graphics card for assistance.
Does image sticking occur even when the monitor is turned off?	 Displaying a still image for a prolonged time may cause damage to the screen, resulting in the retention of the image. To extend the lifetime of the monitor, use a screensaver.
Are there spots on the screen?	When using the monitor, pixilated spots (red, green, blue, white, or black) may appear on the screen. This is normal for an LCD screen. It is not an error, nor is it related to the monitor's performance.
Some features are disabled.	
Are some functions not available when you press the Menu button?	The OSD is locked. Disable OSD Lock in General.

Do you see an "Unrecognized monitor, Plug and Play (VESA DDC) monitor found" message?			
Have you installed the display driver? Be sure to install the display driver from our web site: http://www.lg.com. Make sure to check if the graphics card supports Plug and Play function.			
No sound from the headphone port.			
Are images displayed without sound? • Make sure that the headphone port connections are made properly. • Try increasing the volume with the joystick. • Set the audio output of the PC to the monitor you are using. (The settings may differ depending on the operating system (OS) you use.)			

NOTE

• LED can be lighted with Set OSD Menu. Settings — General — Power LED — On

PRODUCT SPECIFICATION

Color Depth	8-bit / 10-bit color is supported.			
	Max Resolution	2560 x 1440 @ 75 Hz		
Resolution	Recommended Resolution	2560 x 1440 @ 60 Hz		
	Power Rating	19V 2.4A		
Power Sources	Power Consumption	On mode: 18.1 W Typ. (ENERGY STAR® standard)* Sleep Mode \leq 0.5 W ** Off Mode \leq 0.3 W		
AC/DC adaptor	DA-48F19 type, Asian Power Devices Inc. Or ADS-48F5K-19 19048EPCU-1 type, SHENZHEN HONOR ELECTRONIC Or ADS-48F5K-19 19048EPK-1 type, SHENZHEN HONOR ELECTRONIC Or ADS-48F5K-19 19048EPG-1 type, SHENZHEN HONOR ELECTRONIC Output: 19 V = 2.53 A			
	Operating Conditions	Temperature	0 °C to 40 °C	
Environmental Conditions		Humidity	Less than 80 %	
Environmental Conditions	Storing Conditions	Temperature	-20 °C to 60 °C	
		Humidity	Less than 85 %	
	Monitor Size (Width x Height x Depth)			
Dimensions	With Stand	613.5 x 527.6 x 249.5 (mm)		
	Without Stand	613.5 x 363.5 x 45.4 (mm)		
Weight (Without Packaging)	With Stand	7.0 kg		
weight (without rackaging)	Without Stand	4.8 kg		

The specifications are subject to change without notice.

The power consumption level can be different by operating condition and monitor setting.

^{*} The On mode power consumption is measured with ENERGY STAR® test standard.

^{**} The monitor goes to the Sleep Mode in a couple of minutes(Max 5 minutes).

Factory Support Mode (Preset Mode, PC)

DisplayPort

Preset Mode	Horizontal Frequency (kHz)	Vertical Frequency (Hz)	Polarity (H/V)	Remarks
640 x 480	31.469	59.94	-/-	
800 x 600	37.879	60.317	+/+	
1024 x 768	48.363	60	-/-	
1152 x 864	54.347	60.05	+/+	
1280 x 720	45.00	60.00	+/+	
1280 x 800	49.702	59.810	-/+	
1280 x 1024	63.981	60.02	+/+	
1600 x 900	60.00	60.00	+/+	
1920 x 1080	67.5	60	+/-	
2560 x 1440	88.79	59.95	+/-	
2560 x 1440	111.86	74.97	+/-	

Preset Mode	Horizontal Frequency (kHz)	Vertical Frequency (Hz)	Polarity (H/V)	Remarks
640 x 480	31.469	59.94	-/-	
800 x 600	37.879	60.317	+/+	
1024 x 768	48.363	60	-/-	
1152 x 864	54.347	60.05	+/+	
1280 x 720	45.00	60.00	+/+	
1280 x 800	49.702	59.810	-/+	
1280 x 1024	63.981	60.02	+/+	
1600 x 900	60.00	60.00	+/+	
1920 x 1080	67.5	60	+/-	
2560 x 1440	88.79	59.95	+/-	
2560 x 1440	110.95	74.96	+/-	

HDMI Timing (Video)

Factory support mode (Preset Mode)	Horizontal Frequency(kHz)	Vertical Frequency(Hz)	Remarks
480p	31.5	60	
720p	45.0	60	
1080р	67.5	60	
2160p	67.5	30	



The model and serial number of the product are located on the back and on one side of the product. Record them below in case you ever need service.

Model	
Serial No.	



This Product qualifies for ENERGY STAR®

 $Changing the factory default configuration and settings or enabling certain optional features and functionalities may increase energy consumption beyond the limits required for ENERGY STAR {\it `ertification.} \\$

Refer to ENERGYSTAR.gov for more information on the ENERGY STAR® program.