









1 2 3

Dell Display Manager:
Dell.com/DDM

Daisy Chain

Dell.com/support/P2425E