Dell 27 Gaming Monitor -S2721DGFA Dell Display Manager User's Guide





NOTE: A NOTE indicates important information that helps you make better use of your computer.

Copyright © 2020 Dell Inc. or its subsidiaries. All rights reserved. Dell, EMC, and other trademarks are trademarks of Dell Inc. or its subsidiaries. Other trademarks may be trademarks of their respective owners.

2020 - 07

Rev. A00

Contents

Overview
Using the Quick Settings Dialog
Setting Basic Display Functions
Assigning Preset Modes to Applications
Organizing Windows with Easy Arrange
Managing Multiple Video Inputs
Restoring Application Positions
Applying Energy Conservation Features
Other Shortcut Keys13
Attach DDM To Active Window (Only Window 10) 14
Troubleshooting

(D&LL

Overview

Dell Display Manager is a Microsoft Windows application used to manage a display or a group of displays. It enables manual adjustment of the displayed image, assignment of automatic settings, energy management, window organization, image rotation, and other features on selected Dell displays. After installed, Dell Display Manager runs each time the system starts and places its icon in the notification tray. Information about displays connected to the system is available when hovering over the notification-tray icon.



NOTE: Dell Display Manager uses DDC/CI channel to communicate with your display. Ensure that DDC/CI is enabled in the menu as below.

Deel	Dell 27 Gaming Monitor		
g			
::			÷
¢			
Ţ			×
-4>			^
☆			
11			
_			

S2721DGF

DEL

Using the Quick Settings Dialog

Clicking Dell Display Manager's notification tray icon to open the **Quick Settings** dialog box. When more than one supported Dell displays are connected to the computer, a specific target display can be selected using the menu. The **Quick Settings** dialog box enables convenient adjustment of the display's brightness, contrast, resolution, window layout, and so on. You can select **Manual Mode** or **Auto Mode**, and the screen resolution can be changed.

(reu) Display	Manager	
Displays	Del 6272406F +	
Resskation	2540x1440	change
C ALIO MODE		confloure
(B) Manual Music	Standord	v
Dightreas		74%
Conbust	<mark>.</mark>	75%
×		
		>
	Open tiel risplay Manager	

The **Guick Settings** dialog box also provides access to Dell Display Manager's advanced user interface that is used to adjust basic functions, configure auto mode and access other features.

MOTE:

Feature	Function	Description
Quick DDM Access	Quick key to call up DDM UI	 Ctrl+Shift+D Use Page Up/Page Down key or click on ">" to flip through all Easy Arrange layouts.
	Control individual display in multiple display setup	 From dropdown box to select display, selected display has Dell logo shown. Perform display self-test feature check. Move DDM UI to the display to be controlled. Press Ctrl+Shift+D to bring up the miniUI under the mouse pointer.



Setting Basic Display Functions

You can select **Manual Mode** that enables you to manually select a preset mode or select **Auto Mode** that applies a preset mode based on the active application. An onscreen message displays the current preset mode whenever it changes. The selected display's **Brightness** and **Contrast** can also be directly adjusted from the **Basic** tab.

Denkc	Auto Made	Bacy Arrange	triput Manager	opaure	
Rank, dox	2560a 14	140			Change
		for active application			Carifyre
Chaose a p	se model		3	tandard	¥
Drightness:			70%		
Combrasto	1.1.1		75%		

NOTE: When multiple Dell displays are connected, select "Enable display matrix control" to apply brightness, contrast and color presets controls to all displays.

Depic	Auto made	Bacy Arrange	Dip.r.Marager	Options	
lask.tox	2560x14	940			Change
O Auto Mode Luce preset	nade acognineirs f	for active applications			Configure
Choose a p				standard	¥
Brightnessi	5.00		74%		
Combrasts			75%		
Distant dat	ey metric control				

DELI

Assigning Preset Modes to Applications

The **Auto Mode** tab allows you to associate a specific **Preset Mode** with a specific application, and apply it automatically. When **Auto Mode** is enabled, Dell Display Manager automatically switches to the corresponding **Preset Mode** whenever the associated application is activated. The **Preset Mode** assigned to a particular application may be the same on each connected display, or it can vary from one display to another.

Dell Display Manager is pre-configured for many popular applications. To add a new application to the assignment list, simply drag the application from the desktop, Windows Start Menu, or elsewhere, and drop it onto the current list.

NOTE: Preset Mode assignments for batch files, scripts, loaders, and nonexecutable files such as zip archives or packed files, are not supported.

You can also configure the Game preset mode to be used whenever a Direct3D application runs in full-screen mode. To prevent an application from using mode, assign a different preset mode to it.


Reso:	Auto Mede	RMQ AR	ange .	WARKING MANAGER	riptions	
reign a presei	t mode to a specific a	epoleation.	To add a	n application, they it	to the lat:	
Application			Pres	et.Pierde		^
Default	(may optimize the test		510	ded	v	
Default	for fulleareen Direct	900	(in	el.	~	
E Defait	for universal trincles	(expected	We	-	~	
Adda R	broatler		310	ndend	~	
🥂 Internet	Explorer		Wa	-	~	~

Dell

7


Organizing Windows with Easy Arrange

Easy Arrange helps you to effectively organize your application windows on the desktop. You first choose a pre-defined layout pattern which suits your work, then you just need to drag the application windows into the defined zones. Press ">" or use Page Up/Page Down key to find more layouts. To create a custom layout, arrange the open windows and then click **Save**.



For Windows 10, you can apply different window layouts for each of the virtual desktops.


If you often use Windows snap feature, you can select "**Hold down the SHIFT key to enable zone positioning**". This gives Windows snap priority over **Easy Arrange**. You will then need to press the Shift key to use **Easy Arrange** positioning.





DELL

If you are using multiple displays in an array or matrix, **Easy Arrange** layout can be applied across to all the displays as one desktop. Select "**Span multiple displays**" to enable this feature. You need to align your displays properly to make it effective.



There are other advanced ways for the usage of Easy Arrange. Refer to table below.

Feature	Function	Description
Enhanced Easy Arrange	Custom lay- outs	 Save and name 5 customized Easy Arrange patterns. Configure x*y patterns.
	5 MRU (most- recently-used) layouts	 Press Ctrl+Shift+Home to cycle among the last 5 MRU layouts.
	On the fly par- tition resizing	 Hold down Ctrl while resizing current Easy Arrange layout to adjust the size and numbers of cells in a layout. Newly formed Easy Arrange pattern is saved into the Easy Arrange icon position. Hold down Ctrl while clicking on a modified layout icon to restore it to default layout.
	Easy Arrange layouts for portrait mode	 Portrait mode Easy Arrange icons are present- ed when display is rotated.

NOTE: An application may require a minimum effective resolution for its application window. Such application may not fit in an Ease Arrange zone if the zone is smaller than the required window size.

9

Managing Multiple Video Inputs

The **Input Manager** tab provides convenient ways for you to manage multiple video inputs connected to your Dell display. It makes it very easy to switch between inputs while you work with multiple computers.

All video input ports available to your display are listed. You can give each input a name as you like. Please save your changes after editing.

You can define a shortcut key to quickly switch to your favorite input and another shortcut key to quickly switch between two inputs if you often work between them.

Sec.	Auto Made	Bary Amarge	Deut Har	197	Options	
Input ports	liqui	maner.				
0P	1244	its estil)				
HEHEL(Addree)	220	to +dd				
16942	1048	is all (
					Seve	
Parante input abort	ntiny	1.11				
NON	20	-043			charge active input.	
input switch shorts	oker:					
Norid	10	4941		101	HHE	

You can use the dropdown list to switch to any input source.

heir	Auto-Rode	See lenner	Input Men	iger	Options	
liquit parts	lips.	d numer				
DP	(26	(land)				
HORES (Advin)	(De	i is edij				
HOHI2	636	004-011				
					Seat	
Pavorite riput sho	find keys					
1914	20	HEHEE	1		Change active in	M
heat which share						
Hane	1.0	HEHEL			HEHEE	

NOTE: DDM communicates with your display even when the display is displaying video from another computer. You can install DDM on the computer you frequently use and control input switching from it. You may also install DDM on other computers connected to the display.



Restoring Application Positions

DDM can help you restore application windows into their positions when you reconnect your computer to the display(s). You can quickly access to this feature by right-clicking on DDM icon in the notification tray.



If you choose "**Auto-restore window layout**", your application windows' positions are tracked and remembered by DDM. DDM automatically puts the application windows into their original positions when you reconnect your computer to your display(s).

	Open Dell Display Manager Attach to active window
	Save carrent window layout
	Restore saved window layout
4	Auto-restore window layout
	Online documentation
	Checkfor new version
	Edit .

If you want to go back to a favorite layout after you have moved the application windows around, you can first "Save current window layout" and later "Restore saved window layout".



You may use displays with different models or resolutions in your daily routine, and you may apply different window layouts on them. DDM is able to know the display you have reconnected and restore application positions accordingly.


In case you need to replace a display in a display matrix configuration, you can save the window layout before replacement and restore the layout after a new display is installed.

NOTE: You should keep your applications running in order to benefit from this feature. DDM doesn't launch applications.




Applying Energy Conservation Features

On supported Dell models, an Options tab is available that provides PowerNap energy conservation options. You can choose to set the display's brightness to the minimum level, or to put the display to sleep when the screensaver is activated.



NOTE: The Dark Stabilizer shortcut key is available only when you select FPS game, RTS game, RPG game, SPORTS game, Game1, Game2 or Game3 preset mode.

Desic	Auto-Made	Easy Amange	Input Manager	Uptions	
Promiting	a capiliante-				Carlage
· ante	a brightness when so	reencever activates			
-	e daples to sleep who				
wagan dor	tout keys		Application mindaw sh	ortnut keys	
CH 4 Shift 4	D		Citil 4 Shift 4 Hum 9		
Even Annenge	MRLI shartcut key:				
Orl + Shift +	Hum 7				
Dark Stabilize	ahertout key:				
New					



DELI

Other Shortcut Keys

Shortcut keys can be defined for below operations, you can define the shortcut keys for quick access to perform these operations:

- Program shortcut key: to quickly open the Quick Settings dialog box.
- Easy Arrange MRU shortcut key: to quickly apply the 5 recently used window layouts.
- Application window shortcut key: to launch a quick menu for options under Auto Mode and Easy Arrange.
- **Dark Stabilizer shortcut key:** to quickly improve the visibility in the dark gaming scenarios.

Desic	Auto-Made	Easy Amange	Input Manager	uptions		
Parentin	p capilians.				Carlagar	
· Retu	a brightness when so	reencever ectivates				
ON	te display to sless wh	on surchmarker activ	ajus			
Fragram chartout keys Ctrl + shift + Num 2			Ctrl + shift + Num 3			
			Gui + Shint + Nulli	5		
	MRL1 short cut key:					
Ctrl + shift	t + Num 4					
Dark Stabilize	r shartout key:					
Ctrl + shift	t + Num 5					



Attach DDM To Active Window (Only Window 10)

DDM icon can be attached to the active window you are working on. Click on the icon for easy access to below features.


Feature	Function	Description	
Attach DDM to Active Window (only Window	Change preset or snap to different partitions	 DDM icon attached to active window and user can eas- ily switch windowposition, change color preset mode, and associate auto preset mode. 	
10)	Shortcut key trigger	 On a running app window, press Ctrl+Shift+Ins also triggers the attached DDM menu. 	
	Move app window among Easy Arrange cells	 Send the app window to previous/next Easy Arrange cell. 	
	Move app window among displays	• Send the app window to previous/next display.	

	Open Dell Display Manager					
ł	Attach to active window					
	Save current window layout					
	Restore seved window leyout					
	Auto-restore window layout					
	Online documentation					
	Check for new version-					
	Eat					
	A.P. 3240.					
	6		Move window to			
			Standard			
		1	FPS Game			
			RTS Game			
			RPG Game			
			SPORTS Game			
			SPORTS Game			
			SPORTS Game Game1			
			SPORTS Game Game1 Game2			


DELL

Troubleshooting

If DDM does not work with your display, DDM will show below icon in your notification tray.



Click on the icon, DDM shows a more detailed error message.



Please note that DDM only works with Dell branded displays. If you are using displays from other manufacturers, DDM doesn't support them.

If DDM is unable to detect and/or communicate with a supported Dell display, please take below actions to troubleshoot:

- 1. Make sure the video cable is properly connected to your display and your computer. especially the connectors should be firmly inserted into position.
- **2.** Check the display OSD to ensure DDC/Cl is enabled.
- **3.** Make sure you have the correct and latest display driver from the graphics vendor (Intel, AMD, NVidia, etc.). Display driver is often the cause of DDM failure.
- **4.** Remove any docking stations or cable extenders or converters between the display and the graphics port. Some low-cost extenders, hubs or converters may not support DDC/CI properly and can fail DDM. Update the driver of such device if the latest version is available.
- 5. Restart your computer.

DEL

DDM may not work with below displays:

- Dell display models earlier than year 2013 and D-series of Dell displays. For more information see www.dell.com/support/monitors.
- Gaming displays using Nvidia-based G-sync technology
- · Virtual and wireless displays do not support DDC/CI
- Some early models of DP 1.2 displays, it may be necessary to disable MST/DP 1.2 using the display OSD

If your PC is connected to the Internet, you will be prompted to upgrade to a newer version of DDM when it is available. It is recommended to download and install the latest DDM application.

You may also check for new version by right clicking on DDM icon while pressing and holding 'shift' key.

	Open Dell Display Manager					
	Refresh					
	Save monitor asset report					
	Save diagnostic report					
	Save current window layout					
	Restore saved window layout					
	Auto-restore window layout					
\checkmark	Auto-load at startup					
~	Onscreen notifications					
	Check for new version					
	Exit					