Dell Display Manager User's Guide

Overview

Dell Display Manager is a Windows application used to manage a monitor or a group of monitors. It allows manual adjustment of the displayed image, assignment of automatic settings, energy management, image rotation and other features on select Dell models. Once installed, Dell Display Manager will run each time the system starts and will place its icon in the notification tray. Information about monitors connected to the system is always available when hovering over the notification tray icon.



Using the Quick Settings Dialog

Clicking Dell Display Manager's notification tray icon opens the Quick Settings dialog box. When more than one supported Dell model is connected to the system, a specific target monitor can be selected using the menu provided. The Quick Settings dialog box allows convenient adjustment of the monitor's Brightness and Contrast levels, Preset Modes can be manually selected or set to Auto Mode, and the screen resolution can be changed.

Display:	DM 62216H			
Resolution:	1820×1080	Change		
Auto Mode		Configure		
🚫 Manual Mode	Standard	4		
Brightness:	<mark>.</mark>	75%		
Contrast:	· · · · · · · · · · · · · · · ·	75%		
Open Dell Display Manager				

The **Quick Settings** dialog box also provides access to Dell Display Manager's advanced user interface which is used to adjust Basic functions, configure Auto Mode and access other features.

Setting Basic Display Functions

A Preset Mode for the selected monitor can be manually applied using the menu on the Basic tab. Alternatively, Auto Mode can be enabled. Auto Mode causes your preferred Preset Mode to be applied automatically when specific applications are active. An onscreen message momentarily displays the current Preset Mode whenever it changes.

The selected monitor's Brightness and Contrast can also be directly adjusted from the Basic tab.

el Display Ma	anager			Dell E221
0±k	Auto Made	Pawer Nap	1	
Resolution:	4920 = 1080			Change
 Auto Mode Use preset mod 	e assignments for active appli	cations		Configure
 Hanual Mode Choose a prese 	t made:		Standard	Ý
Brightness:	Ţ	25%		
Contrast:		75%		

Assigning Preset Modes to Applications

The Auto Mode tab allows you to associate a specific Preset Mode with a specific application, and apply it automatically. When Auto Mode is enabled, Dell Display Manager will automatically switch to the corresponding Preset Mode whenever the associated application is activated. The Preset Mode assigned to a particular application may be the same on each connected monitor, or it can vary from one monitor to the next.

Dell Display Manager is pre-configured for many popular applications. To add a new application to the assignment list, simply drag the application from the desktop, Windows Start Menu or elsewhere, and drop it onto the current list.

NOTE: Preset Mode assignments targeting batch files, scripts, and loaders, as well as non-executable files such as zip archives or packed files, are not supported and will be ineffective

Essk	Auto Made	Power Nap	1		
sign a preset mode to a :	specific application. 1	To add an application, dray	jit to the lists		
Application		Preset Mode			
🚨 Adobe Reader 8.0		Renderd	×	Renove	
🏉 Internet Explorer		Multimedia	×		
🔄 Nicrosoft Office Exc	el	Standard	*		
😼 Microsoft Office Out	look.	Standard	4		
📴 Microsoft Office Pau	er Point	Multimedia	*		
🔟 Nicrosoft Office Wo	nd	Standard	*		

Applying Energy Conservation Features

On supported Dell models, the PowerNap tab will be available to provide energy conservation options. When the screensaver activates, the monitor's Brightness can automatically be set to minimum level or the monitor can be put to sleep in order to save additional power.

Dell Display Ma	Sell Display Manager		
Bask	Auto Mode	PowerNep	0
🛃 PowerNap optio	ns:		
🛞 Reduce brigh	tness when spreensever as	ti-ates	
🔘 Put the displa	ay to sleep when screensav	er activates	