Dell P3223QE Dell Display Manager User's Guide





NOTE: A NOTE indicates important information that helps you make better use of your computer.

Copyright © 2022 Dell Inc. or its subsidiaries. All rights reserved. Dell, EMC, and other trademarks are trademarks of Dell Inc. or its subsidiaries. Other trademarks may be trademarks of their respective owners.

2022 - 05

Rev. A00


Contents

Overview
Using the Quick Settings Dialog
Setting Basic Display Functions
Assigning Preset Modes to Applications
Organizing Windows with Easy Arrange
Managing Multiple Video Inputs
Restoring Application Positions
Applying Energy Conservation Features
Other Shortcut Keys14
Attach DDM To Active Windows (Windows 10 Only)15
Troubleshooting


(D&LL

Overview

Dell Display Manager is a Microsoft Windows application used to manage a monitor or a group of monitors. It allows manual adjustment of the displayed image, assignment of automatic settings, energy management, window organization, image rotation, and other features on selected Dell monitors. After installed, Dell Display Manager runs each time the system starts and places its icon in the notification tray. Information about monitors connected to the system is available when hovering over the notification-tray icon.



NOTE: Dell Display Manager uses DDC/CI channel to communicate with your monitor. Ensure DDC/CI is enabled in the menu as follows.





DEL

Using the Quick Settings Dialog

Clicking Dell Display Manager's notification tray icon opens the **Quick Settings** dialog box. When more than one supported Dell monitors are connected to the computer, a specific target monitor can be selected using the menu. The **Quick Settings** dialog box allows you to easily adjust the brightness, contrast, resolution, window layout, and so on. It also allows you to enable automatic switching between preset modes or to select a preset mode manually.

Disclow.	Dell P3223QE		
Detailine	3840x2160		Sec.
() 4 x % A -			ie'ie
90 Manual Hash		Sardord	٧
Ligvenie	The second	- 85	1
Centrupts	F	24	
Recently used:		. Ha	e op store
		10 10 10 1	10.00

The **Guick Settings** dialog box also provides access to Dell Display Manager's advanced user interface that is used to adjust basic functions, configure auto mode and access other features.

Dél

MOTE:

Feature	Function	Description
Quick	Quick key to	Ctrl+Shift+D
DDM Access	call up DDM UI	 Use Page Up/Page Down key or click on ">" to flip through all Easy Arrange layouts.
AUCE33	Control individual display in multiple display setup	 Select the monitor from the dropdown box. If more than one monitor is connected to your computer, an icon appears on the selected monitor for a second so you know which monitor you have selected.
	display setup	 Perform monitor self-test feature check. Move DDM UI to the monitor to be controlled. Press Ctrl+Shift+D to bring up the miniUI under the mouse pointer.

(Dell

Setting Basic Display Functions

You can select **Manual Mode** that enables you to manually select a preset mode or select **Auto Mode** that applies a preset mode based on the active application. An onscreen message displays the current preset mode whenever it changes. The selected display's **Brightness** and **Contrast** can also be directly adjusted from the **Basic** tab.

	Auto Pode	TWA VUMBE	cibra venetie	6
keeps, sono	3840x2160			charge
	leavigment to accord	golociae		Comant
B Harvel Hode Utware a new	da ales		dechel	

NOTE: When multiple Dell monitors are connected, select "Enable display matrix control" to apply brightness, contrast and color presets controls to all monitors.

Exerc	Anter Manari	Sighteent	bra Massiper	010
Francisco	3840x2160			linge
C Kato Kode	le comptients la comp	g di state		Configure
 Nerva Pace Desteração 	d. ars		Flanking)	×.
Billik cos	10.10	U		
Onteres				

DEL

Assigning Preset Modes to Applications

The **Auto Mode** tab allows you to associate a specific **Preset Mode** with a specific application, and apply it automatically. When **Auto Mode** is enabled, Dell Display Manager automatically switches to the corresponding **Preset Mode** whenever the associated application is activated. The **Preset Mode** assigned to a particular application may be the same on each connected monitor, or it can vary from one monitor to another.

Dell Display Manager is pre-configured for many popular applications. To add a new application to the assignment list, simply drag the application from the desktop, Windows Start Menu or elsewhere, and drop it onto the current list.

NOTE: Preset Mode assignments for batch files, scripts, loaders, and non-executable files such as zip archives or packed files, are not supported.

You can also configure the Game preset mode to be used whenever a Direct3D application runs in full-screen mode. To prevent an application from using mode, assign a different preset mode to it.

date:	a da Park	Lan Atterps	Unput Hanager	69.3
and a later of a	et has an its galaxies.	Teachtar geleinne a	soft father in the	
		Freed Nade		
e chatte	Arishina aya	sandard	7	
() Chatty	have stars (10)	sare.	10	
C.t.t.I.	and and Mindows (1996)	99.0	1	100
Steam	100.0	Max		
C Mossilla	la.	WA B	-9-	
Motort P.	ent	2 is sized	1.4	12

DEL

Organizing Windows with Easy Arrange

Easy Arrange helps you to effectively organize your application windows on the desktop. You first choose a pre-defined layout pattern which suits your work, then you just need to drag the application windows into the defined zones. Press ">" or use Page Up/Page Down key to find more layouts. To create a custom layout, arrange the open windows and then click **Save**.



Windows OS 10 only, you can apply different window layouts for each of the virtual desktops.


If you often use Windows snap feature, you can select "**Hold down the SHIFT key to enable zone positioning**". This gives Windows snap priority over **Easy Arrange**. You will then need to press the Shift key to use **Easy Arrange** positioning.

Display	/ Manager		De	II P3223QE 🕴	×
Casic	Auto Mode	Replacer	arput Manager	Options	
Select a predefin sourcer and reco	ed or outloss window lay te externetically:	out for this monitor. Ope	in windows dragged in to	auch sone wi	
\times					
					>
Cvarlap trans		states and the adult is	lever		



9

If you are using multiple monitors in an array or matrix, **Easy Arrange** layout can be applied across to all the monitors as one desktop. Select "**Span multiple monitors**" to enable this feature. You need to align your monitors properly to make it effective.



There are other advanced usage of **Easy Arrange**. Refer to table below.

Feature	Function	Description
Enhanced Easy	Custom layouts	Save and name 5 customized Easy Arrange patterns.
Arrange		 Configure x*y patterns.
	6 MRU (most- recently-used) layouts	 Press Ctrl+Shift+Home to cycle among the last 6 MRU layouts.
	On the fly partition resizing	 Hold down Ctrl while resizing current Easy Arrange layout to adjust the size and numbers of cells in a layout.
		 Newly formed Easy Arrange pattern is saved into the Easy Arrange icon position.
		• Hold down Ctrl while clicking on a modified layout icon to restore it to default layout.
	Easy Arrange	Portrait mode Easy Arrange icons are presented
	layouts for	when monitor is rotated.
	portrait mode	

NOTE: An application may require a minimum effective resolution for its application window. Such application may not fit in an Ease Arrange zone if the zone is smaller than the required window size.

Managing Multiple Video Inputs

The **Input Manager** tab provides convenient ways for you to manage multiple video inputs connected to your Dell monitor. It makes it very easy to switch between inputs while you work with multiple computers.

All video input ports available to your monitor are listed. Provide a valid input name and save the changes.

You can define a shortcut key to quickly switch to your favorite input and another shortcut key to quickly switch between two inputs if you often work between them.

des.	date from .	line) de renge	- Pant Pan	Apr. Delet
rection.	Yakit tamer			
100 × 100	(Orle to add)			
IF Deniel	\$38 (p.a.4)			
iot:	(Date and)			
			100	100
wini muchi	fail ever			
ere .	- 188-C		-	Copations.
and mittle dard	uthers .			
Nitroit.	00 HEHE		and one like	ć

You can use the dropdown list to switch to any input source.

Sec.	Automatic 1	NAV REPART	1.14	d Managari (10001
had set	Institute				
248H	(Sink to mill)				
CP (Aven)	\$300 m arth;				
- timi	2545 m with				
				1.1	
S-ante reput shar	the weight				
laret	11 100-6		-	Desper	- 100
nid anth-shirt	suit keyy				
	The second			1.500-01	

NOTE: DDM communicates with your monitor even when the monitor is displaying video from another computer. You can install DDM on the computer you frequently use and control input switching from it. You may also install DDM on other computers connected to the monitor.

Restoring Application Positions

DDM can help you restore application windows into their positions when you reconnect your computer to the monitor(s). You can quickly access to this feature by right-clicking on DDM icon in the notification tray.



If you choose "**Auto-restore window layout**" (support Windows OS 10 or 8.1), your application windows' positions are tracked and remembered by DDM. DDM automatically puts the application windows into their original positions when you reconnect your computer to your monitor(s).

	Open Dell Digity Manger Attach to active window.
	Save current window layout Restaurs several window layout
×	Auto restore window layout
	Check for new version
	5.8

To go back to a favorite layout, first select **"Save current window layout**" and then **"Restore saved window layout**".



You may use monitors with different models or resolutions in your daily routine, and you may apply different window layouts on them. DDM is able to know the monitor you have reconnected and restore application positions accordingly.

In case you need to replace a monitor in a monitor matrix configuration, you can save the window layout before replacement and restore the layout after a new display is installed.

NOTE: You should keep your applications running in order to benefit from this feature. DDM does not lanuch applications.



Applying Energy Conservation Features

On supported Dell models, an Options tab is available that provides PowerNap energy conservation options. You can choose to set the display's brightness to the minimum level, or to put the display to sleep when the screensaver is activated.

P.ot	Sale Mede	Bas aver	free (Player	Uptions
	paure:			Configure
B berine	ad read a sea	or above		
	table to clean ther state			
03.0-12		16267837998 1979		
free or sheriou	tion:	Analyzite	nininden enerteut leur	
11 + 2 2 + 10			VI + Har J	
Fas heaty Pl	A Contraction of the			
1.2) + ah h + 10	6. e .			



Other Shortcut Keys

You can define the shortcut keys for quick access to the following DDM functions:

- **Program shortcut key:** to quickly open the **Quick Settings** dialog box.
- Easy Arrange MRU shortcut key: to quickly apply the 6 recently used window layouts.
- Application window shortcut key: to launch a quick menu for options under Auto Mode and Easy Arrange.

Deal:	astellion.	Sear Amongo	Input Henapor	Logram.
M from Harry	41 m			tan'ny s
Strades b	till the construction of the	ele-floren		
	leky and graterious			
			21 W	
		A spin a horizon them then the first for yo		
	len	and the second sec		
Ctrl + Alt + N	leo	Ctrl + Alt	+ Num 3	
		Ctrl + Alt		



Attach DDM To Active Windows (Windows 10 Only)

DDM icon can be attached to the active window you are working on. Click on the icon for easy access to below features.

Feature	Function	Description
Attach DDM to Active Window (Windows 10 only)	Change preset or snap to different partitions	DDM icon attached to active window and user can easily switch the window position, change color preset mode, and associate auto preset mode.
	Shortcut key trigger	• On a running app window, press Ctrl+Shift+Ins to trigger the attached DDM menu.
	Move app window	• Send the app window to previous/next Easy
	among Easy	Arrange cell.
	Arrange cells	
	Move app window among monitors	Send the app window to previous/next monitor.

~	All Sev Res Aut	en Dell Display Manager ach to active window « cument window layout tore saved window layout tor-restore window layout eck for new version
Ĩ	Y	Move window to


DELL

Troubleshooting

If DDM does not work with your monitor, DDM will show the following icon in your notification tray.



Click on the icon, DDM shows a more detailed error message.



Please note that DDM only works with Dell-branded monitors. If you are using monitors from other manufacturers, DDM doesn't support them.

If DDM is unable to detect and/or communicate with a supported Dell monitor, please take the following actions to troubleshoot:

- 1. Make sure the video cable is properly connected to your monitor and your computer. especially the connectors should be firmly inserted into position.
- 2. Check the monitor OSD to ensure DDC/CI is enabled.
- **3.** Make sure you have the correct and latest graphics driver from the graphics vendor (Intel, AMD, NVidia, etc.). Graphics driver is often the cause of DDM failure.
- **4.** Remove any docking stations or cable extenders or converters between the monitor and the graphics port. Some low-cost extenders, hubs or converters may not support DDC/CI properly and can fail DDM. Update the driver of such device if the latest version is available.
- 5. Restart your computer.



DDM may not work with the following monitors:

- Dell monitor models earlier than year 2013 and D-series of Dell monitors. For more information see https://www.dell.com/support/monitors
- · Gaming monitors using Nvidia-based G-sync technology
- · Virtual and wireless monitors do not support DDC/CI
- Some early models of DP 1.2 monitors, it may be necessary to disable MST/DP 1.2 using the display OSD

If your PC is connected to the Internet, you will be prompted to upgrade to a newer version of DDM when it is available. It is recommended to download and install the latest DDM application.

You may also check for new version by right clicking on DDM icon.

	pen Dell Display Manager ttach to active window
	ive current window layout estore saved window layout
A	uto-restore window layout
C	heck for new version
Б	iit

Dell