






4



Register your product and get support at
www.philips.com/support



FAQ

Software
SmartControlUser
Manual

Version: M10243BQ1T

2021 © TOP Victory Investments Ltd. All rights reserved.

This product has been manufactured by and is sold under the responsibility of Top Victory Investments Ltd., and Top Victory Investments Ltd. is the warrantor in relation to this product. Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license.

Specifications are subject to change without notice.

HDMI

The terms HDMI, HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

www.philips.comEnergy Labelling
243B1

Printed in China



H41G78S281391C

PHILIPS





B Line

243B1




Quick Start


Register your product and get support at
www.philips.com/welcome




Power




*HDMI



*DP



*USB C-C



*USB C-A




*USB C-C/A


*Different according to region

Display design may differ from that illustrated



1



2





USB docking (USB C-C)




USB Type-C

USB A-C




USB Type-A

Multi-stream transport



3



SENSOR

PowerSensor - + Off



SmartImage
EasyRead
Office
Photo
Movie
Game
Economy
LowBlue Mode
Off



Input
HDMI 1.4
DisplayPort
USB C



PowerSensor
SmartImage
EasyRead
Office
Photo
Movie
Game
Economy
LowBlue Mode
Off

OK

PowerSensor
SmartImage
EasyRead
Office
Photo
Movie
Game
Economy
LowBlue Mode
Off



PowerSensor
SmartImage
EasyRead
Office
Photo
Movie
Game
Economy
LowBlue Mode
Off



PowerSensor
SmartImage
EasyRead
Office
Photo
Movie
Game
Economy
LowBlue Mode
Off