




4




MultiView	SUB SOURCE POSSIBILITY (x1)					
	Inputs	HDMI-1	HDMI-2	HDMI-3	DisplayPort	USB C1
MAIN SOURCE (x1)	HDMI-1	●	●	●	●	●
	HDMI-2	●	●	●	●	●
	HDMI-3	●	●	●	●	●
	DisplayPort	●	●	●	●	●
	USB C1	●	●	●	●	●

5



Register your product and get support at
www.philips.com/support



FAQ



Software SmartControl



User Manual

Version: M10439PQ1T

2021 © TOP Victory Investments Ltd. All rights reserved.

This product has been manufactured by and is sold under the responsibility of Top Victory Investments Ltd., and Top Victory Investments Ltd. is the warrantor in relation to this product. Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license.

Specifications are subject to change without notice.

HDMI

The terms HDMI, HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

www.philips.com

Energy Labelling

439P1



Printed in China



Q41G43M181327A

PHILIPS



Brilliance

439P1




Quick Start

Register your product and get support at
www.philips.com/welcome



*Remote Control
 Batteries AAA R03 1.5V



*USB A-B



Screw M4



*CD



Power




* HDMI




*DP



*USB C-C





*USB C-C/A




*RS232

* Different according to region.
 Display design may differ from those illustrated.


1



2



USB docking (USB C-C)



a

b

c

d

e

f

g

h

i

j

k

l

m

n

o

p

q

r

s

t

u

v

w

x

y

z

aa

ab

ac

ad

ae

af

ag

ah

ai

aj

ak

al

am

an

ao

ap

aq

ar

as

at

au

av

aw

ax

ay

az

ba

bb

bc

bd

be

bf

bg

bh

bi

bj

bk

bl

bm

bn

bo

bp

bq

br

bs

bt

bu

bv

bw

bx

by

bz

ca

cb

cc

cd

ce

cf

cg

ch

ci

cj

ck

cl

cm

cn

co

cp

cq

cr

cs

ct

cu

cv

cw

cx

cy

cz

da

db

dc

dd

de

df

dg

dh

di

dj

dk

dl

dm

dn

do

dp

dq

dr

ds

dt

du

dv

dw

dx

dy

dz

ea

eb

ec

ed

ee

ef

eg

eh

ei

ej

ek

el

em

en

eo

ep

eq

er

es

et

eu

ev

ew

ex

ey

ez

fa

fb

fc

fd

fe

ff

fg

fh

fi

fj

fk

fl

fm

fn

fo

fp

fq

fr

fs

ft

fu

fv

fw

fx

fy

fz

ga

gb

gc

gd

ge

gf

gg

gh

gi

gj

gk

gl

gm

gn

go

gp

gq

gr

gs

gt

gu

gv

gw

gx

gy

gz

ha

hb

hc

hd

he

hf

hg

hh

hi

hj

hk

hl

hm

hn

ho

hp

hq

hr

hs

ht

hu

hv

hw

hx

hy

hz

ia

ib

ic

id

ie

if

ig

ih

ii

ij

ik

il

im

in

io

ip

iq

ir

is

it

iu

iv

iw

ix

iy

iz

ja

jb

jc

jd

je

jf

jg

jh

ji

jj

jk

jl

jm

jn

jo

jp

jq

jr

js

jt

ju

jv

jw

jx

jy

jz

ka

kb

kc

kd