




4



5



Register your product and get support at
www.philips.com/support



FAQ

Software
SmartControlUser
Manual

Version: 34M2C7600MQ1T

2022 © TOP Victory Investments Ltd. All rights reserved.

This product has been manufactured by and is sold under the responsibility of Top Victory Investments Ltd., and Top Victory Investments Ltd. is the warrantor in relation to this product. Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license.

Specifications are subject to change without notice.

HDMI

The Adopted Trademarks HDMI, HDMI High Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. in the United States and other countries.

www.philips.comEnergy Labelling
34M2C7600MV

Printed in China



Q41G34M181315A

EVNIA




Quick start




34M2C7600MV

Register your product and get support at www.philips.com/welcome**PHILIPS**

Contents



VESA Bracket

Screw
M4 x 4


AC/DC Adapter




*HDMI



*DP




*USB A-B



*USB C-C




*USB C-A



*USB C-C/A


*Different according to region
 Display design may differ from that illustrated

1




CAUTION: Place the monitor face down on a smooth surface.
 Pay attention not to scratch or damage the screen.


2




USB C-C




USB A-C





USB hub



KVM



3



4

