




4



5



Register your product and get support at
www.philips.com/support



FAQ

Software
SmartControlUser
Manual

Version: M1279EQ1WWT
 2020 © TOP Victory Investments Ltd. All rights reserved.

This product has been manufactured by and is sold under the responsibility of Top Victory Investments Ltd., and Top Victory Investments Ltd. is the warrantor in relation to this product. Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license.

Specifications are subject to change without notice.

HDMI

The terms HDMI, HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

www.philips.com



Printed in China



H41G78S281393C

PHILIPS



E Line

279E1



Quick Start


Register your product and get support at
www.philips.com/welcome




AC/DC Adapter




* CD



* DP




* HDMI




*USB C-C

* Different according to region.
 Display design may differ from those illustrated.


1



2



2



3

