

Diagram 5 illustrates the following adjustments:

- Tilt Adjustment:** The monitor can be tilted back up to 20° , down to -5° , or rotated $+170^\circ$ and -170° .
- Height Adjustment:** The monitor can be raised or lowered by 180mm .
- Swivel Adjustment:** The monitor can be rotated horizontally. The diagram shows a vertical position (0°) and a horizontal position (90°).

Register your product and get support at
www.philips.com/welcome

Brilliance
328P6



Quick
Start

PHILIPS

The image displays a variety of accessories for the Philips monitor. At the top left is a blue icon of a box with an arrow pointing out, indicating the unboxing process. Below this, a line drawing of the monitor is shown on its stand. To the right of the monitor is a CD-ROM labeled 'Quick Start' and 'PHILIPS', which contains the 'Monitor User's Manual'. Below the monitor, a power cord is shown with the label '* Power Cord'. To the right of the power cord is an HDMI cable labeled '* HDMI'. Further right is an audio cable labeled '* Audio'. Below the power cord is a USB Type-C cable labeled '* USB Type-C'. To the right of the USB Type-C cable is a USB AC Adapter labeled '* USB AC Adapter'. Finally, at the bottom right is a VGA cable labeled '* VGA'. A note at the bottom states: '* Different according to region. Display design may differ from those illustrated.'

3

This diagram illustrates the various ports and connectivity options available on the monitor. At the top, a monitor is shown with a dashed box highlighting its rear panel. Below this, a central dashed box lists the ports: HDMI HDR, D-SUB, USB-C, SS-C (SuperSpeed USB-C), and AUDIO IN. Arrows indicate the following connections:

- HDMI HDR:** Connects to a laptop.
- D-SUB:** Connects to a monitor (indicated by a dashed line from the top monitor).
- USB-C:** Connects to a smartphone (labeled 'Fast Charger') and a USB-C hub.
- SS-C:** Connects to a USB-C hub.
- AUDIO IN:** Connects to headphones.
- USB-C Hub:** A central hub that also connects to an RJ-45 Ethernet port and a USB-A port.

Below the central dashed box, a detailed view of the monitor's rear panel shows the physical ports. A callout bubble labeled 'SS-C' points to the SuperSpeed USB-C port. Another callout bubble labeled 'USB-C' points to the standard USB-C port. The diagram shows the following connections:

- SS-C:** Connected to a keyboard.
- USB-C:** Connected to a mouse.
- USB-C Hub:** Connected to the monitor's USB-C port. This hub has two additional ports:
 - USB CC:** Connected to a laptop (labeled 'USB C' with a checkmark).
 - OR:** A secondary connection point for a 'USB AC Adapter' connected to another laptop (labeled 'USB C' with a checkmark).

4

Turn on the monitor.

Press the **Source** button on the monitor.

Select the input source (VGA, HDMI 2.0, DisplayPort, or USB C) from the menu.

Press the **Settings** button on the monitor.

Adjust the brightness using the slider.

The diagram illustrates the navigation sequence for the iReelBlue Main menu using four numbered steps:

- Step 1:** The menu is shown with the 'Input' option highlighted. A blue arrow points to the 'Input' option.
- Step 2:** The 'Picture' option is highlighted. A blue arrow points to the 'Picture' option.
- Step 3:** The 'Audio' option is highlighted. A blue arrow points to the 'Audio' option.
- Step 4:** The 'Color' option is highlighted. A blue arrow points to the 'Color' option.

The menu structure is as follows:

iReelBlue Main		Max	Off
Input			✓
Picture			
Audio			
Color			
Language			
+			