



4



Need help?

Online help: www.philips.com/support

需要帮助?

在线帮助: www.philips.com/support

Besoin d'Aide ?

Aide en ligne: www.philips.com/support

¿Necesita ayuda?

Ayuda en línea: www.philips.com/support

Benötigen Sie Hilfe?

Online-Hilfe: www.philips.com/support

Avete bisogno di aiuto?

Guida in linea: www.philips.com/support

Precisa ajuda?

Ajuda online: www.philips.com/support

도움이 필요하신가요?

온라인 도움말: www.philips.com/support

Потребуєте допомоги?

Підтримка он-лайн: www.philips.com/support

Нужна помощь?

Интерактивная справка:
www.philips.com/support

Yardıma ihtiyacınız var mı?

Online yardım: www.philips.com/support

क्या सहायता की जरूरत है?

ऑनलाइन सहायता: www.philips.com/support

هل تريد المساعدة؟

www.philips.com/support للمساعدة عبر الإنترنت

ヘルプが必要ですか?

オンラインヘルプ: www.philips.com/support

Version: M72XXBJQ1L

© 2016 Koninklijke Philips N.V. All rights reserved.

This product was manufactured and brought to the market by or on behalf of Top Victory Investments Ltd. or one of its affiliates. Top Victory Investments Ltd. is the warrantor in relation to this product. Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. used under license.

Specifications are subject to change without notice.
www.philips.com

HDMI

HDMI trademark and related patents on technologies belong to their respective owners.



Printed in China



F41G24M181321A----




Register your product and get support at
www.philips.com/welcome

Brilliance
221B7/231B7
240B7/241B7




Quick Start


PHILIPS




*CD



Power




*Audio




*DP



*VGA



*USB
(2X1B7QPJKEB)




*HDMI
(231B7QPJEB/
231B7QPJKEB)



*Different according to region

Display design may differ from that illustrated


1



2



3



OK

Left arrow

Right arrow

Power button

