
# **Dell Display Manager User's Guide**

#### Overview

Dell Display Manager is a Windows application used to manage a monitor or a group of monitors. It allows manual adjustment of the displayed image, assignment of automatic settings, energy management, image rotation and other features on select Dell models. Once installed, Dell Display Manager will run each time the system starts and will place its icon in the notification tray. Information about monitors connected to the system is always available when hovering over the notification tray icon.



**NOTE:** Dell Display Manager needs to use DDC/CI channel to communicate with your monitor. Please make sure DDC/CI is enabled in the menu as below.







# Using the Quick Settings Dialog

Clicking Dell Display Manager's notification tray icon opens the Quick Settings dialog box. When more than one supported Dell model is connected to the system, a specific target monitor can be selected using the menu provided. The Quick Settings dialog box allows convenient adjustment of the monitor's Brightness and Contrast levels, Preset Modes can be manually selected or set to Auto Mode, and the screen resolution can be changed.

Display	/ Manager	*
Display:	Del P3439-W	
Resolution:	1920x1080	Chance
Auto Mode		Configure
Manual Mode	(	Standard •
Brightnessi		35%
Contrasti		75%
<b>X</b>		
T		
	Open Dell Display Man	agar

The Quick Settings dialog box also provides access to Dell Display Manager's advanced user interface which is used to adjust Basic functions, configure Auto Mode and access other features.



#### **Setting Basic Display Functions**

A Preset Mode for the selected monitor can be manually applied using the menu on the Basic tab. Alternatively, Auto Mode can be enabled. Auto Mode causes your preferred Preset Mode to be applied automatically when specific applications are active. An onscreen message momentarily displays the current Preset Mode whenever it changes.

The selected monitor's Brightness and Contrast can also be directly adjusted from the Basic tab.

Elesic	Auto Mode	Easy Arrange	Input Manager	Options	
Resolutions	1920v0	200			Change
-3191 M 214 M		for active applications			Configurat
Manual Mod Choose a pr	le reset made:		Sta	ndard	•
Brightnesst	Ťer s	Ū	35%		
Contrast:	1.11	0	75%		



#### **Assigning Preset Modes to Applications**

The Auto Mode tab allows you to associate a specific Preset Mode with a specific application, and apply it automatically. When Auto Mode is enabled, Dell Display Manager will automatically switch to the corresponding Preset Mode whenever the associated application is activated. The Preset Mode assigned to a particular application may be the same on each connected monitor, or it can vary from one monitor to the next.

Dell Display Manager is pre-configured for many popular applications. To add a new application to the assignment list, simply drag the application from the desktop, Windows Start Menu or elsewhere, and drop it onto the current list.

**NOTE:** Preset Mode assignments targeting batch files, scripts, and loaders, as well as non-executable files such as zip archives or packed files, are not supported and will be ineffective.

Basic	ac Auto Mode Easy Ar		Input Manager	Options		1
Assign a pres	et mode to a specific a	application. To add a	en application, drag it t	o the list		
Application	oplication		et Mode			
(Defai	It for desktop apps)	Sta	Standard 💌			
(Default for fullscreen games)		s) Gar	Game 🔫			
P Adobe	Adobe Photoshop CS6		Standard 🔫			
Adobe	Adobe Premiere Pro CS6		Standard 🔻			
Rivefor	Mareton .		Standard 🔫		eniove	-



#### Easy Arrange Your Monitor Window Layout

On supported Dell monitors, the Easy Arrange tab allows you to easily arrange the open windows in one of the predefined layouts by dragging them in the zones. To create a custom layout, arrange the open windows and then click Save.



#### **Managing Multiple Video Inputs**

The Input Manager tab provides convenient ways for you to manage multiple video inputs connected to your Dell monitor. It makes it very easy to switch between inputs while you work with multiple computers.

All video input ports available to your monitor are listed. You can give each input a name as you like. Please save your changes after editing.

You can define a shortcut key to quickly switch to your favorite input and another shortcut key to quickly switch between two inputs if you often work between them.

Bosic Auto M	de Basy Arrange	Input Managor	Options
Imput port:	Input name:		
DP	(Click to edit)		
n02	(Click to edit)		
HOMEL	(Click to edit)		
HDME2 (Active)	(Click to edit)		
PIP/PEP mode		1	Save
evarite input shartcut keys			
None	>> []]2	•	Change active input

You can use the dropdown list to swtich to any input source.

Basic	Automode	basy Avance	Input Manager	Options	
input ports	10	putname			
00	0	ide to edit)			
ND2	(0	hick to ad ()			
-040	(0	lid: to editj			
HDHE2 (Active)	0	lick to edit()			
- প্রচ/বচৎ	node			Sive	
Pavorite input sho					
'awarite input sha None	rteut key: >> [	P	•	Change active inpo	ut

**NOTE:** DDM communicates with your monitor even when the monitor is displaying video from another computer. You can install DDM on the PC you frequently use and control input switching from it. You may also install DDM on other PCs connected to the monitor.

Click the **PIP/PBP mode** selection button to select a **PIP/PBP** configuration.



You can adjust the **PIP/PBP (Picture in Picture/Picture by Picture)** from Off to **PIP Small, PIP Large, or PBP Fill.** 

Sec.	A de Moste	Res James	Input Hereocr	Quinn
Department is		police on		
CPF	7	litik in oddj		
-01	0	line to exist		
HEH?)	4	lick to edit		
HD/20ebo	4	lok si eoʻs		
Roado -	ode .			low
wers inscribed	aties:			
tore .	20 1		-	Mangel ACtive read-

You can select video inputs for your main window and sub window. Please save your change after your selection. You can define a shortcut key to quickly swap the video inputs between main window and sub window.

Click Video swap button or use the defined Video swap shortcut key to swap the video inputs between main window and sub window.

Vec 9,2 Ma	ter here any	a hysel Marvager	Cp Son
Jun. 1 post	Jack Change		
99	(cida to edd)		
m02	(cisk to sale)		
i Di Ca	(cish to sald)		
0/2	(Child to will)		
All Mill model .			fee:
en winder #1:	Sib ender e	2	CO twich the factories
K1M1:	- 4040	-	Norm
de minders #7	0 is sincher 4	**	Rice any shortest logs



### **Applying Energy Conservation Features**

On supported Dell models, the Options tab will be available to provide PowerNap energy conservation options. When the screensaver activates, the monitor's Brightness can automatically be set to minimum level or the monitor can be put to sleep in order to save additional power.






# Troubleshooting

If DDM cannot work with your monitor, DDM will show below icon in your notification tray.



Click on the icon, DDM shows a more detailed error message.



Please note that DDM only works with Dell-branded monitors. DDM does not support monitors from other manufacturers.

If DDM is unable to detect and/or communicate with a supported Dell monitor, please take below actions to troubleshoot:

- **1.** Make sure the video cable is properly connected to your monitor and your PC: especially the connectors should be firmly inserted into position.
- 2. Check the monitor OSD to ensure DDC/CI is enabled.
- **3.** Make sure you have the correct and latest display driver from the graphics vendor (Intel, AMD, NVidia, etc.). Display driver is often the cause of DDM failure.
- 4. Remove any docking stations or cable extenders or converters between the monitor and the graphics port. Some low-cost extenders, hubs or converters may not support DDC/CI properly and can fail DDM. Update the driver of such device if the latest version is available.
- 5. Restart your system.

DDM may not work with below monitors:

- Dell monitor models earlier than year 2013 and D-series of Dell monitors. You can refer to Dell Product Support websites for more information
- Gaming monitors using Nvidia-based G-sync technology
- · Virtual and wireless displays do not support DDC/CI
- In some early models of DP 1.2 monitors, it may be necessary to disable MST/DP 1.2 using the monitor OSD



If your PC is connected to the Internet, you will be prompted with a message when a newer version of DDM application is available. It is recommended to download and install the latest DDM application.

You may also check for new version by right clicking on DDM icon while pressing and holding 'shift' key.

