


User Guide





First Edition
March 2022

Copyright © 2022 ASUSTeK COMPUTER INC. All Rights Reserved.

No part of this manual, including the products and software described in it, may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purposes, without the express written permission of ASUSTEK COMPUTER INC. ("ASUS").

Product warranty or service will not be extended if: (1) the product is repaired, modified or altered, unless such repair, modification of alteration is authorized in writing by ASUS; or (2) the serial number of the product is defaced or missing.

ASUS PROVIDES THIS MANUAL "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL ASUS, ITS DIRECTORS, OFFICERS, EMPLOYEES OR AGENTS BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES (INCLUDING DAMAGES FOR LOSS OF PROFITS, LOSS OF BUSINESS, LOSS OF USE OR DATA, INTERRUPTION OF BUSINESS AND THE LIKE), EVEN IF ASUS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES ARISING FROM ANY DEFECT OR ERROR IN THIS MANUAL OR PRODUCT.

SPECIFICATIONS AND INFORMATION CONTAINED IN THIS MANUAL ARE FURNISHED FOR INFORMATIONAL USE ONLY, AND ARE SUBJECT TO CHANGE AT ANY TIME WITHOUT NOTICE, AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY ASUS. ASUS ASSUMES NO RESPONSIBILITY OR LIABILITY FOR ANY ERRORS OR INACCURACIES THAT MAY APPEAR IN THIS MANUAL, INCLUDING THE PRODUCTS AND SOFTWARE DESCRIBED IN IT.

Products and corporate names appearing in this manual may or may not be registered trademarks or copyrights of their respective companies, and are used only for identification or explanation and to the owners' benefit, without intent to infringe.

Contents

Notic	es		iv			
Safet	y inform	nation	ν			
Care	& Clean	ing	v i			
Take	back Se	rvices	vii			
Prod	uct infor	rmation for EU energy label	vii			
Chap	oter 1:	Product introduction				
1.1	Welco	ome!	1-1			
1.2	Package contents					
1.3	Monit	or introduction	1-2			
	1.3.1	Front view	1-2			
	1.3.2	Back view	1-4			
	1.3.3	QuickFit Plus Function	1-5			
	1.3.4	Other Function(s)	1-7			
	1.3.5	Color Calibration	1-8			
Chap	oter 2:	Setup				
2.1	Adjus	sting the mini stands	2-1			
2.2	Attacl	hing the stand (arm/base)	2-2			
2.3	Detac	hing the stand (for VESA wall mount)	2-3			
2.4	Instal	ling the monitor hood	2-4			
2.5	Instal	ling the cable clips	2-6			
2.6	Adjus	Adjusting the monitor2-7				
2.7	Conn	Connecting the cables2-9				
2.8	Turnii	ng on the monitor	2-10			
Chap	oter 3:	General instructions				
3.1	OSD ((On-Screen Display) menu	3-1			
	3.1.1	How to reconfigure	3-1			
	3.1.2	OSD function introduction	3-2			
3.2	Speci	fications Summary	3-14			
3.3	Outlin	ne dimensions	3-16			
3.4	Troub	Troubleshooting (FAQ)3-19				
3.5	Supp	Supported operating modes				

Notices

Federal Communications Commission Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with manufacturer's instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the
 receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



The use of shielded cables for connection of the monitor to the graphics card is required to assure compliance with FCC regulations. Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Canadian Department of Communications Statement

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

This class B digital apparatus complies with Canadian ICES-003.

This Class B digital apparatus meets all requirements of the Canadian Interference - Causing Equipment Regulations.

Cet appareil numérique de la classe B respecte toutes les exigences du Réglement sur le matériel brouiller du Canada.

Safety information

- Before setting up the monitor, carefully read all the documentation that came with the package.
- To prevent fire or shock hazard, never expose the monitor to rain or moisture.
- Never try to open the monitor cabinet. The dangerous high voltages inside the monitor may result in serious physical injury.
- If the power supply is broken, do not try to fix it by yourself. Contact a qualified service technician or your retailer.
- Before using the product, make sure all cables are correctly connected and the power cables are not damaged. If you detect any damage, contact your dealer immediately.
- Slots and openings on the back or top of the cabinet are provided for ventilation.
 Do not block these slots. Never place this product near or over a radiator or heat source unless proper ventilation is provided.
- The monitor should be operated only from the type of power source indicated on the label. If you are not sure of the type of power supply to your home, consult your dealer or local power company.
- Use the appropriate power plug which complies with your local power standard.
- Do not overload power strips and extention cords. Overloading can result in fire or electric shock.
- Avoid dust, humidity, and temperature extremes. Do not place the monitor in any area where it may become wet. Place the monitor on a stable surface.
- Unplug the unit during a lightning storm or if it will not be used for a long period of time. This will protect the monitor from damage due to power surges.
- Never push objects or spill liquid of any kind into the slots on the monitor cabinet.
- To ensure satisfactory operation, use the monitor only with UL listed computers which have appropriate configured receptacles marked between 100-240V AC.
- If you encounter technical problems with the monitor, contact a qualified service technician or your retailer.
- Adjustment of the volume control as well as the equalizer to other settings than the center position may increase the ear-/headphones output voltage and therefore the sound pressure level.



This symbol of the crossed out wheeled bin indicates that the product (electrical, electronic equipment, and mercury-containing button cell battery) should not be placed in municipal waste. Please check local regulations for disposal of electronic products.

AEEE yönetmeliğine uygundur

Care & Cleaning

- Before you lift or reposition your monitor, it is better to disconnect the cables and power cord. Follow the correct lifting techniques when positioning the monitor. When lifting or carrying the monitor, grasp the edges of the monitor. Do not lift the display by the stand or the cord.
- Cleaning. Turn your monitor off and unplug the power cord. Clean the monitor surface with a lint-free, non-abrasive cloth. Stubborn stains may be removed with a cloth dampened with mild cleaner.
- Avoid using a cleaner containing alcohol or acetone. Use a cleaner intended for use with the OLED. Never spray cleaner directly on the screen, as it may drip inside the monitor and cause an electric shock.

The following symptoms are normal with the monitor:

- You may find slightly uneven brightness on the screen depending on the desktop pattern you use.
- When the same image is displayed for hours, an afterimage of the previous screen may remain after switching the image. The screen will recover slowly or you can turn off the Power Switch for hours.
- When the screen becomes black or flashes, or cannot work anymore, contact your dealer or service center to fix it. Do not repair the screen by yourself!

Conventions used in this guide



WARNING: Information to prevent injury to yourself when trying to complete a task.



CAUTION: Information to prevent damage to the components when trying to complete a task.



IMPORTANT: Information that you MUST follow to complete a task.



NOTE: Tips and additional information to aid in completing a task.

Where to find more information

Refer to the following sources for additional information and for product and software updates.

1. ASUS websites

The ASUS websites worldwide provide updated information on ASUS hardware and software products. Refer to http://www.asus.com

2. Optional documentation

Your product package may include optional documentation that may have been added by your dealer. These documents are not part of the standard package.

Takeback Services

ASUS recycling and takeback programs come from our commitment to the highest standards for protecting our environment. We believe in providing solutions for our customers to be able to responsibly recycle our products, batteries and other components as well as the packaging materials.

Please go to http://csr.asus.com/english/Takeback.htm for detail recycling information in different region.

Product information for EU energy label



1.1 Welcome!

Thank you for purchasing the ASUS® OLED monitor!

The latest widescreen OLED monitor from ASUS provides a crisper, broader, and brighter display, plus a host of features that enhance your viewing experience.

With these features, you can enjoy the convenience and delightful visual experience that the monitor brings to you!

1.2 Package contents

Check your package for the following items:


- ✓ OLED monitor
- ✓ Stand
- ✓ Cable clips
- ✓ Calibration report
- ✓ Quick start guide
- ✓ Warranty card
- ✓ Power cord
- ✓ HDMI cable
- ✓ DisplayPort cable
- ✓ USB Type-C cable
- ✓ USB Type-C to Type-A cable
- ✓ Hood



If any of the above items is damaged or missing, contact your retailer immediately.

1.3 Monitor introduction

1.3.1 Front view



- 1. E Menu (5-way) button:
 - Enter the OSD menu
 - Enact the selected OSD menu items
 - Increase/Decrease values or move your selection up/down/left/right.
- 2. Close button:
 - Exit the OSD menu.
 - Toggle the Key Lock function between on and off with a long press for 5 seconds.
- 3. Input Select button:
 - Smart switch to the next existed input source.
- - This is a hotkey to activate the QuickFit Plus function designed for alignment.
 - The QuickFit Plus function contains 4 types of alignment patterns. (Please refer to 1.3.3 QuickFit Plus Function).

- 5. Self Calibration Button:
 - Perform standalone calibration to ensure color accuracy every working period.
- 6. Shortcut 1
 - Default: HDR hotkey
 - To change the hotkey function, go to the Shortcut > Shortcut 1 menu.
- 7. Shortcut 2
 - Default: ProArt Preset hotkey
 - To change the hotkey function, go to the Shortcut > Shortcut 2 menu.
- 8. **b** Power Button/Power Indicator:
 - Turn the monitor on/off.
 - The color definition of the power indicator is as the below table.

Status	Description
White	ON
Amber	Standby mode
OFF	OFF


- 9. Proximity sensor
 - If the function is enabled and the system does not detect the presence of object within 30cm~1.5m over the preset time, the system will automatically decrease brightness periodically.



Recovery time would be within 2 seconds.

To configure the setting, go to the System Setup > Proximity Sensor menu.

1.3.2 Back view



- 1. **Earphone jack**: This port connects to an earphone.
- 2. **HDMI ports**: These ports are for connection with an HDMI compatible device.
- DisplayPort in: This port is for connection with a DisplayPort compatible device.



The default setting of DisplayPort Stream in the OSD menu is DisplayPort 1.4. You can change it to DisplayPort 1.1 when your device output signal is DisplayPort 1.1.

- 4. **Power switch**: Press the switch to turn on/off power.
- 5. **AC-IN port**: This port connects the power cord.
- USB 3.2 Type-C: This port is for connection with a DisplayPort/USB Type-C
 compatible device. This port is also for connection with a USB upstream
 cable, which supports USB power and data delivery.



This monitor is Super-Speed USB 3.2 Gen 2 compatible (10 Gbps). The port offers 5V/3A, 9V/3A, 12V/3A, 15V/3A, and 20V/3.25A power delivery.

 USB 3.2 Gen 2 Type-A (SuperSpeed USB 10Gbps): These ports are for connection with USB devices, such as USB keyboard/mouse, USB flash drive, etc.



- The top USB port supports BC 1.2.
- The bottom USB port supports FW upgrade.
- Kensington lock slot: This port connects a lock-and-cable apparatus for security purposes.

1.3.3 QuickFit Plus Function


The QuickFit Plus function contains 4 types of patterns: (1) Safe Area (2) Center Marker (3) Customization (4) Ruler. To activate the patterns, press the QuickFit Plus button. Use the Menu (5-way) button to select a desired pattern. You can move the button up/down/left/right to change the pattern's position if needed.

Note that only **Customization** pattern can be adjusted its frame size according to your need, but may have limited range for moving left/right/up/down.

1. Safe Area

Facilitates designers and users to organize content and layout on one page and achieve a consistent look and feel.


The selections are:



2. Center Marker

Selects the center marker type.

The selections are:



3. Customization

You can decide the frame size by moving the Menu (5-way) button up/down/ left/right. You can press the Menu (5-way) button for longer than 3 seconds to switch the measurements between millimeter and inch.



4. Ruler

This pattern presents physical ruler on top and left side. You can press the Menu (5-way) button for longer than 3 seconds to switch the measurements between metric and imperial.



1.3.4 Other Function(s)

1. HDR

The monitor supports HDR format. When detecting HDR content, an "HDR ON" message will pop up and display the Information page.




HDR content is not supported when the PIP/PBP mode is on.

1.3.5 Color Calibration


Users can use the ProArt tool with the color sensor that is embedded on the top of the monitor for color calibration. Ensure that the protective film on the color sensor has been removed before using the color sensor for calibration.

 Open the ProArt tool to activate the color sensor to perform the color calibration.

The color sensor starts moving from its original position towards the screen.



When the color sensor reaches the edge of the screen, it will stop and start the calibration process. The calibration time depends on the amount of preset modes you select, the longest time might be 30 minutes.



 After the calibration process is completed, the color sensor will automatically return to its original position.




- When the device is turned on, the color sensor will return to its original position and produce a sound while the motor is running during the initialization process. This is a normal.
- When the hood is installed, the color sensor can also be used.
- · Avoid pulling the color sensor to prevent damage.
- To ensure ProArt tool to perform the calibration smoothly, do not touch the color sensor with your hands and there are no interfering objects during the process.

1-8

2.1 Adjusting the mini stands

To adjust the mini stands:

- Carefully take the monitor out of the box. Hold the monitor firmly and do not press on the panel screen when lifting to avoid any accidental damage (Figure 1).
- 2. Have the front of the monitor face down on a table (Figure 2).
- 3. Rotate the mini stands by 90 degrees away from the bottom of the monitor (Figure 3).






- We recommend that you cover the table surface with soft cloth to prevent damage to the monitor.
- When the panel screen is facing down, be careful not to damage the Menu (5-way) button.

2.2 Attaching the stand (arm/base)

To assemble the stand:

- Carefully take the monitor out of the box. Hold the monitor firmly and do not press on the panel screen when lifting to avoid any accidental damage (Figure 1).
- 2. Have the front of the monitor face down on a table. Then using a paperclip (or similar item), remove the rubbers covering the screw holes (Figure 2).
- 3. Install the arm and secure it using the screws (Figure 3).
- 4. Attach the base to the arm. Then lift the screw ring and turn it clockwise to secure the base in place (Figure 4).





- We recommend that you cover the table surface with soft cloth to prevent damage to the monitor.
- When the panel screen is facing down, be careful not to damage the Menu (5-way) button.


2-2 Chapter 2: Setup

2.3 Detaching the stand (for VESA wall mount)

The detachable stand of this monitor is specially designed for VESA wall mount.

To detach the stand:

- 1. Have the front of the monitor face down on a table.
- 2. Remove the screws securing the stand to the monitor. Then remove the stand (Figure 1).





- We recommend that you cover the table surface with soft cloth to prevent damage to the monitor.
- When the panel screen is facing down, be careful not to damage the
 Menu (5-way) button.



- The VESA wall mount kit (100 x 100 mm) is purchased separately.
- Use only the UL Listed Wall Mount Bracket with minimum weight/load 22.7kg (Screw size: M4 x 12 mm).


2.4 Installing the monitor hood

You can install the monitor hood to reduce glare or reflection.

To install the monitor hood:

- 1. By aligning the embedded screws on the side cover with the side screw holes, lift the hood side cover fully upward, and hold it into place. Then secure the side cover by partial tighten the screws to fix its position. Repeat the same step to install another side cover (Figure 1).
- 2. Remove the rubbers securing the top screw holes (Figure 1).
- 3. Slide the hood top cover until it fully engaged with the upper side latches (Figure 2).
- Slightly loosen the embedded screws on the side cover. Then carefully push
 the hood assembly downward. Press the rear edges of the top cover firmly
 until the latches are fully engaged (Figure 3).
- 5. Secure the hood assembly with the screws (Figure 4).

2-4 Chapter 2: Setup



2.5 Installing the cable clips

Use the cable clips to manage the connected cables.


To install the cable clips:

- Using a paperclip (or similar item), remove the rubbers covering the screw holes (Figure 1).
- 2. By aligning the screw hole (marked by blue line) and the guide pin (marked by the pink line) of the cable clip with the screw holes, install the clip to its designated location on the rear of the monitor. Then secure the cable clip with the screw (Figure 2).

Repeat the same steps to install other cable clips.




- Make sure the guide pin is installed into the screw hole closer to the edge of the monitor.
- The cable clip is divided into two sides (left and right).
- 3. Route the connected cables through the installed cable clips (Figure 3).



2-6 Chapter 2: Setup


2.6 Adjusting the monitor

- For optimal viewing, we recommend that you look at the full face of the monitor, then adjust the monitor to the angle that is most comfortable for you.
- Hold the stand to prevent the monitor from falling when you change its angle.
- You can adjust the monitor's angle from -5°~+23°, and it allows 30° swivel adjustment from either left or right. You can also adjust the monitor's height within 130 mm.



Pivoting the monitor


- 1. Lift the monitor to the highest position.
- 2. Tilt the monitor to its maximum angle.
- 3. Pivot the monitor to the angle you need.





It is normal that the monitor slightly shakes while you adjust the viewing angle.


4. The OSD menu item will automatically rotate when the monitor rotates.



2-8 Chapter 2: Setup

2.7 Connecting the cables

Connect the cables according to the following instructions:



- **To connect the power cord:** Connect one end of the power cord securely to the monitor's AC input port, the other end to a power outlet.
- To connect the HDMI/DisplayPort/USB Type-C/USB Type-A cable:
 - a. Plug one end of the HDMI/DisplayPort/USB Type-C/USB Type-A cable to the monitor's HDMI/DisplayPort/USB Type-C/USB Type-A jack.
 - b. Connect the other end of the HDMI/DisplayPort/USB Type-C* cable to your device's HDMI/DisplayPort/USB Type-C jack.



It is suggested to use USB certified Type-C 4K/ support 3.25A (or up to 3.25A) cable. If the signal source supports DP Alt mode, all video, audio and data signal can be transmitted.


- To use the earphone: Connect the end with plug type to the monitor's earphone jack when an HDMI/DisplayPort/USB Type-C signal is fed.
- To use the USB upstream/downstream function:
 - » Upstream: Use an USB Type-C cable and plug on end of the Type-C connector to the monitor's USB 3.2 Type-C port as upstream and the other end to your computer's USB Type-C port. Or use an USB Type-C to Type-A cable, plug the Type-C connector to the the monitor's USB 3.2 Type-C port as upstream and the Type-A connector to your computer's USB Type-A port. Make sure your computer is installed with the latest Windows 10/11 operating system. That will enable the USB ports on the monitor to work.
 - » Downstream: Use an USB cable to connect your device with the monitor's USB Type-A port.



When these cables are connected, you can choose the desired signal from the Input Select item in the OSD menu.

2.8 Turning on the monitor

Set the AC switch to ON position (A), and then press the $\boldsymbol{\upsilon}$ button (B). See page 1-3 for the location of the Power button. The power indicator lights up in white to show that the monitor is ON.



2-10 Chapter 2: Setup

3.1 OSD (On-Screen Display) menu

3.1.1 How to reconfigure






- 1. Press the Menu (5-way) button to activate the OSD menu.
- 2. Move the Menu (5-way) button up/down/left/right to navigate through the functions. Highlight the desired function and press the Menu (5-way) button to activate it. If the function selected has a sub-menu, move the Menu (5-way) button up/down to navigate through the sub-menu functions. Highlight the desired sub-menu function and press the Menu (5-way) button or move the Menu (5-way) button to activate it.
- 3. Move the Menu (5-way) button up/down to change the settings of the selected function.
- To exit and save the OSD menu, press the Close button or move the Menu (5-way) left repeatedly until the OSD menu disappears.
 To adjust other functions, repeat steps 1-3.

3.1.2 OSD function introduction

1. ProArt Preset

This function contains 14 sub-functions you can select for your preference. Each mode has the Reset selection, allowing you to maintain your setting or return to the preset mode.





- Standard Mode: Best choice for document editing.
- sRGB Mode: Compatible with sRGB color space, sRGB is the best choice for web browsing.
- Adobe RGB Mode: Compatible with Adobe RGB color space.
- Rec. 2020 Mode: Compatible with Rec. 2020 color space.
- DCI-P3 Mode: Compatible with DCI-P3 color space.
- DICOM Mode: Compliant with DICOM standard, best choice for medical image checking.
- Rec. 709 Mode: Compatible with Rec. 709 color space.
- HDR_PQ DCI: Presents ST2084 with DCI-P3 color gamut and D65 white point.
 - » PQ Optimized: Delivers the optimized HDR performance of this display with as much accuracy as with ST2084 in terms of display luminance capability.
 - » PQ Clip: Preserves PQ curve till displaying maximum luminance with accuracy. ST2084 code value with higher than display maximum will be mapped to the maximum luminance.
 - » PQ Basic: Presents HDR performance of general HDR supported displays.

- HDR_PQ Rec2020: Presents ST2084 with Rec.2020 color gamut and D65 white point.
 - » PQ Optimized: Delivers the optimized HDR performance of this display with as much accuracy as with ST2084 in terms of display luminance capability.
 - » PQ Clip: Preserves PQ curve till displaying maximum luminance with accuracy. ST2084 code value with higher than display maximum will be mapped to the maximum luminance.
 - » PQ Basic: Presents HDR performance of general HDR supported displays.
- HDR_HLG BT2100: Compliant with BT2100.
- HDR_HLG DCI: Compliant with DCI-P3.
- HDR_DolbyVision: Selects the DolbyVision lighting type.
 - » Bright: Compliant with DolbyVision Bright mode settings.
 - » Dark: Compliant with DolbyVision Dark mode settings.
- User Mode 1/User Mode 2: You can save one or two ProArt Calibration profiles as User Mode 1/User Mode 2 after executing ProArt Calibration and then have quick access here.



Please apply the following settings while performing ProArt color calibration:

- Set output dynamic to full range.
- Set output color format to RGB.
- Set output color depth to 8 bit.

Below tables show the default configurations for each ProArt Preset mode:

Function	Standard	sRGB	AdobeRGB	Rec 709
Color Temp.	6500K	Fixed (6500K)	Fixed (6500K)	6500K
Brightness	50	Fixed 80nits	160nits	100nits
Contrast	80	80	80	80
Sharpness	Enable (0)	Enable (0)	Enable (0)	Enable (0)
Saturation	Middle (50)	Disable	Middle (50)	Middle (50)
Hue	Middle (50)	Disable	Middle (50)	Middle (50)
ProArt Pallette/ Color	Enable (default)	Disable	Enable (default)	Enable (default)
Black Level	Enable (default)	Enable (default)	Enable (default)	Enable (default)
Gamma	Enable (2.2)	Fixed (2.2)	Fixed (2.2)	Enable (2.4)
Light Effect	Enable (default)	Disable	Enable (default)	Enable (default)
Adaptive Color	Enable (default)	Disable	Disable	Enable (default)
Uniform Brightness	Enable (default: Off)	Disable (On)	Enable (default: On)	Enable (default: On)

Function	DCI-P3	Rec 2020	DICOM	HDR_PQ DCI
Color Temp.	P3-Theater	6500K	6500K	Fixed (6500K)
Brightness	48nits	100nits	80	250nits/Max
Contrast	80	80	80	Disable
Sharpness	Enable (0)	Enable (0)	Enable (0)	Enable (0)
Saturation	Middle (50)	Middle (50)	Middle (50)	Disable
Hue	Middle (50)	Middle (50)	Middle (50)	Disable
ProArt Pallette/ Color	Enable (default)	Enable (default)	Enable (default)	Enable (RGB Gain only)
Black Level	Enable (default)	Enable (default)	Enable (default)	Enable (default)
Gamma	Enable (2.2/2.6 only)	Enable (2.4)	Disable	Disable
Light Effect	Enable (default)	Enable (default)	Enable (default)	Disable
Adaptive Color	Enable (default)	Enable (default)	Enable (default)	Disable
Uniform Brightness	Enable (default: On)	Enable (default: On)	Enable (default: On)	Enable (default: Off)

Function	HDR_PQ Rec2020	HDR_HLG BT2100	HDR_HLG DCI	HDR_DolbyVision
Color Temp.	Fixed (6500K)	Fixed (6500K)	Fixed (6500K)	Fixed (6500K)
Brightness	250nits/Max	250nits/Max	250nits/Max	250nits/Max
Contrast	Disable	Disable	Disable	Disable
Sharpness	Enable (0)	Enable (0)	Enable (0)	Disable
Saturation	Disable	Disable	Disable	Disable
Hue	Disable	Disable	Disable	Disable
ProArt Pallette/ Color	Enable (RGB Gain only)	Enable (RGB Gain only)	Enable (RGB Gain only)	Disable
Black Level	Enable (default)	Enable (default)	Enable (default)	Enable (default)
Gamma	Disable	Disable	Disable	Disable
Light Effect	Disable	Disable	Disable	Disable
Adaptive Color	Disable	Disable	Disable	Disable
Uniform Brightness	Enable (default: Off)	Enable (default: On)	Enable (default: On)	Enable (default: Off)


Function	User Mode 1	User Mode 2
Color Temp.	Fixed (6500K)	Fixed (6500K)
Brightness	50	50
Contrast	80	80
Sharpness	Enable (0)	Enable (0)
Saturation	Middle (50)	Middle (50)
Hue	Middle (50)	Middle (50)
ProArt Pallette/ Color	Enable (RGB Gain only)	Enable (RGB Gain only)
Black Level	Enable (default)	Enable (default)
Gamma	Fixed (2.2)	Fixed (2.2)
Light Effect	Disable	Disable
Adaptive Color	Disable	Disable
Uniform Brightness	Disable (default: On)	Disable (default: On)

2. ProArt Palette

Set a desired color setting from this menu.



To activate this function, you need to disable the Ambient Effect function.





Brightness: The adjusting range is from 0 to 100.



When the HDR function is enabled, the maximum brightness level is automatically set to 500nits as default.

- **Contrast**: The adjusting range is from 0 to 100.
- **Saturation**: The adjusting range is from 0 to 100.
- Hue: Shifts the image color between green and purple.
- Color Temp.: Contains 5 modes including 9300K, 6500K, 5500K, 5000K, and P3-Theater.




When the ProArt Preset setting is set to DCI-P3 Mode, only 6500K and P3-Theater options are available.

- Gamma: Allows you to set the color mode to 1.8, 2.0, 2.2, 2.4, or 2.6.
- Color: Configures the color settings.
 - » Six-axis Hue: Adjusts the six-axis hue settings for the red, green, blue, cyan, magenta, or yellow color.
 - » Six-axis Saturation: Adjusts the six-axis saturation settings for the red, green, blue, cyan, magenta, or yellow color.
 - » Gain: Adjusts the gain levels for the red, green, or blue color.
 - » Offset: Adjusts the black level offset values for the red, green, or blue color.
- Black Level: Adjusts the initialized 1st signal level of darkest gray level.

- Color Reset: Resets the color related settings.
 - » Current mode color reset: Resets the color settings of the current color mode to the factory default value.
 - » All modes color reset:
 Resets the color settings of all color modes to the factory default value.

3. Image

Set the image related setting from this menu.





- **Sharpness**: The adjusting range is from 0 to 100.
- **Aspect Control**: Adjusts the aspect ratio to Full, 4:3, 1:1, or OverScan.



- To activate this function, you need to do the following: turn off the PBP mode.
- 4:3 is only available when input source is in 4:3 format. OverScan is only available for the HDMI input source.
- Input Range: Adjusts the input range to Auto, Full, Limited 16-235, or Limited 16-254.
- Blue Light Filter: Adjusts the blue light filter level.
 - » Level 0: No change.
 - » Level 1~4: The higher the level, the less blue light is scattered. When Blue Light Filter is activated, the default settings of Standard Mode will be automatically imported. Between Level 1 to Level 3, the Brightness function is user-configurable. Level 4 is optimized setting. It is compliance with TUV Low Blue Light Certification. The Brightness function is not user-configurable.

3-6 Chapter 3: General Instruction



Please refer to the following to alleviate eye strains:

- Users should take some time away from the display if working for long hours. It is advised to take short breaks (at least 5 mins) after around 1 hour of continuous working at the computer. Taking short and frequent breaks is more effective than a single longer break.
- To minimize eye strain and dryness in your eyes, users should rest the eye periodically by focusing on objects that are far away.
- Eye exercises can help to reduce eye strain. Repeat these exercises
 often. If eye strain continues please consult a physician. Eye
 exercises: (1) Repeating look up and down (2) Slowly roll your eyes
 (3) Move your eyes diagonal.
- High energy blue light may lead to eye strain and AMD (Age-Related Macular Degeneration). Blue light Filter to reduce 70% (max.) harmful blue light to avoiding CVS (Computer Vision Syndrome).

4. Self Calibration

Perform standalone calibration to ensure color accuracy every working period.



To maintain the accuracy of the schedule, ensure that the AC switch is always set to ON position.






5. PIP/PBP Setting

The PIP/PBP Setting allows you to open up another sub-window connected from another video source besides the main-window from your original video source. By activating this function, the monitor displays up to 2 pictures from different video sources.



To activate this function, you need to disable the HDR function.





- **PIP/PBP Mode**: Selects PIP, PBP, PBP x 3, or PBP x 4 function, or turn it off.
- PIP/PBP Source: Selects the video input source between HDMI-1, HDMI-2, HDMI-3, DisplayPort, and USB Type-C. The table below shows the input source combinations.

Cub window	Main-window				
Sub-window	HDMI-1	HDMI-2	HDMI-3	DisplayPort	USB Type-C
HDMI-1	Yes	Yes	Yes	Yes	Yes
HDMI-2	Yes	Yes	Yes	Yes	Yes
HDMI-3	Yes	Yes	Yes	Yes	Yes
DisplayPort	Yes	Yes	Yes	Yes	Yes
USB Type-C	Yes	Yes	Yes	Yes	Yes


- Color Setting: Selects an individual ProArt Preset Mode for the selected PIP/PBP source. (Up to 2 ProArt Preset modes can be chosen)
- PIP Size: Adjusts the PIP size to Small, Middle, or Large. (Only available for the PIP mode)

6. QuickFit Plus

Allows users to have a preview of the document or photo layout directly on the screen without printing the test copies.



To activate this function, you need to disable the PIP/PBP mode.





- Safe Area: Facilitates designers and users to organize content and layout on one page and achieve a consistent look and feel. The selections are: 1:1, Action Safe, Title Safe, or 3 x 3.
- **Center Marker**: Selects the center marker type. The selections are: Type 1, Type 2, or Type 3.
- Customization: You can decide the frame size by moving the Menu (5-way) button up/down/left/right. You can press the Menu (5-way) button for longer than 3 seconds to switch the measurements between millimeter and inch.
- Ruler: This pattern presents physical ruler on the top and left sides. You can press the Menu (5-way) button for longer than 3 seconds to switch the measurements between metric and imperial.

7. Input Select


In this function, you can select your desired input source.





8. System Setup

Allows you to adjust the system.





 HDR Preview: Allows you to preview non-HDR content performance with HDR10 and HLG mapping. While HDR Preview function is on, only HDR_PQ DCI, HDR_PQ Rec2020, HDR_HLG BT2100, and HDR_HLG DCI options can be chosen.



To activate this function, you need to disable the PIP/PBP mode.

- DolbyVision: Enables or disables the DolbyVision function.
- Uniform Brightness: If enabled, the maximum brightness is approximately 250 nits.

- USB Setup: Configures the USB Type-C port setting. The USB Setup
 parameter affects the output resolution only when the source is connected
 to the USB Type-C port. Due to the technological differences between
 USB 2.0 and USB 3.2, the maximum USB data throughput (bandwidth
 and other related characteristics) varies and therefore influences the
 maximum output resolution.
 - » USB 2.0 (4K2K @ 60Hz): The data transfer rate according to the 2.0 specification in USB Type-C port can output the maximum resolution of 4K2K 60Hz.
 - » USB 3.2 (4K2K @30Hz): The data transfer rate according to the 3.2 specification in USB Type-C port can only output the maximum resolution of 4K2K 30Hz.



- The data transfer rate will remain USB 3.2 when using USB Type C to A cable.
- The USB Setup setting does not affect the resolution if the source is connected to the DisplayPort or HDMI port.
- Power Saving: Specifies the power saving setting.
 - » Normal Level: Allows the USB downstream ports/USB Type-C ports to charge external devices when the monitor enters power saving mode.
 - » Deep Level: Does not allow all ports to charge external devices and keeps USB Type-C and USB signals from being automatically detected when the monitor enters power saving mode.
- OSD Setup: Configures the OSD menu settings.
 - » OSD Timeout: Adjusts the OSD timeout from 10 to 120 seconds.
 - » DDC/CI: Enables or disables the DDC/CI function.
 - » Transparency: Adjusts the OSD background from opaque to transparent.
 - » Auto Rotation: Enables or disables the automatic OSD rotation function.
- Language: Selects the OSD menu language.
- Sound: Configures the sound settings.
 - » Volume: Adjusts the output volume level.
 - » Mute: Enables or disables the mute function.
 - » Source: Specifies the monitor sound comes from which source. (Only available for the PIP/PBP mode)
- DisplayPort Stream: Compatibility with graphic card. Select DisplayPort
 1.1 or DisplayPort
 1.4 by graphic card DP version.

- Screen Sync: If enabled, the system will keep the current settings after the device wakes up from standby or sleeping mode (via DP or Type-C connection).
- **Key Lock**: Selects "On" to disable all function keys. To cancel the Key Lock function, press the Close button for more than five seconds. See page 1-2 for the location of the Close button.
- **Power Indicator**: Turns the power LED indicator on/off.
- Ambient Effect: Configures the ambient effect settings.
 - » Light Effect: Adjusts the brightness level adaptively.
 - » Adaptive Color: Adjusts the color temperature adaptively.



This function will be disabled if the HDR function is enabled and the ProArt Preset setting is set to HDR_PQ DCI, HDR_PQ Rec2020, HDR_HLG BT2100, HDR_HLG DCI, or HDR_DolbyVision.

 Proximity Sensor: If the function is enabled and the system does not detect the presence of object within 30cm-1.5m over the preset time, the system will automatically decrease brightness periodically.



Recovery time should be within 2 seconds.

 Screen Protection: Ensure the life cycle of panel by decreasing brightness gradually.




This function will be disabled if the ProArt Preset setting is set to HDR_PQ DCI, HDR_PQ Rec2020, HDR_HLG BT2100, HDR_HLG DCI, or HDR_DolbyVision.

- Information: Shows the monitor information.
- All Reset: Selects "Yes" to revert all settings to the factory default mode.

3-12

9. Shortcut

Defines the functions for Shortcut 1 and 2 buttons.





• Shortcut 1/Shortcut 2: Selects a function for Shortcut 1 and 2 buttons.



When a certain function is selected or activated, your shortcut key may not support. Available function choices for shortcut: Blue Light Filter, Brightness, ProArt Preset, HDR, PIP/PBP Setting, Color Temp., Volume, User Mode 1, User Mode 2.

3.2 Specifications Summary

Panel Type	OLED PANEL	
Panel Size	31.5" wide screen	
Max. Resolution	3840 x 2160	
Pixel Pitch	0.182 mm	
Brightness	250 cd/m² (Typ.), 500 cd/m² (HDR, Peak)	
Contrast Ratio	1,000,000:1 (max.)	
Viewing Angle (H/V) CR>10	178° (H) / 178° (V)	
Display Colors	1.07 Billion (10 bit)	
Color Gamut	Adobe RGB 99.5%, DCI-P3 97%, Rec2020 80%, sRGB 100%	
Response Time	0.1ms (GTG)	
ProArt Preset Selection	14 color preset modes (2 user modes included)	
Color Temperature Selection	5 color temperatures	
Digital Input	HDMI 2.0, DisplayPort 1.4, USB Type-C	
Earphone Jack	Yes (3.5mm)	
USB 3.2 port	Upstream x 1, Downstream x 4 (USB 3.2 Gen2)	
Color	Black	
Power LED	White (On)/Amber (Standby)	
Tilt	+23° ~ -5°	
Swivel	+30° ~ -30°	
Pivot	+90° ~ -90°	
Height Adjustment	130mm	
Kensington lock	Yes	
AC input voltage	AC: 100~240V	
Power consumption	Power On: < 38 W** (Typ.), Standby: < 0.5 W, Power Off: 0 W (Switch off)	
Temperature (Operating)	0°C ~ 40°C	
Temperature (Non-operating)	-20°C ~ +60°C	
Dimension (W x H x D)	735.4mm x 466.9mm x 54.4mm (monitor only) 735.4mm x 489.1mm x 162.6mm (with mini stand) 735.4mm x 626.9mm x 245mm (with stand, highest) 735.4mm x 496.9mm x 245mm (with stand, lowest) 878mm x 616mm x 298mm (package)	

3-14

Weight (Esti.)	7.6 kg (monitor only) 8 kg (with mini stand) 12.14 kg (with stand) 12.5 kg (Net) 19.92 kg (Gross)
Multi-languages	27 Languages (English, Simplified Chinese, Traditional Chinese, Japanese, Russian, Spanish, Italian, German, French, Dutch, Portuguese, Czech, Croatia, Romania, Turkish, Arabic, Danish, Finnish, Greek, Hungarian, Slovak, Slovenian, Swedish, Polish, Korean, Persian, Ukraine)
Accessories	Quick start guide, Warranty card, Power cord, HDMI cable, USB Type-C cable, DisplayPort cable, USB Type-C to Type-A cable, Calibration report, Stand, Cable clips, Hood
Compliance and Standards	Energy Star 8.0, cTUVus, CB, CE, ErP, FCC (Class B), CCC, BSMI, CU, C-Tick(RCM), VCCI, ISO-9241-307, PSE, J-MOSS, RoHS, WEEE, Windows 10&11 WHQL, Mac Compliance***, Ukraine, VESA DisplayHDR TrueBlack 400, DolbyVision


^{*}Specifications are subject to change without notice.

^{**}Measuring a screen brightness of 200 nits without audio/USB/Card reader connection.


^{***}Requires Mac OS 11.6.x.

3.3 Outline dimensions


[Monitor]



[Monitor with mini stands]



[Monitor with stand]



3.4 Troubleshooting (FAQ)

Problem	Possible Solution
Power LED is not ON	 Press the button to check if the monitor is in the ON mode. Check if the power cable is properly connected to the monitor and the power outlet. Check if the AC switch is set to ON.
The power LED lights amber and there is no screen image	 Check if the monitor and the computer are in the ON mode. Make sure the signal cable is properly connected the monitor and the computer. Inspect the signal cable and make sure none of the pins are bent. Connect the computer with another available monitor to check if the computer is properly working.
Screen image is too light or dark	Adjust the Contrast and Brightness settings via OSD.
Screen image bounces or a wave pattern is present in the image	Make sure the signal cable is properly connected to the monitor and the computer.
Screen image has color defects (white does not look white)	 Inspect the signal cable and make sure that none of the pins are bent. Perform All Reset via OSD. Adjust the Color settings or select the Color Temperature (Color Temp.) via OSD.
No sound or sound is low	 Ensure that the HDMI/DisplayPort cable is properly connected to the monitor and the computer. Adjust the volume settings of both your monitor and HDMI/DisplayPort device. Ensure that the computer graphic card driver is properly installed and activated.

3.5 Supported operating modes

Resolution Frequency	Vertical Frequency (Hz)	Horizontal Frequency KHz)	Pixel (MHz)
640x480	59.94(N)	31.47(N)	25.18
640x480	72.82(N)	37.87(N)	31.5
640x480	75(N)	37.5(N)	31.5
720x400	70(P)	31.47(N)	28.32
720x480	59.94	31.469	27
720x576	50	31.25	27
800x600	56.25(P)	35.16(P)	36
800x600	60(P)	37.88(P)	40
800x600	72(P)	48.1(P)	50
800x600	75(P)	46.9(P)	49.5
1024x768	60(N)	48.36(N)	65
1024x768	70(N)	56.48(N)	75
1024x768	75(N)	60(N)	78.75
1152x864	75(P/N)	67.5(P/N)	108
1280x720	60	45(N)	74.25
1280x960	60(N)	60(P)	108
1280x1024	60(P)	63.98(P)	108
1280x1024	75(P)	79.98(P)	135
1440x900	60(P)	55.94(N)	106.5
1600x1200	60(P)	75(P)	162
1680x1050	60(P)	65.29(N)	146.25
1920x1080	60(P)	67.5(P)	148.5
1920x1200	59.885(P)	74.556(N)	193.25
1920x2160	60(N)	135(P)	297
2560x1080	60(N)	66(P)	198
2560x1440	59.9(N)	88.7(P)	241.5
3840x2160	23.98(P)	52.593(N)	266.75
3840x2160	25	54.786(N)	278.75
3840x2160	29.97(P)	67.5(N)	297
3840x2160	50(P)	111.174(N)	587
3840x2160(DP)	60(N)	133.3(P)	533.3
3840x2160(HDMI)	60(N)	135(P)	594

[&]quot;P" / "N" stands for "Positive" / "Negative" polarity of incoming H-sync/V-sync (input timing). When the monitor is operating in the video mode (ie, not displaying data) using the HDMI connector, the following high definition modes shall be supported in addition to standard definition video.

3-20 Chapter 3: General Instruction

Resolution	Vertical Frequency (Hz)	Horizontal Frequency (KHz)
	24	27
	25	28.125
1920x1080p	30	33.75
	50	56.25
	60	67.5
1000~1000;	50	28.13
1920x1080i	60	33.75
4.440400	59.94	31.47
1440x480p	60	31.5
1440x576p	50	31.25
1000,700	50	37.5
1280x720p	60	45

^{*} Modes not listed in the table may not be supported. For optimal resolution, we recommend that you choose a mode listed in the table above.